



OWNER'S MANUAL



U.S. Patents

8,113,137

8,191,495

Other Patents Pending



Your Owner's Manual was written to include safety instructions to ensure safe operation and maintenance of your boat. Safety alerts symbols are used to alert potential personal injury hazards.

\Lambda DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury. All instructions are viewed from the stern looking toward the bow, with starboard (to your right) and port (to your left). A glossary of boating terms is included.

Your boat produces carbon monoxide (CO) and uses flammable fuel. CO will cause BRAIN DAMAGE or DEATH. Carbon monoxide gas (CO) is colorless, odorless and extremely dangerous.

Every precaution has been taken by Pursuit Fishing Boats to reduce the risks associated with death, possible injury and damage from fire or explosion. Your own precaution and good maintenance procedures are necessary in order to enjoy safe operation of your boat.

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates a potentially hazardous situation which, if not avoided, may result in property damage.

Exposure to carbon monoxide will cause death or serious injury. Avoid direct and prolonged exposure to CO.

Gasoline and other fuels are extremely flammable and highly explosive under certain conditions.

- DO NOT smoke or allow open flame or sparks nearby when fueling.
- DO NOT block fuel vents.
- DO NOT store fuel in any containers or compartments which are not designated for storing fuel.

PURSUIT. DC 365 dual console

Table of Contents

Safety Information

Safety Information	ii
--------------------	----

Safety Label Locations

Label List	1
Label Table	2

General Information

Engine and General Specifications	13
Boat Information	14
Warranty & Warranty Registration Cards .	15
Federal Boating Safety Act	15
Product Changes	15
Transferring the Warranty	15
Owner/Operator Responsibilities	15
Towing	15
Registration and Documentation	16
Insurance	16
Reporting Boating Accidents	16
Education	16
Required Equipment	17
EPA Compliant Fuel System	17

Propulsion Systems

1.1	General 1-1
1.2	Saltwater Application 1-1
1.3	Engine Lubrication1-2
1.4	Engine Cooling System 1-2
1.5	Propellers1-2
1.6	Engine Instrumentation1-2

Helm Systems

2.1	General	2-1
2.2	Helm Access	2-1
2.3	Engine Throttle and Shift Controls.	2-1
2.4	Neutral Safety Switch	2-2
2.5	Engine Power Tilt and Trim	2-2
2.6	Engine Stop Switch	2-2

2.7	Automatic Fire Extinguisher System. 2-3		
2.8	Steering System2-4		
2.9	Optional Electronics2-5		
2.10	Trim Tabs2-5		
2.11	Compass2-6		
2.12	Bow Thruster2-6		
2.13	Spotlight (Optional)2-7		
2.11	Control Systems Maintenance 2-7		
Fue	Fuel Systems		
3.1	General		
3.2	Fuel System3-2		
3.3	Diesel Generator Fuel System3-3		
3.4	Fueling Instructions3-4		
Electrical Systems			
4.1	General4-1		
42	DC System		

4.3 12-Volt DC Panels4-5

AC System4-7

AC Main Distribution4-7 Battery Charger Operation4-8

Shore Power Connection4-9

Electrical System Maintenance 4-10

Plumbing Systems

4.4 4.5

4.6

4.7

4.8 4.9

5.1	Fresh Water System	5-1
5.2	Raw Water Washdown	5-2
5.3	Livewell	5-3
5.4	Drainage	5-3
5.5	Plumbing System Maintenance	5-5



Table of Contents

Ventilation Systems

6.1	Cabin Ventilation6-1
6.2	Windshield Ventilation6-1
6.3	Carbon Monoxide
	and Proper Ventilation6-1
6.4	Bilge Compartment Ventilation 6-1
6.5	Maintenance6-1

Exterior Equipment

7.1	Deck7-	1
7.2	Cockpit7-	4

Interior Equipment

8.1	Companionway Doors	8-1
8.2	Mid-Berth	8-1
8.3	Head Compartment	8-1
8.4	Galley	8-2
8.5	Carbon Monoxide Detector	8-2
8.6	Air Conditioner	8-2
8.7	Audio and Video Systems	8-3

Safety Equipment

9.1	General	9-1
9.2	Engine Alarms	9-1
9.3	Neutral Safety Switch	9-1
9.4	Engine Stop Switch	9-1
9.5	Automatic Fire	
	Extinguishing System	9-2
9.6	Carbon Monoxide Hazards	9-2
9.7	First Aid	9-4
9.8	Required Safety Equipment	9-5
9.9	Additional Safety Equipment	9-7

Operation

10.1	General 10-1	
10.2	Homeland Security Restrictions 10-1	
10.3	Rules of the Road 10-2	
10.4	Pre-Cruise Check10-4	
10.5	Operating your Boat10-5	
10.6	Fishing10-6	
10.7	Docking, Anchoring and Mooring 10-6	
10.8	Controls, Steering or Propulsion	
	System Failure10-8	
10.9	Grounding, Towing and	
	Rendering Assistance10-9	
Routine Maintenance		

111 General

General11-1
Exterior Hull and Deck11-1
Seats, Upholstery, Canvas
and Enclosures 11-5
Cabin Interior 11-6
Bilge 11-6
Generator (Optional)11-7


Seasonal Maintenance

12.1	Storage and Lay-up	12-1
12.2	Winterizing	12-2
12.3	Recommissioning	12-4

Appendices

Glossary of Terms	A-1
Maintenance Schedule	B-1
Maintenance Log	B-2
Boating Accident Report	C-1
Float Plan	. D-1
Troubleshooting Guide	E-1
Schematics	F-1
Fresh Water System	. G-1
Aquatic Invasive Species	H-1







Lab		Labels and Logos All Labels and Logos May Apply
1	LOGO: "P" 12V LED, LIGHTED P/N: 5346801	
2	LABEL, CAUTION - HOT WATER HEATER P/N: 5430190	CAUTION II Do Not activate hot water heater switch until water system is filled and purged of air. Secret
3	LABEL, WASHDOWN/BAITWELL PICKUP P/N: 5435220	WASHDOWN / BAITWELL PICKUP
4	LOGO: "P" SMALL PLATINUM P/N: 5437700	FURSUIT.
5	LABEL, WARNING CO HATCH P/N: 5437750	Cerbon monexide (CO) can cause brain damage or death. This hatch should not be in the open position whenever the ratires, generator or engines on adjacent vescels are running.
6	TAG, WARNING ETHANOL FUEL P/N: 5450041	And the second s
7	TAG, OVERBOARD DISCHARGE YELLOW P/N: 5450050	EXE: In the experimentation of the two experiments in the experimentation of the exper
8	LABEL, WARNING SUNSHADE STOWAGE P/N: 5450054	A WARNING Excessive wind may cause damage or injury while the sunshade is deployed. The sunshade should be stowed in the hardtop when running above idle speeds or while in windy conditions.

Labol Tabl

		Ali Labels ana Logos May Apply
9	LABEL, NOTICE DASH PANEL CLEANING P/N: 5450055	NOTTICE Clean dash panel using only soft damp cloth with mild soapy water. Blot dry with chamois or soft cloth. Do not use ammonia based cleaning fluids. Use of abrasives or chemicals may cause damage to surface.
10	LABEL, FUEL SYSTEM WARNING MYLAR P/N: 5450060	WARNING Avoid serious injury or death from fire or explosion resulting from leaking fuel. Inspect system for leaks at least once a year.
11	LABEL, BOATMAN'S CHECKLIST P/N: 5450120	Board Page (Sectoring Indiana) Sectoring System (Triangle Control and all Sectoring Control and Sectoring C
12	LABEL, "110 VOLTS" RED ON WHITE P/N: 5450170	IIO VOLTS
13	LABEL, "FRESH WATER" P/N: 5450260	FRESH WATER
14	LABEL, "RAW WATER" P/N: 5450270	RAW WATER
15	LABEL, TRANSOM DOOR WARNING P/N: 5450550	Do not operate boat with transom door open.
16	LABEL, BOARDING DOOR WARNING P/N: 5450551	Falling overboard can result in serious injury or drowning. Keep door closed while boat is underway.

Labels and Logos

Labels and Logos

Not All Labels and Logos May Apply

	Not	
17	LABEL, FISH BOX VALVE PORT P/N: 5450580	PORT FISHBOX 5450580
18	LABEL, FISH BOX VALVE STBD P/N: 5450585	STBD FISHBOX 5450585
19	PLATE, YACHT CERTIFICATION OVER 26' ALL P/N: 5450650	VACHT CERTIFICATION Sea outre termane stratum in forct owned the termane stratum in forct owned termane stratum in forct Mail and the stratum in the stratum in the stratum termine termane stratum in the stratum in the stratum termine termine stratum in the stratum in the stratum termine termine stratum in the stratum in the stratum termine termine termine termine termine termine termine termine termine termine termine termine termine Mail termine
20	LABEL, STORAGE AREA NOTICE MYLAR 3"X1-1/8 P/N: 5450710	NOTICE Do not use this area for storage. For plumbing access only.
21	LABEL, GELCOAT DAMAGE NOTICE MYLAR 3" LONG P/N: 5450720	NOTICE Gelcoat damage may result if anchor is not properly secured.
22	LABEL, "FORWARD" MECHANICAL HATCH P/N: 5450730	† FORWARD
23	TAG, LEXAN "GENERATOR PICKUP" P/N: 5450800	GENERATOR PICKUP
24	TAG, LEXAN "HEAD OVERBOARD DISCHARGE" P/N: 5450805	HEAD OVERBOARD DISCHARGE

PURSUIT. DC 365 DUAL CONSOLE

25	TAG, LEXAN "AIR CONDITIONING PICKUP" P/N: 5450810	
26	TAG, LEXAN "WASHDOWN PICKUP" P/N: 5450815	WASHDOWN PICKUP
27	TAG, LEXAN "BAITWELL PICKUP" P/N: 5450820	BAITWELL PICKUP
28	TAG, LEXAN "FUEL SYS ENG WITHDRAWL STBD" P/N: 5450825	FUEL SYSTEM ENGINE WITHDRAWAL STARBOARD
29	TAG, LEXAN "FUEL SYS ENG WITHDRAWL PORT" P/N: 5450830	FUEL SYSTEM ENGINE WITHDRAWAL PORT
30	TAG, LEXAN "FUEL SYS GENERATOR WITHDRAWL" P/N: 5450835	FUEL SYSTEM GENERATOR WITHDRAWAL
31	TAG, LEXAN "FUEL SYSTEM GENERATOR RETURN" P/N: 5450840	FUEL SYSTEM GENERATOR RETURN
32	TAG, LEXAN "TO DECK PUMPOUT" P/N: 5450845	TO DECK PUMPOUT

Labels and Logos

Labels and Logos

Not All Labels and Logos May Apply

33	TAG, LEXAN "FROM WASTE TANK" P/N: 5450850	FROM WASTE TANK
34	TAG, LEXAN, GREEN "WINTERIZED" P/N: 5450855	N H H R R H Z Z N N
35	LABEL, HAZARDOUS VOLTAGE (WRAP AROUND) P/N: 5451120	A WARNING Market Network Preserve and weak of the conversion of the addition of the local or preserve conversion, may and the conversion of the conversion of the addition Preserve and the observe conversion, may addition of the addition of the addition Preserve and the addition Preserve addit Preserve addit Preserve addition Preser
36	LABEL, NO SMOKING P/N: 5451130	
37	LABEL, CAPACITY TOWER Y8 P/N: 5451160	TOWER CAPACITY 2 PERSONS OR 450 LBS
38	LABEL, DANGER PROPELLER, SWIM PLATFORM P/N: 5451181	CONTACT WITH A SPINNING PROPELLER WILL CAUSE SERIOUS INJURY OR DEATH. DO NOT USE SWIM LADDER OR SWIM PLATFORM WHILE ENGINE(S) ARE RUNNING SHUT OFF ENGINE(S) while people are in the water near the boat, on the swim platform, or on the boarding ladder. NEVER OPERATE IN REVERSE TOWARD A PERSON in the water
39	LABEL, SWIM LADDER DANGER P/N: 5451751	A DANGER CONTACT WITH A SPINNING PROPELLER WILL CAUSE SERIOUS INJURY OR DEATH. DO NOT USE SWIM LADDER OR SWIM PLATFORM WHILE ENGINE(S) ARE ENGINE(S) ARE ENGINE(S) ARE ENGINE(S) ARE ENGINE(S) ARE
40	LABEL, MANUAL DOOR OVERRIDE "UP" P/N: 5451781	For Manual Override of Door Latch 1. Remove access plate 2. Move lever as indicated by arrow

PURSUIT. DC 365 dual console

41	LABEL, "FIRE EXTINGUISHER INSIDE" P/N: 5452010 LABEL, "ESCAPE HATCH" WHITE/CLEAR P/N: 5452020	NSIDE
43	LABEL, WARNING "DO NOT RUN W/HELM OPEN" P/N: 5452510	WARRNING UNDER NO CIRCUMSTANCES SHOULD THE HELM BE OPEN BUTHEN THE ENGINES ARE RUNNIG, IT IS POSSIBLE TO ENGAGE THE ENGINE SHIFT INTO GEAR AND/OR ADVANCE THROTTLE CONTROLS AS THE HELM IS OPENNIG, THIS COULD RESULT IN LOSS OF CONTROL, AND/CR PERSONAL INJURY. ALWAYS MAKE SURE THE HELM IS CLOSED AND PROPERLY LATCHED BEFORE STARTING THE ENGINES.
44	LABEL, WARNING HARDTOP P/N: 5453160	WARNING Hardtop is not a weather deck. Falling from hardtop can result in serious injury or death. Stay off hardtop.
45	TAG, WARNING CA CODE PROP 65 P/N: 5453551	Andre Andre Andre Andre Andre Andre Andre Andre
46	LABEL, "SLING" PS POLYESTER P/N: 5453600	SLING
47	LABEL, TRANSOM CO CALIFORNIA P/N: 5453650	A DANGER Profession and generative for the state of the
48	LABEL, WARNING CO CABIN P/N: 5453680	Carbon monoxide (Co) can cause brain damage or desm. Carbon monoxide (Co) can cause brain damage or desm. Carbon monoxide polaring hydride manese, lesdache, diszlinesa, drowsitiesa, and lack of consciousness, lesdache, diszlinesa, drowsitiesa, and lack of consciousness, lesdache, def fresh air fl aryton monoxide delector alarm sounds. Carbon monoxide delector must be functioning at all times.

Labels and Logos



Labels and Logos

Not All Labels and Logos May Apply

49	LABEL, WARNING CO HELM P/N: 5453690	Arbon monoxide (CO) can cause brain damage or desth. Engline and generator axisuat contains otherises and colorises carbon monoxide ges. Signe of carbon monoxide poisoning include nausea, headache, dizzness, drowsiness, and lack of consciousness. See Owner's Manual for information regarding carbon monoxide poisoning. See Owner's Manual for information regarding carbon monoxide poisoning.
50	LABEL, "NO STEP" 3"X8" RED/WHITE P/N: 5453970	NO STEP
51	LABEL, KIT FOR FUSE BLOCK P/N: 5454010	
52	PLATE, CAPACITY C 238 MY2016 P/N: 5454215	MAXIMUM CAPACITIES Descent of the reaction of
53	PLATE, CAPACITY DC 235 MY2017 P/N: 5454216	A Contract of the second secon
54	LABEL, "DISCHARGE OF OIL PROHIBITED" P/N: 5454490	Discharge of all provided and and all provided and all pr
55	LABEL, "TRASH OVERBOARD DISCHARGE" P/N: 5454500	
56	LABEL, FILL W/DIESEL ONLY P/N: 5454580	FILL WITH DIESEL FUEL ONLY

PURSUIT. DC 365 DUAL CONSOLE

57	LABEL, "NMMA" CERT SLVR/BLK 2IN CIRCLE P/N: 5455250	ERTIFICATION - MARK
58	LABEL, ENGINE FLUSHING SYSTEM P/N: 5455602	OUTBOARD FLUSHING SYSTEM PRESS ONCE = 15 MIN PRESS TWICE = 7.5 MIN PRESS THIRD = STOP CAP INLET WHEN NOT IN USE MASSAGE
59	LABEL, NOTICE CONSISTENT TEMPERATURE P/N: 5455650	NOTICE To ensure consistent internal temperature drain plugs must be used 5455650
60	LABEL, NOTICE KEEP HATCHES CLOSED P/N: 5455660	NOTICE Keep cockpit hatches closed while underway 5455660
61	LABEL, WARNING HOT SURFACE - GRILL P/N: 5455680	A WARNING HOT SURFACE MAY CAUSE SEVERE BURNS DO NOT OPERATE GRILL WHILE BOAT IS UNDERNWAY ALLOW GRILL TO COOL BEFORE CLOSING LID
62	LABEL, WARNING V - BERTH TABLE P/N: 5455770	To prevent serious injury or property damage confirm that the area around the table is clear of obstructions before lowering or raising. 545577
63	LABEL, WARNING AFT FACING SEAT P/N: 5455780	To prevent serious injury port and starboard seat locks must be fully engaged before use. 545578
64	LABEL, WARNING "DO NOT DRILL" P/N: 5455830	A WARNING Do Not Drill Into This Bulkhead

Labels and Logos

Labels and Logos

_		All Labels and Logos May Apply
65	LABEL, DANGER "DO NOT EXCEED 1000LB CAP" P/N: 5455840	Avoid injury or death. DO NOT overload the pylon or use it for anything other than water sports. Only one skier can be towed with the pylon. 5455840
66	LABEL, WARNING SUNPAD FILLER P/N: 5455870	A WARNING SUNPAD FILLER NOT INTENDED TO BE OCCUPIED WHILE UNDERWAY MAX LOAD 250 LBS. 5455870
67	LABEL, WARNING NO FLAMMABLE LIQUIDS P/N: 5455950	Avarning Fuel vapors are a fire and explosion hazard. To avoid injury or death, do not store gasoline or petrol or flammable liquids in any fishbox, storage or bilge access compartments. 5455950
68	LABEL, WARNING WINDLASS LEWMAR P/N: 5455960	A CONTRACTOR DE LA CONTRACTOR DE LA CONTRACTÓR DE LA CONT
69	LABEL, NOTICE ANCH RODE LEWMAR P/N: 5455970	NOTE: ON OCCASION, YOU MAY HAVE TO CLEAR The Pile of Rope from under the hawse Pipe to make room for the remaining rode.
70	LABEL, NOTICE BALL VALVE ACTUATOR P/N: 5456080	PULL TO OPEN PUSH TO CLOSE
71	LABEL, HOUSE BATTERY & BREAKER LOCATION P/N: 5456081	House battery and breaker located behind cabinet. 6466081
72	LABEL, NOTICE WINDSHIELD CLEANING P/N: 5456090	NOTICE Wash windshield only with soapy water. Use of abrasives, pressure cleaners and chemicals can cause irreparable damage.



Labels and Logos

73	LABEL, CAUTION "SEAT ASSEMBLY" P/N: 5450215	CAUTION Seat assembly moves fore and aft. To avoid pinching and/or bodily harm, stay clear of path of travel while seat is in motion. Do not operate while seat is occupied.
74	LABEL, WARNING "FALLING OVERBOARD" P/N: 5450062	CALC WARNING Falling overboard can result in serious injury or drowning. Keep cockpit door and platform closed while boat is underway. 5450062
75	LABEL, "SHORE WATER SUPPLY" P/N: 5450082	NOTICE SHORE WATER SUPPLY SHALL BE SHUT OFF WHEN THE BOAT IS UNATTENDED. 5450082
76	LABEL, WARNING "FALLING OVERBOARD" P/N: 5454491	EXAMPLANCE Falling overboard can result in injury or drowning. Keep hull side platform closed while boat is underway. Risk of pinching and/or bodily harm. Stay clear of path of travel while door is operating and maintain clear view of movement. Operator must ensure locking bolts are engaged fully when door is closed. Only board hull side platform when it is in the fully open position.
77	LABEL, WARNING "FALLING FROM HARDTOP" P/N: 5453601	CALC CALC C



Labels and Logos

	NOT AII LABEIS ANA LOGOS MAY APPIY			
78	LABEL, GYRO PICKUP P/N: 5450821	O O GYRO PICKUP O O		
79	LABEL, GYRO DISCHARGE P/N: 5450822	GYRO DISCHARGE		
80	LABEL, BATTERY TRAY P/N: 5456085	CAUTION Property damage will occur if sliding battery tray is not secured. Locking pin must be engaged when boat is underway.		
81	LABEL, "AMERICAN MADE" 2.4" X 12" P/N: 5455601	AMERICAN MADE		
82	MODEL DESIGNATOR LABEL, "DC 365" P/N: 5456045	SAMPLE		



Engine and General Specifications

Maximum Horsepower	1050 HP (783 kW)
L.O.A	
Beam	12' 0" (3.66 meters)
Draft (fully loaded, motors up)	
Draft (fully loaded, motors down)	3' 1" (0.94 meters)
Clearance with Hardtop (from waterline)	9' 3" (2.81 meters)
Average Dry Weight	17,000 lbs. (7,710 kg)
Fuel Capacity	326 U.S. gallons (1,234 liters)
Generator Diesel Capacity	
Water Capacity	
Holding Tank Capacity	
Deadrise at Transom	



Boat Information

Fill out the following information and leave it in your PURSUIT Owner's Manual. This information will be important for you and PURSUIT service personnel to know, if and when you may need to call PURSUIT for technical assistance or service.

	Boat	
Model:	Hull Serial #:	
Purchase Date:	Delivery Date:	
Ignition Keys #:	Registration #:	
Draft:	Weight:	
	Engine(s)	
Make:	Model:	
Port Serial #:	Starboard Serial #:	
Tr	ansmission(s) (Inboard)	
Make:	Model:	
Port Serial #:	Starboard Serial #:	
Ratio:		
Outd	lrive(s) (Inboard/Outboard)	
Make:	Model:	
Port Serial #:	Starboard Serial #:	
	Propellar(a)	
	Propeller(s)	
Make:	Blades:	
Diameter/Pitch:	Other:	
	Generator	
Make:	Model:	
Serial #:	kW:	
Dealer	Pursuit	
Name:	Phone:	
Dealer/Phone: Salesman:	Representative: Address:	
Salesman: Service Manager:		
Address:		

PURSUIT Fishing Boats reserves the right to make changes and improvements in equipment, design and vendor supplied equipment at any time without notification.



Warranty and Warranty Registration Cards

The PURSUIT Limited Warranty Statement is included with your boat. It has been written to be clearly stated and easily understood. If you have any questions after reading the warranty, please contact PUR-SUIT Customer Relations.

PURSUIT, engine manufacturers, and the suppliers of major components maintain their own manufacturer's warranty and service facilities. It is important that you properly complete the warranty registration cards included with your boat and engine(s) and mail them back to the manufacturers to register your ownership. This should be done within 15 days of the date of purchase and before the boat is put into service. A form for recording this information is provided at the beginning of this manual. This information will be important for you and service personnel to know, if and when you may need service or technical information.

The boat warranty registration requires the Hull Identification Number "HIN" which is located on the starboard side of the transom, just below the rub rail. The engine warranty registration requires the engine serial number(s). Please refer to the engine owner's manual for the location of the serial number(s).

Federal Boat Safety Act

All boat manufacturers are required by the Federal Boat Safety Act of 1971 to notify first time owners in the event any defect is discovered "which creates a substantial risk of personal injury to the public." It is essential that we have your warranty registration card complete with your name and mailing address in our files so that we can comply with the law if it should become necessary.

Product Changes

PURSUIT is committed to the continuous improvement of our boats. As a result, some of the equipment described in this manual or pictured in the catalog may change or no longer be available. PURSUIT reserves the right to change standard equipment, optional equipment and specifications without notice or obligation. If you have questions about the equipment on your PURSUIT, please contact PURSUIT Customer Relations.

Transferring the Warranty

Pursuit Boats will extend warranty coverage to subsequent owners of Pursuit models for the duration of the original warranty period. Please refer to the Pursuit Limited Warranty Statement for the procedure to transfer the warranty. To take advantage of this program, notification of the change of ownership, including the new owner's name, address and telephone number must be sent to Pursuit Boats, Customer Relations Department, 3901 St. Lucie Boulevard, Ft. Pierce, Florida 34946, within 30 days of resale.

Pursuit Boats will confirm, in writing, that the transfer of warranty has taken place. After which, the transferee will be treated as the original purchaser as outlined in the Pursuit Limited Warranty Statement.

Owner/Operator Responsibilities

Towing

Pursuit Boats offers a custom bow tow eye on certain models as an optional feature. If your boat is equipped with this optional feature the following operational guidelines must be followed to prevent damages or injury from occurring during towing operations:

Ensure that towing tackle is properly rated/ sized for the weight of your vessel.

Inspect the towing tackle prior to and at the end of every towing operation.

Prior to towing, close all seacocks which are designed to pick up raw water for air conditioning, generator, washdown pumps and live wells. Close all seacocks which are designed to discharge water through the hull bottom or hull sides for macerators, fish box pumps and deck drains. This will prevent flooding of mechanical spaces if a break in a



line were to occur. Since it is assumed the vessel will be unoccupied during towing operations this is a critical step prior to beginning the towing operation.

On boats equipped with a generator, the generator exhaust outlet must be sealed to prevent water filling exhaust and flooding generator engine block/cylinders. This can be accomplished by installing an expandable plug in the exhaust outlet. Note, after a towing operation is completed and prior to starting the generator, the exhaust outlet plug must be removed. Failure to remove the exhaust outlet plug can lead to damage to the generator, it's exhaust system and/or associated components.

Sea conditions will dictate the speed at which your boat can be safely towed. Be mindful of changing conditions and adjust towing speeds accordingly.

It is the owner's responsibility to ensure these guidelines are followed during all towing operations. Failure to follow the guidelines can possibly lead to damages or injury. Damages to equipment and/or the vessel which are deemed to be caused by failure to follow the guidelines can void any warranty coverage.

On models which do not offer an optional factory installed custom bow tow eye, owner will assume all responsibility for damages to the vessel and equipment which are deemed the result of installation and or use of the non-factory tow eye.

Registration and Documentation

Federal law requires all undocumented vessels equipped with propulsion machinery be registered in the state of principal use. A certificate of documentation will be issued upon registration. These registration numbers must be displayed on your boat. The owner/ operator of a boat must carry a valid certificate of registration whenever the boat is in use. When moved to a new state of principal use, the certificate is valid for 60 days.

In order to be valid, the numbers must be installed to the proper specifications. Check with your dealer or state boating authority for numbering requirements. The Coast Guard issues the certificate of number in Alaska; all others are issued by the state.

Insurance

In most states the boat owner is legally responsible for damages or injuries the boat causes. Responsible boaters carry adequate liability and property damage insurance for their boat. You should also protect the boat against physical damage and theft. Some states have laws requiring minimum insurance coverage. Contact your dealer or state boating authority for information on the insurance requirements in your boating area.

Reporting Boating Accidents

All boating accidents must be reported by the owner or operator of the boat to the proper marine law enforcement authority for the state in which the accident occurred. Immediate notification is required if a person dies or disappears as a result of a recreational boating accident.

If a person dies or there are injuries requiring more than first aid, a formal report must be filed within 48 hours.

A formal report must be made within 10 days for accidents involving more than \$500.00 damage or the complete loss of a boat.

A "Boating Accident Report" form is located near the back of this manual to assist you in reporting an accident. If you need additional information regarding accident reporting, please call the Boating Safety Hotline, 800-368-5647 or uscgboating.org.

Education

If you are not an experienced boater, we recommend the boat operator and other people that normally accompany the operator, enroll in a boating safety course. Organizations such as the U.S. Power Squadrons, United States Coast Guard Auxiliary, State Boating Authorities and the American Red Cross offer excellent boating educational programs. These courses are worthwhile even for experienced boaters to sharpen your skills or bring you up to date on current rules and regulations. They can also help in pro-



viding local navigational information when moving to a new boating area. Contact your dealer, State Boating Authority or the Boating Safety Hotline, 800-368-5647 or uscgboating.org for further information on boating safety courses.

Required Equipment

U.S. Coast Guard regulations require certain equipment on each boat. The Coast Guard also sets minimum safety standards for vessels and associated equipment. To meet these standards some of the equipment must be Coast Guard approved. "Coast Guard Approved Equipment" has been determined to be in compliance with USCG specifications and regulations relating to performance, construction or materials. The equipment requirements vary according to the length, type of boat, and the propulsion system. Some of the Coast Guard equipment is described in the Safety Equipment Section of this manual. For a more detailed description, obtain "Federal Requirements and Safety Tips for Recreational Boats" by contacting the Boating Safety Hotline 800-368-5647, uscgboating.org or your local marine dealer or retailer.

Some state and local agencies go beyond USCG regulations or impose similar equipment requirements on waters that do not fall under Coast Guard jurisdiction. Contact your dealer or local boating authority, they can provide you with additional information for the equipment requirements for that boating area.

EPA Compliant Fuel System

EPA (Environmental Protection Agency) regulations have required additional emissions related components for the fuel tank, fuel fill and fuel vent systems. It is unlawful to remove or intentionally defeat these emission related components.



Operator Notes

	_

Propulsion Systems

1.1 General

Your Pursuit boat is designed to be powered with triple 4-cycle outboard engines.

Each manufacturer of the various outboard engines provides an owner's information manual which includes its limited warranty statement with its product. It is important you read and understand the information and become familiar with the warranty, operation and maintenance of the engines and drive systems.

NOTICE

DO NOT attempt to service any part of the outboard or boat systems unless you are familiar and qualified to do so. Do not use parts which are not designed for a marine application.

🛆 WARNING

MOVING PARTS HAZARD

Contact with moving parts can entangle, cut and cause death or serious injury. DO NOT get close enough to make contact with any running machinery moving parts, i.e., engine or propeller. Contact can result in loss of body parts, strangulation, burns and/or severe loss of blood resulting in death or serious injury.

NOTICE

Use only the fuel recommended by the engine manufacturer. Use of old, contaminated fuel can cause the engine to malfunction or severe damage.

1.2 Saltwater Application

Each outboard engine is a complete drive system with the gear case (transmission) forward of the propeller and connected to the power head with a vertical drive shaft. Other than the routine maintenance outlined in the engine owner's manual, there is little to be concerned with unless the boat is to be kept in saltwater for extended periods. Marine growth will occur when components are left in the water for extended periods and can cause poor performance or permanent damage to the exposed components. The type of growth and how guickly it occurs is relative to the water conditions in your boating area. Water temperature, pollution, current, etc. can have an effect on marine growth.

NOTICE

DO NOT use copper-based coatings or any coatings not approved for use with aluminum. Some paint manufacturers claim their paints are safe for aluminum. Copper components and copper-based paints can cause severe corrosion to aluminum. DO NOT use copper-based paints. Mercury or mercury-based compounds that come into contact with aluminum will result in severe corrosion.

Section 1

Galvanic corrosion is the corrosion process occurring when different metals are submerged in an electrolyte. Sea water is an electrolyte and submerged engine components must be properly protected. Outboard engines are equipped with sacrificial anodes to help prevent galvanic corrosion problems. The anodes must be monitored and replaced as necessary. For locations and maintenance, refer to the engine owner's manual.

When leaving the boat in the water, tilt the motors as high as possible to decrease the risk of marine growth around the cooling inlets, propeller and exhaust ports and damage from galvanic corrosion.

1.3 Engine Lubrication

4-cycle engines have an oil sump in the crankcase. The oil type, grade and level must be followed in accordance with the engine manufacturer's recommendation. It is normal for 4-cycle engines to consume a small amount of oil. Check the oil level before each use and change it following the engine manufacturer's recommendation.

NOTICE

Use only the oil recommended by the engine manufacturer, and monitor the oil level. Use of any other type of oil can cause the engine to malfunction or severe damage.

1.4 Engine Cooling System

Outboard engines are raw water (sea water) cooled. Water is pumped through the water inlets, circulated through the engine block, and expelled with the exhaust through exhaust port, water port and the propeller hub. The water pump uses a small impeller made of synthetic rubber. The impeller and water pump cannot run dry for more than a few seconds. In most outboard engines, some cooling water is diverted through ports below the engine cowling. This allows the operator to visually check the operation of the cooling system. When the engine is started, make sure a steady stream of water is present.

NOTICE

DO NOT operate an engine out of the water, even momentarily. Water must be supplied to the cooling system of the power head and water pump, or serious damage will result. If it is necessary to run the engine out of the water, connect it to an engine flush attachment design for your specific engine.

If the boat is used in salt or badly polluted water, flush the engines after each use to reduce corrosion. Refer to the engine owner's manual for the proper engine flushing procedure.

1.5 Propellers

The propellers convert the power of the engines into thrust. Propellers vary in style, diameters and pitch. The best set for your needs will depend on your application and expected average load. Propeller sizes are identified by two numbers stamped on the prop in sequence; the first is the diameter and the second is the pitch (example 14 x 21). Pitch is the theoretical distance the propeller will travel in one rotation. Repair or replace a propeller immediately if it has been damaged. A damaged propeller can cause vibration that can be felt in the boat and can damage the engine gear case. Refer to the engine owner's manual for information on propeller removal and installation.

1.6 Engine Instrumentation

The helm station is equipped with a set of engine instruments and alarms. The instruments allow the operator to monitor the operational conditions of the engines. Monitoring the instrumentation allows the operator to operate the engines most efficiently and prevent serious costly damage. The instrumentation is unique to the type of out-



Propulsion Systems

board engines installed on your Pursuit. Your boat may not be equipped with all of the following gauges.

Some models may be equipped with Yamaha Command Link Integrated Information System®. Refer to the Yamaha manuals for information on the operation of this system.

Tachometer

The tachometer displays the speed of the engine in revolutions per minute (RPM). This speed is not the boat speed or the speed of the propeller. The tachometer may not register zero with the key in the "OFF" position.

NOTICE

DO NOT exceed maximum recommended engine RPM. Exceeding, maintaining or close to maintaining maximum RPM can reduce engine life.

Speedometer

The speedometer indicates the speed of the boat in miles per hour (MPH). Most speedometers measure the water pressure against a small hole in a pick-up tube located in the engine lower unit or from GPS in a Yamaha® installation.

Temperature Warning

The temperature warning indicates the temperature of the engine. A sudden increase in the temperature could indicate an obstructed water inlet or an impeller failure.

NOTICE

Continued operation of an overheated engine will cause severe engine damage. If the engine overheats, shut off the engine, investigate the problem and correct it.

Fuel Gauge

The fuel gauge indicates the approximate fuel level in the fuel tanks. This gauge is a relative indication of the fuel supply available; it is not a calibrated instrument.

Voltmeter

The voltmeter displays the voltage for the battery and the charging system. The normal voltage for a full charged battery is 12.6 volts with the engine(s) off and 13 to 14.5 volts with the engine(s) running.

Hourmeter

The hourmeter keeps a running total of engine hours while operating.

Tilt/Trim Gauge

The tilt/trim gauge monitors the position of the outboard engine. The upper range of the gauge indicates the tilt, which is used for shallow water operation, trailering and to keep the gear case out of the water. The lower range indicates the trim position. Trim is used to adjust the hull angle while operating your boat on plane. Refer to the engine owner's manual for more information on the operation of the outboard power tilt and trim.



Engine Alarms

Most outboards are equipped with an audible alarm system mounted in the helm area to monitor selected critical engine systems and functions. The alarm will sound if one of these systems begins to fail. Refer to the engine owner's manual for information on the alarms installed with your engines.

NOTICE

If an engine alarm sounds, shut off the engine, investigate the problem and correct it.

Fuel Management

Fuel management systems are standard equipment with some outboard engines. On Yamaha® engines, the fuel management gauge is a multifunction gauge used to monitor fuel consumption of the engines. If your boat is equipped with this system, refer to the engine or fuel management manual.

Instrument Maintenance

Electrical system, instruments and ignition circuitry are protected by a circuit breaker or fuse located on the engine. The ignition switches and all instruments, controls, etc. must be protected from the weather when not in use. Excessive exposure can lead to gauge and ignition switch failures.

Moisture may fog the inside of the gauge lens. Turning the gauge lights on will help dry the lenses. Fogging will normally not harm the gauges, but if the fogging continues and moisture accumulates, the excess water can damage the gauges. The gauges are designed with drain holes to reduce the accumulation of moisture. Make sure that if a gauge is removed, it is reinstalled with the drain holes in the proper position.



Helm Systems

2.1 General

The helm controls consist of engine throttle and shift controls, steering system, trim tab control switches, optional spotlight and the optional bow thruster controls.

Each manufacturer of the control components provides an owner's manual with its product. It is important that you read, understand and become familiar with the proper care and operation of all control systems.

2.2 Helm Access

The helm and engine controls are located on an opening helm station. The helm station is hinged at the bottom and opens to provide access to service the helm equipment. To open, slide the seat back to its furthest aft position and tilt the steering wheel to the full upright position and open the two latches securing the helm in place. A strap holds the helm in the open position. To secure the helm back in place, close the helm and secure the two latches. The helm station must be secured before operating or transporting your boat. Injury or damage can occur if the helm is left unsecured. Do not open the helm station with engines running: accidental engagement of shift and throttle levers can occur.

LOSS OF CONTROL AND UNSAFE BOAT HAZARD

Hazard from improper securing of helm is hazardous and can cause death or serious injury from sudden loss of control. Make sure the helm is secure before getting underway and during transporting the boat.

2.3 Engine Throttle and Shift Controls

The shift and throttle controls on your boat may vary depending on the engines. The following control description is typical to most outboard remote controls. Refer to the engine or control manuals for specific information on the controls installed on your Pursuit.

The helm on your Pursuit is designed for a binnacle style control with a single gear shift and a throttle lever for each engine; a position for neutral (straight up and down), forward position (first detent forward of neutral) and reverse position (the first detent aft of neutral). Advancing the control lever beyond the shift range will advance throttle, forward or reverse. Each control is equipped to allow the engine to be operated above idle RPM while in neutral for cold starting or warming up.

The handles of dual lever controls may not always align with each other at all RPM settings because of variations in adjustments at the engine. Usually the alignment of the handles can be optimized at a chosen RPM, but may vary at other settings.

Avoid possible injury or engine damage when shifting:

Pause in neutral before shifting from FORWARD to REVERSE, or REVERSE to NEUTRAL.

- DO NOT shift into reverse while the boat is traveling forward at speed.
- Keep area around shifter control clear of obstructions.

See your Pursuit dealer for necessary control adjustments. If the starter for either engine engages with the shift controls in any position other than neutral, the neutral safety switch is not functioning properly and must be repaired before using your boat.



2.4 Neutral Safety Switch

Every control has a neutral safety switch to prevent the engine from being started while in gear. Control adjustments must be performed if the engine will start in forward or reverse.

Test the neutral safety switches periodically to ensure they are operating. To test the neutral safety switches; tilt the engines down and move the shift levers to the forward position, past first detent. DO NOT advance past the idle position. Turn the ignition key to the start position. The starter should not engage for either engine. Repeat test with the shift levers in reverse and the engine throttles at idle, the starter should not engage for either engine. If an engine starts in gear during this test, immediately move the control levers to the neutral position and turn the engine off. Ejection or sudden loss of control can occur if an engine can start in gear and neutral safety switch system does not function properly.

Test the neutral safety switch periodically. If the switch is not operating properly, DO NOT use the boat. Contact your Pursuit Dealer and have it repaired. A neutral safety switch not operating properly can allow the boat to start in FORWARD or REVERSE causing sudden boat movement and throwing operator and passengers.

LOSS OF CONTROL AND UNSAFE BOAT HAZARD

A neutral safety switch that does not function properly can cause death or serious injury. DO NOT operate the boat if the switch does not function properly.

2.5 Engine Power Tilt and Trim

All outboard engines used on your boat have a tilt and trim feature. The tilt and trim switches are usually built into the engine shift and throttle controls and allow the operator to control the position of the outboards from the helm. Moving the gear cases closer to the boat transom is called trimming "in" or "down." Moving the gear cases away from the boat transom is called trimming "out" or "up." In most cases, the boat will perform best with the outboards adjusted so the hull will run at a three to five degree angle to the water.

The term "trim" generally refers to the adjustment of the outboards within the first 20 degree range of travel. This is the range used while operating your boat on plane. The term "tilt" refers to adjusting the outboards further up for shallow water operation, trailering or "tilting" the outboards out of the water. Refer to the engine owner's manual for information on the proper use and maintenance of the power tilt and trim.

NOTICE

The outboard hoses, rigging or the transom gel coat can be damaged if the engine(s) are tilted to full up position or turned in the wrong direction. Turn the steering wheel completely to one direction or the other before tilting up to determined which direction is best for your boat.

2.6 Engine Stop Switch

Your Pursuit is equipped with an engine stop switch and lanyard. When the lanyard is pulled away, it will shut off the engines.



LOSS OF CONTROL AND UNSAFE BOAT HAZARD

An engine stop switch system that does not function properly or is not used can cause death or serious injury. DO NOT operate the boat if the emergency stop switch system does not function properly.

Attach the engine stop switch lanyard to a strong piece of clothing on the operator. The engines will not start if the clip is not inserted into the stop switch. Make sure the lanyard is properly attached to the engine stop switch before attempting to start the engine.

DO NOT use the switch to stop the boat under normal operation. Test the switch periodically, if the switch is not operating properly, DO NOT use the boat. Contact your Pursuit Dealer and have it repaired.

The boat is provided with a spare engine stop switch lanyard. The spare lanyard allows the engine(s) to be re-armed in case of the primary lanyard becoming disconnected and lost or unreachable during boat operation. The spare lanyard is to be kept in a readily accessible location near the helm. If your boat is equipped with a stainless button-like post, snap the spare lanyard in place for secure and accessible storage.

Refer to the engine owner's manual for more information on the engine stop switch.



2.7 Automatic Fire Extinguisher System

FIRE/EXPLOSION HAZARD

The gas of the fire extinguisher system displaces oxygen to "smother" the fire. DO NOT open the hatch. Oxygen can feed a fire and flashback can occur which can cause death or serious injury. If the onboard fire system discharges, wait at least 15 minutes before opening engine hatch.

The generator is equipped with an automatic fire extinguishing system. The extinguisher has been chosen and located to provide sufficient coverage of the generator compartment. While the system helps ensure bilge fire protection, it does not eliminate the U.S. Coast Guard requirement for hand held fire extinguishers.

The system is equipped with an engine shutdown circuit to automatically shut down the generator. The red light on the fire extinguisher control panel will light and an alarm will sound if this should occur. When sufficient time has elapsed for the fire to be extinguished and a flashback is no longer possible, find and fix the problem, then the override switch on the control panel can be moved to the "OVERRIDE" position and the engines can be restarted. Refer to the Automatic Fire Extinguisher System in the Plumbing Systems.

Start Stop Switch Panel



Section 2

If the extinguisher system is activated, shut down all engines immediately. Turn off all electrical systems, powered ventilation and extinguish all smoking materials. DO NOT open the engine compartment hatch, this will feed oxygen to the fire and a flashback can occur. Allow the extinguishing agent to soak the generator compartment for at least 15 minutes and wait for hot metals or fuels to cool before inspecting for cause or damage. Have an approved portable fire extinguisher at hand and ready for use and DO NOT breathe fumes or vapors caused by the fire. It is extremely important that you read, understand and know how this system works, refer to the manufacturer's literature.



Automatic Fire Extinguisher Display Unit

2.8 Steering System

The steering system is hydraulic and made of two main components: the helm assembly and the hydraulic cylinder. The helm unit acts as both a fluid reservoir and pump. Turning of the helm, or steering wheel, pumps the fluid in the hydraulic hoses and activates the hydraulic cylinder causing the motors to turn. A slight clicking sound may be heard as the wheel is turned. This sound is the opening and closing of valves in the helm unit and is normal. Refer to the steering manufacturer owner's manual for specific information on the steering system.

Triple engine outboards are coupled at the tiller arms by a tie bar. The outboards must be aligned with each other to provide maximum stability on straight ahead runs and proper tracking through corners. If damage has ever occurred with the outboards or steering system, the outboards may have to be realigned.

NOTICE

Some autopilot systems have engine position sensors mounted to the hydraulic steering cylinder. The sensor bracket can contact the transom when the engines are fully tilted up and damage the autopilot, engine rigging or transom. Monitor the bracket and rigging while engines are tilting to determine the best position for your application.

Power Steering

The power steering system uses an electrically controlled hydraulic pump to provide power to the standard hydraulic steering system. Additional components are a helm mounted power steering switch and a hydraulic pump. The switch activates the power steering feature. Manual steering is always available regardless of the switch position. To reduce the sensitivity of the steering, turn off the power steering at low speeds. To conserve battery power, because of limited engine charging output during extended periods of slow speed operation, the power steering should be turned off. Refer to the Teleflex® Power Assist manual for more information.

Yamaha Helm Master (Optional)

The Yamaha Helm Master system is an option. Before using this system, you should carefully review the Yamaha Owner's Manual for important safety warnings and information, including important operating information and instructions.



NOTICE

If your boat is equipped with the Yamaha Helm Master system it is very important to install the trailering clips on each steering cylinder when transporting the vessel. Failure to do so can cause damage to the engine cowlings.

Ensure steering lock clips are removed BEFORE operating boat. Failure to remove steering lock clips may result in no steering control and potential injury.

Tilt Helm

A tilt helm and steering wheel is installed on your boat. To tilt the helm, depress the lever located in the base of the helm and move into position. DO NOT adjust when the boat is underway.

2.9 Optional Electronics

If your boat is equipped with a factory installed electronics package care must be used when cleaning the acrylic trim panel. Use only soapy water with a soft, non-abrasive cloth to assure the best appearance.

NOTICE

Use only warm soapy water and a soft, non-abrasive cloth to clean the acrylic electronics trim. Using any other chemicals or abrasive cloth will cause irreparable damage.

2.10 Trim Tabs

The trim tabs are recessed into the hull on the transom. Switches are used to control the trim tabs. The switches are labeled and control bow up and down movements. They also control starboard and port up and down movements. Bow up and bow down will control the hull planning attitude, while port and starboard up and down provide control for the hull trim side to side.

Before leaving the dock, make sure that the tabs are in the full "UP" position by holding the control in the bow "UP" position for ten seconds. Do not continue to operate the switch when the tabs are fully up or down.

Establish the intended heading and cruise speed before attempting to adjust the hull attitude with the trim tabs. Always make slight adjustments to reduce over adjustments. After stabilizing speed and direction, move the trim tabs to achieve a level side to side running attitude being careful not to over trim.

After depressing a trim tab switch, always wait a few seconds for the change in the trim plane to take effect.

Avoid depressing the switch while awaiting the trim plane reaction. By the time the effect is noticeable the trim tab plane will have moved too far and the boat will be in an overcompensated position.

When running at a speed that will result in the boat falling off plane, lowering the tabs slightly, bow down, will improve the running angle and operating efficiency. Too much bow down tabs can reduce operating efficiency and cause difficult steering and handling.

When running at high speeds, make sure the tabs are in the full "UP" position. Only enough trim plane action should be used to compensate for any listing. Trim tabs are more sensitive at higher speeds. Adjust for this and be prepared to slow down if difficulties arise.

Be extremely careful when operating in a following sea. The effect of trim tabs is amplified under these conditions. Difficulty in steering and handling can result from improper trim tab usage, especially in a following sea; raise the tabs to the full bow "UP" position.

When running into a chop, a slight bow down attitude will improve the ride. Be care-



ful not to over trim, difficulty in handling can result.

Trim Tab Indicator



Trim Tab Switches

The switches are labeled to indicate the reaction of the bow of the boat. The L.E.D. displays indicate the position of the trim tabs. When adjusting the starboard bow up or down, the L.E.D. indicator on the right side of the panel will activate, indicating the movement of the port tab. Refer to the trim tab operation manual.

Trim Tab Maintenance

Marine growth can affect the operation of the trim tab planes and actuators. To help reduce marine growth, return the trim tabs to the full "UP" position after operating the boat. Inspect and clean the actuators and planes regularly.

The trim tabs also include a zinc anode to help prevent galvanic corrosion. Galvanic corrosion occurs when different metals are submerged in an electrolyte. Sea water is an electrolyte and submerged metal components must be protected. Anodes were factory installed and need to be replaced when they are 75% of their original size.

Refer to Routine Maintenance for information regarding zinc anodes and the trim tab owner's manual for additional maintenance information, fluid specifications and operating instructions.

2.11 Compass

The compass is located at the helm. To adjust the compass, read the instructions on "Compass Compensation" included in the literature packet. The compass cannot be adjusted accurately at the factory as it must be compensated for the influence of the electrical equipment and electronics unique to your boat. The compass should be adjusted by a professional after the electronics and additional electrical accessories are installed and before operating the boat.

2.12 Bow Thruster



Bow Thruster Control

The bow thruster is electrically driven and controlled by a joystick on the helm. Service access for the bow thruster is achieved by removing the forward cabin hatch under the bow berth cushion. The bow thruster is powered by its own battery. This battery is located below the aft hatch under the bow berth cushion. Operate in short bursts of a few seconds to preserve battery life. Refer to the bow thruster manual for more information, maintenance and warranty information.

ROTATING PARTS HAZARD

A rotating bow thruster can cut, entangle or draw a swimmer closer or into the thruster causing death or serious injury. DO NOT use the bow thruster near swimmers.



NOTICE

DO NOT operate bow thruster out of the water, even momentarily. Water must be supplied to prevent impeller from over speeding, which will result in serious damage and void the warranty.

2.13 Spotlight (Optional)

The spotlight is controlled by a panel on the helm and a microprocessor. The microprocessor is located inside the hardtop. It is above the center acrylic access panel in the overhead. Refer to the spotlight manufacturer's owner's manual for an explanation of the features and operation.

2.14 Control Systems Maintenance

Control Maintenance

Periodic inspection of the control systems and all connections should be made. Signs of rust, corrosion, wear, or other deterioration must immediately be serviced. Periodic lubrication of all moving parts and connections with waterproof grease is required.

Control system adjustments may become necessary. If adjustments are necessary, see your Pursuit Dealer.

Steering System Maintenance

Periodically inspect all steering hoses, linkages and helm assemblies. Signs of corrosion, cracking, loosening of fastenings, excessive wear, or deterioration must be corrected immediately. Check the hydraulic steering fluid level frequently and maintain the proper level. Periodic lubrication of all moving parts and connections with light waterproof grease is required. Failure to do so can lead to steering system failure and result in loss of control. When new, or after repairs, hydraulic steering systems may need to be purged of air. Refer to the information provided with the steering system for specifications and service information.

Check steering operation and visually inspect for loose or missing hardware before operating the boat. If you suspect the steering system is damaged, see your Pursuit dealer. DO NOT operate the boat if you suspect the steering system is malfunctioning.

LOSS OF CONTROL AND UNSAFE BOAT HAZARD

Improper maintenance of steering system is hazardous and can cause death or serious injury from sudden loss of control. Make sure all steering hardware, and fluid levels are regularly inspected and maintained.

DO NOT attempt to service any part of the steering system unless you are familiar or qualified to do so. Follow all instructions regarding maintenance procedures in the steering system owner's manual.



Operator Notes

Fuel Systems

3.1 General

The fuel system of your Pursuit boat is designed to meet the requirements of the U.S. Coast Guard, Environmental Protection Agency (EPA), National Marine Manufacturers Association (NMMA), and American Boat and Yacht Council (ABYC) in effect at the time of manufacture.

All boats equipped with gasoline engines are required to have anti-siphon valves by the U.S. coast Guard.

DO NOT remove anti-siphon valves from system. Anti-siphon valves prevent fuel from flowing into the bilge should a fuel hose or fitting leak. If the valve becomes clogged, clean and reinstall or replace it.

Pursuit Boats has engineered an improved fuel tank fill and vent system that will reduce or eliminate fuel spillage when re-fuelling the boat with a standard automatic shutoff fuel fill nozzle provided by marinas and gas sta-tions. This is in accordance to EPA regula-tions.

While this system provides a clean consistent refueling experience, it still requires the operator's attention and must not be defeated by attempting to over-fill the tank with fuel. This system will automatically pro-vide the proper air space (approximately 5% of total tank volume) in the fuel tank to accommodate the expansion of fuel during daily temperature cycles.

This new EPA compliant fuel system is engineered to vent through a carbon canister when the fuel cap is installed. This will greatly reduce fuel vapors that escape to the atmosphere and reduce the fuel odor that was present on traditional systems. For that reason, the fuel cap has been changed to help the operator verify the cap is properly closed.

The fuel system was factory inspected and pressure tested in accordance with regulations in effect at the time of manufacture. It is the responsibility of the boat owner to main-tain the safe condition of the system. Inspect the system frequently to ensure no deterio-ration or loosening of connections has occurred.

\land DANGER

FIRE/EXPLOSION HAZARD

Fuel and their vapors are highly explosive when exposed to open flame or spark, resulting in death or serious injury.

- Make sure no vapors are present before turning on electrical equipment or starting engines.
- Make sure fuel is added to the fuel tank only. DO NOT confuse other deck fills with fuel fills.
- DO NOT remove anti-siphon valves from the system.
- Turn off all electrical switches before servicing the fuel system.
- DO NOT drain any fuel in the bilge.
- Check all fuel lines and fittings for leaks before and after starting the engines and after any fuel system service.
- Prime fuel system and check all fittings for leaks before and after starting the engines.
- DO NOT block fuel vents.
- DO NOT store fuel in any containers or compartments not designated for fuel storage.

NOTICE

Certain bulkhead areas are sealed following U.S. Coast Guard regulations at the date of manufacture. Any modifications must be in accordance with the regulations.



3.2 Fuel System

The fuel system on your Pursuit boat has one fuel tank and three manual "ON/OFF" fuel valves. Refer to the schematics section. The valves are off when the handle is perpendicular to the fuel flow. The fuel valves are normally left in the "ON" position except for extended storage and servicing of the system. Turn all three valves to the "OFF" position when servicing the system and changing the fuel filters.

The fuel delivery lines are equipped with anti-siphon valves where the lines attach to the fuel tank. These valves help prevent gasoline from siphoning out of the fuel tank should a line rupture.

All boats equipped with gasoline engines are required to have anti-siphon valves by the U.S. Coast Guard.

DO NOT remove anti-siphon valves from the system. Anti-siphon valves prevent fuel from flowing into the bilge should a fuel hose or fitting leak. If the fuel valve becomes clogged, clean and reinstall or replace it.

Fuel Tank

The fuel pick-up tubes are positioned in the tanks to achieve optimum fuel usage, fuel line routing, etc. At certain speeds and hull trim angles, the fuel supply at the withdrawal tube can increase or decrease accordingly. Be extremely careful when attempting to operate the boat when low on fuel. Though some fuel may be in the tank, the trim angle of the boat may cause the fuel to flow away from the pickup tubes.

Fuel Gauge Senders

The fuel gauge senders are more accurate when the boat is stationary and level. Because of the change in attitude when the boat is underway, variations in gauge readings can occur. This system is a relative indication of the available fuel supply and not a calibrated instrument.

Fuel Fills

The fuel fill is located on the port gunwale and is marked "GAS". It is located directly aft of the spring line cleat. The fuel fill is opened by turning it counterclockwise. After fueling, screw the cap on in a clockwise direction until an audible click is heard indicating that the cap is seated. If the cap is lost or damaged replace only with original equipment. During refueling the tank vents out at both the fuel fill plate and the vent located on the side of the hull. **Note:** There should not be any residual fuel at the vent but there could be residual fuel at the deck fill plate. Do not block or restrict either of these vents.

NOTICE

First time fueling may require a slower than normal flow due to the expansion of the air in the tank. Subsequent fills should allow for a normal flow rate.

Fill the fuel tank slowly and monitor the fuel gauge while filling. Once fueling is completed wash the areas around the fuel fill(s) to help reduce discoloration of the fiber-glass. Use only the fuel recommended by the outboard manufacturer; refer to the engine owner's manual for additional information.

Fuel Systems

If fuel is added to any other tank by mistake, DO NOT attempt to pump fuel out; these systems are not designed to pump fuel. Fuel must be removed by qualified personnel only. Fuel in other systems may also require replacement of that system and/or components.



EPA Fuel Fill

Fuel Vents

There is a single vent for the fuel tank on the port side of the hull. While the tank is being filled, air displaced by the fuel will escape from the vent. Do not allow fuel to be expelled from the vent and pollute our environment. Fill the fuel tank slowly and monitor the fuel gauge while filling. Spilled fuel can be dangerous.

Fuel Filters



Fuel Filters

Fuel filters are located in the mechanical space under the aft in deck hatch. The filters are the water separator type and there is one filter for each engine fuel line. Check all three filters for water frequently to ensure an adequate supply of clean, dry fuel to the engines. The filter elements should be changed once a season.

Turn off all electrical switches before servicing the fuel system and DO NOT drain any fuel into the bilge. Check all fuel lines and fittings for leaks before and after starting the engines and after any fuel system service. Prime fuel system and check all fittings for leaks before starting the engines.

3.3 Diesel Generator Fuel System

The diesel generator is equipped with a separate 24 gallon fuel tank. The diesel filter is located on the port side stringer, midship and is accessed through the mechanical space hatch. This tank is filled through a deck fill marked "DIESEL" on the aft port gunwale. The fuel level of this tank is read on the center tank of the engine display.

NOTICE

DO NOT confuse the diesel and gas fuel fills; severe engine damage will result.

The diesel system is not equipped with antisiphon valves and there is a fuel return line to return unused fuel to the fuel tank. The diesel system may require priming after servicing. Refer to the generator owner's manual for information on priming.

Make sure the fuel valve is in the "ON" position before attempting to start the generator.

A water separator type fuel filter is installed near the diesel fuel tank. The fuel filter has a sediment bowl that must be inspected frequently for water to ensure an adequate supply of clean, water-free fuel is supplied to the engine. Inspect the filter periodically and change the element as needed.



3.4 Fueling Instructions

FIRE/EXPLOSION HAZARD

Gasoline vapors are highly explosive when exposed to open flame or spark, resulting in death or serious injury.

- Stop engines before fueling.
- DO NOT smoke or allow open flames or sparks nearby, within 50 ft (15 m) of the fueling area.
- Maintain contact between fuel nozzle and fuel tank fill to prevent electrostatic spark. DO NOT use a plastic funnel.
- Fill in an open area. BURN HAZARD

Fuel floating on water which is ignited can cause death or serious injury. Fuel will float on top of water and can burn. If the boat is abandoned, swim upwind, far enough to avoid fuel that can spread over the surface of the water.

Try not to spill fuel. If fuel is spilled, wipe up all traces with dry rags and immediately dispose of the rags properly onshore. DO NOT allow fuel to stay on the finish of the boat, discoloration and damage to trim can occur. Avoid fueling at night, except under welllighted conditions. Also, monitor fuel level gauge to avoid overfilling.

To fill fuel:

- 1. Turn all switches to "OFF."
- 2. Secure boat.
- 3. Remove passengers from boat.
- 4. Extinguish all flame producing items.
- 5. Open fuel fill(s) by turning counterclockwise.
- 6. Put nozzle in the fuel fill opening.
- The fuel delivery system will shut off when the tank is filled to the proper capacity.
- 8. Remove the nozzle.
- 9. Install and tighten fuel cap until it clicks.
- 10. Check the fuel compartment and below the deck for fuel odors. If you smell fuel, DO NOT start engines until the source is isolated and repairs have been made.

Fuel System Maintenance

\land DANGER

FIRE / EXPLOSION HAZARD Fuels are extremely flammable and highly explosive under certain conditions. DO NOT smoke or allow open flames or sparks nearby when inspecting the fuel system. Frequently check fuel lines and all system components (filters, primer bulbs, clamps and connections) for leaks, damage or deterioration, or if you suspect damage, replace as necessary. Surface cracking on a hose indicates wear. Replace it.

Spray the valves, fuel tank gauge sender and ground connections with a metal protector.

Inspect the fuel fill cap o-ring seals frequently and lubricate with petroleum jelly or silicone grease. The o-ring seal prevents water from entering the fuel system through the fuel fill cap. If the o-ring is damaged, or you suspect it is damaged, replace it.

NOTICE

Use only the fuel recommended by the engine manufacturer. Use of old, contaminated fuel can cause the engine to malfunction or severe damage. Do not use fuel that contains more than 10% ethanol, harsh additives or methanol; damage to the engines and fuel system will result. Fuel system damage, related to use of alcohol-blended fuels, is not covered by the Pursuit Limited Warranty. Refer to the engine owner's manual for specific fuel requirements for your engines.

Old, degraded gasoline can affect engine performance and damage the engine and boat fuel system. Chemical changes occur as gasoline ages, reducing octane and can cause deposits and varnish in the fuel system.



If your boat is not operated enough to require at least one full tank of fresh fuel a month, a fuel stabilizer should be added to the gasoline to protect the fuel from degrading. Do not allow the boat to sit unused for an extended period with the fuel tanks less than 3/4 full. Changes in temperature and weather conditions can cause condensation in fuel tanks. Your Pursuit dealer or the engine manufacturer can provide additional information on fuel degrading and fuel stabilizers recommended for your engine.

Improper storage of fuel at marinas, limited boat usage, etc. can cause the fuel to become contaminated. Periodically, it may be necessary to pump accumulating water and contaminated fuel from the bottom of the fuel tanks. If the fuel system on your boat becomes contaminated, contact your dealer or marina for assistance.

Avoid using fuels with alcohol additives. Alcohol blend gasoline will absorb moisture from the air which can reach such concentrations that "phase separation" can occur where the water and alcohol mixture becomes heavy enough to settle out of the gasoline to the bottom of the tank. Since the fuel pickup tubes are near the bottom of the tank, phase separation can cause the engine to run very poorly or not at all. Phase separation is more severe with methyl alcohol and will increase as the alcohol content increases. Water or a jelly like substance in the fuel filters is an indication of phase separation from the use of alcohol blended fuels.

Diesel engine operation requires a good supply of clean, water-free diesel fuel. Algae can grow in the accumulated water in the diesel fuel tank. This will normally occur in warm climates. Adding a high quality diesel fuel additive containing an algaecide periodically may be required to control algae in your diesel system, depending on your boating area. Contact your Pursuit Dealer or engine manufacturer for additional information regarding fuels and additives.



Operator Notes

Electrical Systems

4.1 General

Your Pursuit boat is equipped with DC and AC electrical systems. The DC system draws current from onboard batteries. The AC system can draw current from either shore power outlets at dockside or the optional generator.

Electrical schematics are included in this manual to assist technicians in the servicing the electrical systems. Pursuit recommends you take your boat to an authorized Pursuit dealer for service or installation of additional electrical equipment. Pursuit reserves the right to modify or update the electrical system at any time without notice to the consumer or obligation to make updates to boats built prior to the change.

Some compartments on your boat may be lighted. Lights bulbs produce heat and can ignite combustible products. Turn off all lighting before you leave the boat.

FIRE OR EXPLOSION HAZARD Ignited combustible products can cause fire or explosion, resulting indeath or serious injury. DO NOT store combustibles near lights and turn off all lighting before leaving the boat.

4.2 DC System

Batteries

The 12-volt batteries have been selected to provide optimum performance for engine starting, and house and electronics loads. There are three, Group 31, lead acid batteries: one for the port engine, one for the center engine, and one for the starboard engine. These batteries require similar maintenance to automobile batteries. There are three AGM (Absorbed Glass Mat) batteries. There is a house battery, electronics battery and a bow thruster battery.

The three engine starting batteries are located in the port side slide out tray. Remove the pull pin and the tray will slide inboard for servicing. The aft battery is for starting the port engine. The center port battery is for starting the center engine. The forward port battery is for starting the starboard engine.

The house and electronics batteries are located in the starboard side slide out tray. Remove the pull pine and the tray will slide in for servicing. The forward starboard battery is for the house service. The aft starboard battery is for the electronics service.

After inspection or servicing the batteries, slide the battery tray outboard and reinstall the pull pin. The pin locks the tray in the closed position.

The bow thruster battery is located under the removable hatch below the forward berth cushion. The main circuit breaker for the bow thrusted is located in a gray box adjacent to the battery.

DC Distribution

The 12-volt OS system batteries are charged by the engine charging system or the battery chargers when connected to shore power or when operating the generator. 12-volt power is distributed to the battery switches and breakers on the Main Distribution Panel (MDP) (located on the inboard side of the port L-Lounge) that protect the switch panels on the helm and in the cabin. The battery voltage for the house and electronics batteries is monitored using the volt meters on the MDP. The engine battery voltage is monitored on the respective tachometer.



Section 4




Main Electronics Battery Disconnect

The house and electronics main breaker disconnects ALL battery power to the house and electronics batteries. This breaker is located under the starboard cockpit deck hatch. It is mounted to the side of the hull stringer directly opposite the power steering pump. If the boat is stored out of the water, turn off the house and electronics breakers to ensure there is no electrical drain from the associated battery.

Bow Thruster Main

The bow thruster main breaker protects the bow thruster and its wiring. It is located below the forward hatch under the bow berth cushion. It is directly outboard of the bow thruster battery.




Bow Thruster Main



Electrical Systems

Section 4



-RED	SCREEN	PRINT	(5A)	
-YEL	SCREEN	PRINT	(10A)	
-GRN	SCREEN	PRINT	(15A)	
-BLU	SCREEN	PRINT	(20A)	
-ORG	SCREEN	PRINT	(25A)	
-VID	SCREEN	PRINT	(30A)	
-CYN	SCREEN	PRINT	(40A)	
-GRY	SCREEN	PRINT	(50A)	
-BLA	CK TEXT	PRINT	(BREAKER	VALUE



Battery Switches

There are two battery switches to manage the 12-volt power distribution. One battery switch controls the house battery and the electronics battery. The other battery switch controls the two engine batteries. The electronics and house batteries or the port and starboard engine batteries can be paralleled by switching to "combine batteries." It is not possible to parallel the engine batteries with the house and electronics batteries.

Make sure the electronics and house and the engines battery switches are in the "ON" position whenever the engines are running to ensure ALL 12-volt accessories will operate when they are needed. Current is supplied to the CO detector, the automatic float switches for the bilge pumps, stereo memory, high water bilge alarm and the sump when the batteries are connected and the battery switches are "OFF".

DO NOT operate the boat with the engine battery switch in the combine batteries position. This could potentially lead to dead batteries and stranding.

Main Breakers

Electronics Main

This breaker is reserved for electronic accessories installation. An electronic bus is located behind the helm.

House Main

Supplies the 12-volt current to breakers for cabin equipment and the cabin switch panels.

Helm Main

Supplies the 12-volt current to helm and cockpit switch panels.

Vacuflush

The Vacuflush breaker powers the head holding tank vacuum pump and switch panel.

Head Macerator

The macerator breaker powers the head switch panel.

Cockpit Refrigerator

The refrigerator breaker powers the sliding drawer refrigerator in the cockpit. This breaker should not be left on unless the boat is plugged into shore power as it will drain the house battery.

Windlass Main

The windlass breaker is located on the MDP. To reset or turn the circuit breaker on, rotate the lever to "ON." Turn off this breaker when the windlass is not in use to reduce the possibility of accidentally activating the windlass.

CO Detector

These breakers supply current to the carbon monoxide detector. The power indicator on the carbon monoxide detector should be lit whenever someone is occupying the cabin. If the breaker has tripped, it indicates there is a problem with the carbon monoxide detector or the breaker or the wiring from the breaker panel to the detector. Determine the cause of the problem and correct it before resetting the breaker.

Carbon monoxide detectors are safety devices designed to sound an audible alarm when carbon monoxide is detected in the area of the detector. Carbon Monoxide (CO) gas is colorless, odorless and extremely dangerous. All engines and fuel-burning appliances produce CO as exhaust.



Electrical Systems

CO detectors are recommended in areas where CO build-up is a possibility, especially in boats having confined areas; such as sleeping quarters, galleys and head compartments. Check the condition of the CO detector regularly for proper operation. See the manufacturer instructions for installation requirements and operating instructions.

\land DANGER

EXTREME HAZARD

Carbon monoxide (CO) gas is colorless, odorless and extremely dangerous.

All engines and fuel-burning appliances produce CO as exhaust. Directand prolonged exposure to CO will cause brain damage or death.

4.3 12-Volt DC Panels

Helm Switch Panel

The following are descriptions of the components controlled by the helm switches:



Horn

Activates the boat horn.

Nav/Anc

Pressing the top of the rocker switch activates the navigation lights. Pressing the bottom will activate the anchor light.

NOTICE

Do not let your boats lights confuse. The USCG reports that some boaters have hazardously installed unapproved red and green LED strip lighting on the bow, which hampers other boater's efforts to avoid collision. Also avoid displaying any light that could be confused as another navigation light or another vessel. And do remember flashing blue lights are reserved for law enforcement – at a distance, wave action combined with the steady rocking of below the waterline high-intensity blue lights can give the appearance of a police vessel.

Cockpit

Activates lights to illuminate the cockpit area.

Underwater Lights (Optional)

Activates the optional underwater lights. Use these lights only when the boat is in the water as they rely on water for cooling.

NOTICE

These lights should only be used while vessel is anchored, at the dock or on a mooring.

Spreader

Activates the flood lights located on the hardtop.

Hardtop

Activates the lights located on the hardtop. Engaging this switch cycles through the different colors.



Deploy/Retrieve

Pressing the rocker switch drops (deploys) and retrieves the anchor. Refer to the Windlass in the Exterior Equipment.

Sun Shade (Optional)

Activates the retractable sun shade awning. Depressing the bottom of the switch will deploy the shade. Depressing the top of the switch will stow the shade within the hardtop. CAUTION – When retrieving the sun shade make sure all objects are clear of the area. Damage or injury could occur.

ACCY

These are open and reserved for additional accessories. DO NOT exceed 10 amps.

Forward Bilge or Aft Bilge

Depressing the switch will activate the respective manual pump. If the automatic pump activates, the automatic bilge pump indicator on the switch will light.

Fresh Water

Activates the fresh water pump. The pump is the pressure demand type and is protected by a circuit breaker on the MDP and an automatically resetting breaker on the pump motor.

Refer to the Plumbing Systems Section for more information on the fresh water system.

Washdown Pump

Pressing this switch activates the raw water washdown pump. The pump is the pressure demand type and is protected by a circuit breaker on the MDP and an automatically resetting breaker on the pump motor.

Refer to the Plumbing Systems Section for more information on the washdown system.

Livewell

Activates the livewell circulating pump to supply water to the livewell. The pump is protected by a circuit breaker on the MDP.

Refer to the Plumbing Systems Section for more information on the livewell system.

Port Fishbox

The fishbox switch activates the overboard discharge system for the port in floor fishbox. The pump is protected by a circuit breaker on the MDP. See the Plumbing section for more information on pumping out the fishbox.

Washer

Activates the windshield washer. The fresh water system must be on to operate the washer.

Port and Starboard Wiper

Activates the port and starboard windshield wiper.

Power Steering

Activates the optional power steering feature.

Cabin Switch Panels

Switches on the cabin panels operate the interior and accent lighting for the cabin.



Head Panel



The indicators on this panel display the holding tank level and also includes the holding tank overboard discharge macerator switch. The macerator switch can only be activated when the key switch is fully turned. Refer to Head Compartment of the Interior Equipment.

4.4 AC System

ELECTROCUTION, FIRE OR EXPLOSION HAZARD

Contact with live wires or working onan energized electrical system can cause electrocution. It can also cause sparks, resulting in fire and/or explosion. Both cases will result in death or serious injury. DO NOT work on an energized system or allow unqualified personnel to work on the system.

To reduce the possibility of an electrical shock, it is important that the AC ground system is functioning properly and that a proper connection exists between the shore power cord, the shore power inlet, the boat bonding system and the outlet ground circuits. If there is any doubt about the integrity of the ground circuit, a qualified marine electrician should be contacted immediately and the AC should be disconnected until the necessary repairs are completed. Replace with:

The AC electrical system operates on a 240 volt, 50 amp, 60 cycle system. Models with CE designations operate on a 230 volt, 32 amp, 50 cycle system.

The AC system is fed by the shore power or by the generator. Your boat is equipped with an isolation transformer. The isolation transformer maintains correct AC polarity regardless of the polarity of the shore power supply and eliminates the need for a galvanic isolation system and a reverse polarity indicator.

Refer to the isolation transformer manual for additional information.

The main breakers in the AC Main Distribution Panel (AC MDP) are equipped with a selector slide to prevent the shore power source and the generator source from being energized simultaneously and damaging the electrical system components. These breakers protect the system and components from an overload. All AC current is distributed to the AC components through individual 120V/ 240V (230V for CE) circuit breakers located in the AC MDP.

4.5 AC Main Distribution

The AC panel is located in the cabin. The following are descriptions of the AC panel equipment and the breakers that protect the accessories:

AC Multi-Meter

Use the arrow keys to scroll through digital readouts for amperage (A), voltage (V), cycles (hertz) (Hz) and watts (W).

- (A) Indicates the total amperage being drawn through the AC MDP. It is the total current level of all of the AC equipment in operation at the time.
- (V) Indicates the voltage supplied to the panel. Ideally the voltage should be approximately 240 volts (230 for CE) but never less than 208 volts.



- (Hz) Indicates cycles which should be 60 (50 for CE).
- (W) Indicates total watts being consumed as a result voltage x amperage.

AC Main

Protects the general distribution network. This breaker should be on when the boat is using shore power for its source. This breaker is very sensitive. The resulting power surge that occurs when connecting the dockside cord may cause the main breaker to trip. To avoid this surge, turn the main breaker to "OFF" position before plugging or unplugging the shore power cord.

Battery Charger Switches

Supplies AC to the two on-board battery chargers.

Cabin Air

Supplies AC directly to the cabin air conditioning control panel and the air conditioner (if option is installed). Otherwise it is reserved for additional AC equipment. This breaker will trip if raw water is not being supplied to the air conditioner. If this breaker trips, reset and check for water flow out of the air conditioning thru-hull. Refer to the air conditioner manual for additional information.

Cooling Pump

Supplies power to the AC cooling pump. This switch must be on prior to running the cabin or cockpit air systems or a high pressure fault will result on the AC control panels. Refer to the air conditioner manual for additional information.

Water Heater

Supplies AC directly to the water heater. The water temperature is automatically controlled by a thermostat in the water heater control panel. Before operation, the water heater tank must have water. Refer to the water heater manual for more information.

Cockpit Air (Optional)

Supplies AC directly to the cockpit air conditioning control panel and the air conditioner. Otherwise it is reserved for additional AC equipment. This breaker will trip if raw water is not being sup-plied to the air conditioner. If this breaker trips, reset and check for water flow out of the air conditioning thru-hull. Refer to the air conditioner manual for additional information.

Cockpit Grill

Supplies AC power directly to the cockpit grill. This switch should be off at all times other than while using the grill as a safety precaution. Refer to the grill manual for additional information.

Microwave

Supplies AC directly to the microwave oven. Refer to the microwave manual for more information. Electrical System Section 4.

Outlets

Supplies AC to the cabin electrical 120-volt outlets. AC electrical outlets are provided with ground fault interrupters (GFI) to help protect against electric shock. Test outlets periodically by pressing the test/reset buttons in the center of the face plate to ensure proper operation.

GFI outlets do not protect against short circuits and overloads. This protection is done by the outlet breakers on the AC panel. GFI outlets do not provide 100% protection from electric shock. Even though GFI outlets protect by reducing exposure time from line to ground shock hazards, it is still possible to receive an electric shock from defective appliances, power tools or misused electrical equipment.

4.6 Battery Charger Operation

The battery charger charges and maintains the 12-volt batteries simultaneously when activated. It is automatic and is equipped with an ammeter to monitor charging. Refer



to the battery charger manual for more information.

At dockside, when the boat is connected to shore power, the battery charger maintains the charge on the house and engine batteries. When operating on the optional generator, the on-board battery charger must be "ON" to maintain charge of the house battery. The generator charging system does not generate enough current to keep up with the electrical demand on the house battery.

The wires that supply OS charging current to the batteries are protected by an internal fuse in the battery charger and three circuit breakers, one for each battery bank output wire. The breakers protect the OS charging circuit from the batteries to the charger. They are located on the OS distribution panel. Push to reset the breakers. The internal fuses in the charger protect the OS charging circuit from the charger to the batteries.

4.7 Shore Power Connection

Connecting Shore Power

\land DANGER

ELECTROCUTION HAZARD Exposure to high voltage will causedeath or serious injury. DO NOT attempt to correct wiring yourself. DO NOT swim in marinas or near boats connected to shore power. Keep children away from any electrical cablesor equipment and use grounded appliances onboard only.

If you suspect the shore power connection system is faulty or damaged, have a qualified marine electrician check the system.

Turn the AC main breaker to "OFF" position. If the dockside outlet includes a disconnect switch, turn it to "OFF."

Your boat is equipped with a Glendinning shore cable reel. To use simply open the shore power cord cover and pull using the strap on the shore cord to manually deploy. To avoid strain on the cable make sure it has more slack than the mooring lines. Protect the cable so it cannot be damaged by chafing between the boat and the dock. Keep the cable from making contact with the water. Then connect the cable to the boat connection plug and the dockside outlet. Make sure the dockside connection plug includes a three-prong plug with a ground wire. Tighten the lock rings on both the shore and the boat connector plugs. Turn the dockside disconnect switch or circuit breaker to "ON." Turn the main AC breaker on in the cabin.

Disconnecting Shore Power

Turn the main breaker on the AC panel and the disconnect switch on the dockside outlet to "OFF".

Disconnect the cable from the dockside outlet and replace the outlet caps.

Care should be taken when retrieving the shore cord. Keep fingers and objects out of the retrieval path. Injury or damage can occur.

The Glendinning control switch is located directly in front of the transom door on the port side. It is above the switch for the cockpit lights. While guiding the shore power cord press the switch to retrieve the cord. Replace the cover over the shore cord storage.

🛆 DANGER

ELECTROCUTION HAZARD

Exposure to high voltage will causedeath or serious injury. DO NOT attempt to correct wiring yourself. DONOT swim in marinas or near boats connected to shore power. Keep children away from any electrical cablesor equipment and use grounded appliances onboard only.



4.8 Generator

Your Pursuit is equipped with a diesel generator. The generator is equipped with an automated start-up sequence to prevent over cranking which can lead to engine damage and to ensure that the generator is up to operating temperature before the electrical load is applied. The display on the generator panel provides detailed information on the operating status of the generator. Refer to the generator owner's manual for complete explanation on the operation and interpretation of the displayed data.

The generator uses a coolant reservoir tank to maintain proper operating temperatures. The coolant must be checked frequently. The tank is located behind the aft cockpit tackle locker drawer. The drawer is removable. To inspect the fluid level, open the door and remove the drawer. See generator manual for more information. Because of the number of OS systems on this boat that can be in operation, a significant drain on the batteries can occur. Depending on the RPM and the duration of operation of the engines, the engines' charging systems may not be able to keep up with the OS electrical demand particularly when the engines are run at low RPM for extended periods.

To ensure that the batteries remain at peak charge, Pursuit strongly recommends that the generator be run whenever the boat is in use and not connected to shore power. It is important to activate the house battery charger to maintain the house, electronics and bow thruster batteries whenever the generator is running. The generator is located in an enclosure in the machinery space. The generator compartment is equipped with an automatic fire extinguisher system and an automatic engine shutdown system. Refer to the Safety Equipment chapter.

NOTICE

DO NOT allow the generator to run outof fuel. Fuel injected generatorsrequire air to be removed from the fueldelivery system before initial startupor if the generator is allowed to run out of fuel. Continued attempts to start generator with air in the fuel system can lead to engine damage orerratic operation. Air must be purgedby your servicing dealer only.

Generator Panel

These switches control the starting, running, AC power selector and stopping of the generator. The procedures may vary depending on the model and type of generator installed in your boat. Refer to the generator manual for more information.

NOTICE

DO NOT start generator with GENER-ATOR switch in the on position. Allow generator to warm-up three to four minutes before transferring the electrical load. After warm-up, place GEN-ERATOR switch in the on position.

4.9 Electrical System Maintenance

12-Volt OS Electrical System Maintenance

Semi-annually spray all exposed electrical components behind the helm and in the plugs with a protector specific for electrical connections.

Make sure to check that all below deck wiring is properly supported, the insulation is sound and there are no loose or corroded terminals. Clean any corroded terminals thoroughly, or replace them. Tighten securely and spray with a metal and electrical protector. Inspect all engine wiring. Check the electrolyte level in the engine batteries regularly and add distilled water as necessary. If the batteries are frequently charged by a battery charger, check the electrolyte level more often. The correct fluid level in the cells is approximately ¹/₄ to ¹/₂ inch above the plates. If fluid is needed, fill to the proper level with distilled water ONLY. DO NOT overfill. Some batteries are sealed and cannot be filled.

Keep the tops of any battery clean and dry. Dirt and water can conduct electricity from one post to the other and can cause battery discharge or cause errant engine warnings. Keep the battery posts free of corrosion. DO NOT use wing nuts to attach battery cables. Remove the cables and clean the posts and cable clamps with a battery post cleaner or sandpaper as required. Coating the battery posts and cable clamps with petroleum jelly or silicone grease will help protect and reduce corrosion. Battery cables, both positive and ground must be replaced when they show signs of corrosion or fraying. Deteriorated cables cause a considerable voltage loss when high currents are drawn, as for starting the engine.

🛆 DANGER

FIRE OR EXPLOSION HAZARD Explosion or fire from hydrogen gases produced by lead acid batteries will cause death or serious injury. DO NOT smoke or bring a flame near battery storage area. If ignited by a spark or flame, gas may explode violently, causing spraying of battery acid or fragmentation of the battery.

AC Electrical System Maintenance

Inspect periodically all wiring insulation for nicks, chafing, brittleness, improper support, etc. Also, inspect portable appliance cords and plugs.

Examine the shore power cord for cracks in the insulation and corrosion in electrical connectors. Spraying receptacles and electrical connections with an electrical contact cleaner or a metal and electrical protector will help reduce corrosion and improve electrical continuity.

🛆 DANGER

ELECTROCUTION, FIRE OR EXPLOSION HAZARD

Contact with live wires or working onan energized electrical system will cause electrocution. It can also cause sparks, resulting in fire and/or explosion. Both cases will result in death or serious injury. DO NOT work on an energized system or allow unqualified personnel to work on the system.

General Precautions

- DO NOT work on an energized system; make sure all power sources are off.
- DO NOT allow unqualified personnel to perform electrical maintenance; only a qualified marine electrician should work on the electrical system.
- DO NOT work in a wet area.
- Use caution when connecting wires to avoid reversing polarity.
- DO NOT alter wires, connectors or use inferior parts; use OEM replacement parts only.

Corrosion on the electrical connectors can cause poor connections, shorts and ground faults, and/or poor ground connections. Check at least annually and clean as required. DO NOT allow corrosion to build on connections.

Inspect all terminals and make sure they are tight.

Have the entire AC circuitry tested every season by an experienced marine electrician, especially the shore power cord. This will detect any shorts, open wires or ground faults. Also, have the polarity indicator system inspected for proper operation.



Test all GFCI outlets periodically by pressing the test/reset buttons in the center of the face plate to ensure proper operation.

The engine maintenance required on the generator is similar to the main engines. The most important factors to the generator's longevity are proper ventilation, maintenance of the fuel, ignition, cooling and lubrication systems, and the AC alternator.

Maintenance schedules and procedures are outlined in your generator owner's manual, follow them exactly.



Plumbing System

5.1 Fresh Water System

General

The fresh water system consists of a potable water tank, distribution lines and a distribution pump. The pump is equipped with an automatic pressure switch and is accessed by lifting the mid-berth mattress and removing the access hatch cover underneath. An in-line strainer located near the pump protects the system from debris. The tank is filled through a labeled deck fill located on the starboard forward gunwale.

DO NOT confuse other deck fills with the fresh water fill. If toxic fluids or fuel is added to the fresh water tank, the system will be contaminated. DO NOT attempt to pump fuel out; this system is not designed to pump fuel. Fuel must be removed by qualified personal only. Fuel in the fresh water systems will also require replacement of that system and/or many components.

FIRE OR EXPLOSION HAZARD

Fuel and their vapors are highly explosive when exposed to open flame or spark, resulting in death or serious injury. Do not confuse deck fills.

Operation

Fill the water supply tank slowly through the FRESH WATER FILL deck plate. After filling tank, partially open all faucets. Turn on "Fresh Water" switch at the helm. Allow the pump to run until all of the air is purged from the system and a steady stream of water is flowing from each outlet. Next, turn off the faucets one by one. As the pressure builds, the pump will automatically shut off.

When properly primed and activated, the water system will operate like the water system in a home. An automatic pressure sen-

sor keeps the system pressurized. If the system has been recently filled or has not been used for an extended period, air may accumulate at the pump and the system may have to be re-primed.

Whenever the boat is left unattended, turn the fresh water system switch "OFF."

NOTICE

DO NOT allow the fresh water pump to run dry; damage to the pump can occur. The fresh water pump works on demand and WILL NOT shut off when the tank is empty. Turn the water pump switch "OFF" when the system is not in use. Operating any pump from a low-charged battery can lead to a pump failure. Keep the batteries properly charged. The fresh water system must be properly winterized prior to winter lay-up. Refer to Winterizing.

Sink and Shower Operation

To use the head sink and shower, turn on the "Fresh Water" switch on the helm switch panel. Turn the water on at the faucet and adjust the hot and cold water until the desired temperature is obtained. Some minor variations in the water temperature may occur as the pressure pump cycles.

Shower water is drained from the head compartment by a sump pump system connected to the shower drain. An automatic float switch in the shower sump controls the pump. The pump is protected by the shower sump circuit breaker. After showering, let the cold water flow for a period of time to flush the drainage system of soap residue.

The shower sump system is located in the bilge compartment. To access the sump system, open the forward facing door on the centerline of the aft berth. With the door open, flip up the hinged poly hatch. The sump box is fitted with a clear lid and it is important that it is visually inspected on a regular basis for the accumu-lation of debris.



Section 5

Should there be any accumulation on the drain strainer, the box should be cleaned out to prevent degradation in performance or potential stoppage in the system.

Water Heater

The water heater is located in the bilge compartment. To access the water heater, open the forward facing door on the centerline of the aft berth. With the door open, flip up the hinged poly hatch. All water heaters have an AC element that is thermostatically controlled at the heater and activated by a circuit breaker located in the AC panel. A high pressure relief valve protects the system from excessive pressure. Make sure all air is purged from the water heater and lines before activating the water heater breaker. Refer to the water heater manual for additional information.

NOTICE

DO NOT turn on water heater until it is filled and primed; damage to the heater will result.

Shore Water Connection

The shore water connection allows the direct connection of the water system to a shore side water supply. This provides the system with a constant supply of fresh water and minimizes the pressure pump operation. A female inlet fitting is located on the starboard side of the splash well. It is directly behind the livewell.

To use shore water, connect a hose from the shore water faucet to the shore water fitting on the boat, then turn on the shore water. The pressure pump will not run and the water in water tank of the boat will not be used. Also, the water tank will not be filled by connecting to shore water.

NOTICE

DO NOT change or modify the shore water inlet connector without contacting Pursuit Customer Relations or your dealer. Use of the wrong type or a modification can damage the fresh water system.

5.2 Raw Water Washdown

The raw water washdown system pump is supplied by hoses connected to a ball valve and a thru-hull fitting located in the bilge.

Operation

Make sure the ball valve is open before attempting to operate the raw water washdown system. The pump is activated by the "Washdown" switch located on the helm. When activated, the pressure switch will automatically control the pump. As pressure builds in the washdown hose, the pump will shut off. When the washdown hose is in use and the pressure drops, the pump will turn on. Turn the switch off when the washdown is not in use. The raw water washdown is equipped with a sea strainer on the intake side of the pump, located in the aft bilge; check it frequently and clean as necessary.

Priming the System

Open the ball valve and hose connector, and activate the pressure pump. Run the pump until all air is purged from the system. Close the thru-hull ball valve before the boat is hauled from the water to eliminate an air lock in the system. It may be necessary to re-prime the raw water system if the system is not used for an extended period.

NOTICE

DO NOT operate high-pressure pump dry, damage to pump will result. Turn the raw water pump switch "OFF" when leaving the boat unattended.



5.3 Livewell

Seawater is provided to the livewell by a 12volt circulating pump. This pump is designed to carry a constant flow of water to the livewell. The pump is activated by the "Livewell" switch on the helm. An overflow built into the livewell automatically controls livewell water level. Always turn livewell pump off at the switch panel when not in use.

To fill livewell, plug drain fitting at the bottom of the livewell. Make sure the ball valve at the intake thru-hull fitting is open and turn on livewell pump. When water level reaches the overflow, it will begin to circulate.

To drain, turn off pump and remove plug. When the livewell has drained, use the washdown hose to flush livewell and drain debris.

Close the livewell thru-hull ball valve whenever livewell is not in use to prevent water from entering the livewell while the boat is cruising. The livewell pump is equipped with a sea strainer on the intake side of the pump located in the aft bilge. Check it frequently and clean as necessary.

Do not use livewell for stowage. Seawater can enter livewell when it is not in use and damage stowed equipment.

5.4 Drainage

General

Some drain thru-hull fittings are equipped with ball valves that are always open under normal operating conditions. In the event of an emergency, close the valves to prevent sea water from entering the boat through the drainage system. Check and operate the drain valves at least once a month to make sure they are in good condition and operating properly. Also, check the drain system to ensure it is free flowing and hoses on the thru-hull fittings are secure and not leaking. Review and become familiar with the drainage schematic and location of the thru-hull drain valves.

A situation requiring one or more drain valves to be closed can be dangerous to boat and all onboard. If this occurs, distribute PFD's and take all necessary safety precautions, including notifying the Coast Guard or local agency, until the problem is determined and corrected.

Bilge Drainage

The bilge pumps are located in the stern bilge, forward area of the aft bilge and under mid berth. All bilge pumps pump water out of thru-hulls located above the waterline in the hull. A high water bilge alarm monitors excessive bilge water levels and signals a high water condition through a visual and audible alarm. See Electrical Systems for additional information on bilge pump and high water bilge alarm operations.

Inspect the bilge area frequently for evidence of excessive water. Continuous operation of the bilge pump can mean there is excess water in the bilge. Test the bilge pump at regular intervals. Debris can also prevent the pump from operating or make it operate continuously.

Bilge pumps and bilge pumping systems are not designed for damage control. Continuous operation of the bilge pump can mean a leak or a drain plug is installed incorrectly; make sure all drain plugs are installed.

Excess water in the bilge area will adversely affect the handling and maneuverability of the boat and can cause personal injury. DO NOT allow the bilge pump to operate after all the water has been cleared from the bilge area. Damage to the pump will occur.

The aft bilge pump system consists of two pumps; one automatic and the other manual. The automatic bilge pump is activated by a sensor switch (black dot) located on the pump housing. This sensor activates the pump when water reaches the pre-set height. The aft pump is the manual pump and is controlled by the switch at the helm.





Aft Automatic Bilge Pump

Current is supplied to the automatic sensor switches whenever the batteries are connected. The bilge pump switches in the helm are supplied current when the house battery switch is in the "ON" position. Breakers for the manual and the automatic functions are located on the MDP.

Activate the manual bilge pump briefly each time the boat is used to ensure pumps are operating properly. Activate the automatic switch manually to verify operation by running water in the forward bilge until the pump activates. There is a delay (5 seconds) built into the switch before the pump will activate. The pump will continue to operate for a short time after you remove your finger. Refer to the manufacturer's information under "Plumbing" for more information.

When the boat is out of the water, the bilge can be drained by two thru-hull drain fittings located in the aft mechanical space, near the bottom of the hull. It is important to check the drain plugs regularly to ensure they are tight.

A loose drain plug will allow sea water to enter the bilge and cause the boat to sink. Check the drain plug frequently to make sure it is secure.

Any oil spilled in the bilge must be thoroughly removed and properly disposed of before operating the bilge pump. The discharge of oil from the bilge is illegal and subject to fine.

NOTICE

The federal water pollution control act prohibits the discharge of oil or oily waste into or upon the navigable waters of the United States or the waters of the contiguous zone if such discharge causes a film or sheen upon, or a discoloration of the surface of the water, or causes a sludge or emulsion beneath the surface of the water. Violators are subject to a penalty of \$10,000.

Exterior Drains

Your Pursuit boat has scupper drains located in each corner of the rear cockpit. These drains are connected to ball valves in the hull side. To open and close the valves use the control rods in the mechanical space. The valves are closed when the rods are pushed all the way outboard. They are open when the rods are pulled all the way inboard.



Deck drain ball valve levers

All exterior sinks and livewells, provided with fresh or raw water, drain by gravity to overboard thru-hulls located in the hull sides just above the waterline.

The drain rails for the fish boxes and the mechanical space drain overboard by gravity.

The below floor fish box is equipped with a diaphragm pump located in the aft bilge. Access is through the aft in-deck hatch. The



fish box should be flushed out and cleaned after each use.



Fishbox Pump

The anchor locker drains overboard through a special drain fitting located in the hull side at the bottom of the rope locker. Inspect the drain frequently to remove any accumulated debris.

5.5 Plumbing System Maintenance

Information supplied with water system components, by the equipment manufacturers, is included with this manual. Refer to the information for additional operation and service information.

Fresh Water System

Turn the fresh water system switch "OFF" when leaving the boat unattended or when the fresh water system is not in use.

Perform these routine maintenance procedures to maintain your fresh water system:

 Remove filter screens from faucet spouts and eliminate any accumulation of debris. A debris build-up can cause the pump to cycle excessively.

- Check and clean the fresh water system strainer located on the intake line near the pump at least annually.
- When necessary, remove the lid on the shower sump assembly. It is located in the forward bilge compartment. To access the shower sump, open the forward facing door in the mid-berth on centerline. Flip open the hinged poly lid, clean debris from the sump and flush with clean water, activate the float switch to test the pump and spray the pumps and metal components with a metal protector periodically.

NOTICE

Maintain a proper charge on the batteries, operating the pressure pump from a battery with a low charge could lead to pump failure.

- Add a commercially available potable water conditioner to the water tank to keep it fresh.
- Make sure the fresh water system switch is "OFF" when leaving the boat unattended or when not in use.

Raw Water System

If the raw water inlet hose ruptures, turn pump off immediately. Close the thru-hull valve. If this condition is not quickly remedied severe damage and loss of life could occur.

Perform these routine maintenance procedures to maintain your raw water system:

- Check hoses for signs of deterioration, especially the sea water hoses.
- Remove and clean livewell, air conditioner and washdown pump sea water strainers, as needed. Spray pumps and thru-hull valves with a metal protector periodically.
- Drain and clean the fishboxes and livewells after each use.



 Operate all thru-hull valves at least once a month to keep them operating properly.

If a hose ruptures or leaks, turn off pump immediately. Keep the thru-hull valve closed when performing service on a sea water system.

NOTICE

Maintain a proper charge on the batteries; operating the pressure pump from a battery with a low charge could lead to pump failure.

The fresh and raw water systems must be winterized properly before storage. Refer to Winterizing.

Drainage Systems

Perform these routine maintenance procedures to maintain your drainage system:

- Clean the cockpit drain rails with a hose and water to remove all debris.
- Clean the hardtop leg drain holes, especially before winter storage.
- Clean the bilge pump and surrounding areas of any debris. Remove any debris that can block the function of the bilge pumps.
- Test rear automatic bilge pump switch and high water alarm float switch each time the boat is used, for proper operation. Activate the sensor by placing your finger on the black sensor switch on the aft end of the pump housing or add water to the bilge until the water level is high enough to activate the pump.
- Flush all gravity drains with fresh water to keep them clean and free flowing.
- When necessary, clean and inspect the shower and sink drain sump system. Remove accumulated debris and flush with fresh water. Test the automatic sump pump switch for proper operation, frequently.
- Clean and flush the fishbox and cooler/ storage boxes with a mild soap or a bilge

cleaner and fresh water after each use to keep them clean and fresh.

- Operate the thru-hull valves once a month and service as required.
- Check the drain system regularly to ensure it is free flowing and hoses on the thru-hull fittings are secure and not leaking.

NOTICE

DO NOT use harsh chemical drain cleaners in drain systems; permanent damage to the hoses, fittings and system can result. Also, drains and pumps must be properly winterized before winter lay-up.



Ventilation System

6.1 Cabin Ventilation

Ventilation is supplied by opening port lites or using the optional air conditioning system.

Port Lites

The port lites are secured by adjustable dogs. The dogs should be adjusted so they are tight enough to seal the window in the closed position, but not so tight that they are difficult to latch. The dogs are adjusted by turning a screw. The screw increases or decreases the pressure on each dog. The screen must be removed prior to closing the port light to ensure a water resistant seal.

6.2 Windshield Ventilation

The windshield vent is opened by moving the latch bar upward until the latch dogs clear the windshield frame. Make sure to fully engage the latches when in the fully opened or fully closed positions.

Operating the vent panel when the opening is obstructed may cause the glass to twist resulting in glass breakage or injury to people. Do not operate the opening vent unless it is clear of all obstructions.

6.3 Carbon Monoxide and Proper Ventilation

Read "Carbon Monoxide" in the Safety Section. It contains important information on carbon monoxide and the carbon monoxide detector.

6.4 Bilge Compartment Ventilation

Air flow into the bilge compartment is supplied by two vents located on the port side under the gunwale board.

6.5 Maintenance

- Periodically lubricate all hinges and latch assemblies with a light oil. And, clean and coat gasket materials with silicone to help keep them pliable.
- The opening cabin deck hatches and port windows are made of acrylic plastic. Acrylic can scratch easily. DO NOT use a dry cloth or glass cleaning solutions; use a soft cloth, mild soap, and water for routine cleaning. Solvents and products containing ammonia can permanently damage acrylic. Refer to Routine Maintenance for more information on the proper maintenance for acrylic.
- Carbon monoxide detectors have a limited life span. The End of Life (EOL) date, 5 years after the manufactured date, can be found on a sticker adhered to the body of the unit. Plan on replacing this unit prior to the EOL date comes. See the carbon monoxide detector manual for more information.

Operator Notes

Exterior Equipment

7.1 Deck

Unsecured open exterior doors and/or hatches can slam closed and cause injury or damage the boat. Most doors and hatches are equipped with fasteners, hatch lifters, snaps and/or straps to secure them open. Make sure they are properly secured while they are open.

Rails and Deck Hardware

Rails and deck hardware perform specific functions. Do not use for securing fenders or mooring lines; these must be secured to the cleats. Make sure mooring lines are clear of rails or stanchions, or damage can result.

DO NOT use cleats or any other hardware for the purpose of towing or being towed. Inspect all hardware periodically for loosening, wear or damage. Repair or replace immediately.

Anchor/Rope Locker

The anchor locker at the bow of the boat can be accessed through the deck hatch. The anchor locker is drained by a thru-hull fitting in the hull side near the bottom of the locker. Check it frequently and keep it clean and free flowing. Secure anchor chain when trailering or while underway.

Windlass

The windlass is located under the forward deck hatch above the rope locker. The anchor is stored on the anchor roller and is raised and lowered by the windlass. The anchor line is stored in the rope locker and routed out through the windlass to the anchor chain. The anchor locker is equipped with a receptacle for the windlass remote control.

Become familiar with the safe operation of the windless before using it. Refer to the windlass owner's manual for use of the windlass and remote control. The anchor is lowered by releasing the anchor from the cleat or chain snubber and activating the "Deploy" switch at the helm. After the anchor is set, do not allow the windlass to take the force from the anchor line; secure line to bow cleat.

NOTICE

DO NOT use windlass as the only method of securing anchor in the bow roller. Secure anchor line to a cleat or chain snubber before trailering or operating your boat.

Secure the anchor chain when trailering or while underway.

Become familiar with the safe operation of the windless before using it. Refer to the windlass owner's manual for use of the windlass and remote control.

The anchor is lowered by releasing the anchor from the cleat or chain snubber and activating the "Deploy" switch at the helm. After the anchor is set, do not allow the windlass to take the force from the anchor line; secure line to bow cleat. Secure anchor chain when trailering or while underway.



MOVING PARTS OR ENTANGLEMENT HAZARD

Contact with moving parts can entangle, cut, resulting in loss of body parts, strangulation and/or severe loss of blood, causing serious injury or death. Stay clear of moving parts.

Boats at anchor in high swell conditions will snub on the anchor line. This can cause slippage or apply excessive loads to the windlass.



Anchor Line Secured Using Cable

DO NOT use the windlass as a winch to move the boat over the anchor. Move the boat under its own power to the anchor to break the anchor loose.

MOVING PARTS OR ENTANGLEMENT HAZARD

Contact with moving parts while operating the windlass can entangle, cut which can result in loss of body parts, strangulation and/or severe loss off blood, causing serious injury or death. Stay clear of moving parts.

The anchor is retrieved by releasing the line from the bow cleat and activating the "Retrieve" switch at the helm. Once the anchor is retrieved, secure the anchor to the chain snubber or bow cleat to prevent it from being released while underway.

Windshield

The DC 365 is equipped with an opening, heavy duty, aluminum windshield. The front and side wing panels are tempered safety glass. The vent window is provided with locks that secure the window in the open and closed position. The security of the vent window should always be verified before getting underway. The glazing can be replaced, similar to replacing automotive windshields.

To prevent injury or damage to the vent window or windshield the vent window must be secured when in either the open or closed position.

Hardtop

The hardtop consists of a fiberglass top supported by the windshield in the front and powder coated aluminum legs in the back. It is designed to accommodate radio antennas, radar antennas and navigation lights. It could also be equipped with optional outriggers and/or rod holders.

NOTICE

Care should be exercised to prevent damage to powder coated surfaces. If the surface is scratched, chipped or worn exposing the aluminum, it should be resealed to prevent corrosion from forming. If corrosion is allowed to form, it could cause the powder coating to bubble and lift away. Contact your dealer for repair service.

The hardtop is not designed to support the additional weight of items like an instrument locker or a life raft. Radar and electronics antennas must be mounted to the top



between the front and rear legs. Do not mount any antennas or equipment to the brow area. The hardtop frame is not designed to support the weight of accessories in this area and can be damaged. The starboard rear leg provides the chase for components mounted to the top.

The hardtop warranty will be voided if the top is modified in any way or heavy accessories are mounted to the top. Also, if items like radar antennas, spotlights and other accessories are mounted in the wrong location, the warranty can be voided. If you intend to add equipment or make modifications to the hardtop, contact Pursuit Customer Relations to make sure the equipment you would like to add or the intended modification will not void the warranty on the top.

Sun Roof

The hardtop is equipped with a sun roof. To operate, rotate the locking handle forward and move the sun roof to the desired position. Ensure that the locking pins are fully engaged into one of the five hole positions in the side track. Do not attempt to operate the sun roof while the vessel is underway. The sun roof is not designed to be weight bearing. Do not stand, sit or store items on top of it. Do not allow persons to sit on the open sun roof at any time.

Electric Sunshade (Optional)

The optional sunshade offers an extendable awning top to the aft end of the hardtop. This shade is deployed by the Shade switch at the helm. Care should be used when opening and closing to make sure that nothing is in the way.

Opening and closing the sunshade must be done with care. If items or hands are pinched while retracting serious injury could result. Make sure nothing is in the way when retracting. The sunshade is not intended to be deployed while the boat is underway. If it is left deployed while the boat is underway damage could occur to the unit or the surrounding area.

NOTICE

Failure to stow the sunshade while underway could result in damage to the shade and the surrounding area.

Hardtop Canvas

Because the aluminum frames vary slightly, the side curtains and drop curtain are custom made to each boat at the factory. Slide the side curtains into the slide tracks on top of the windshield wings. Zip into the hardtop.

Snap the side curtains to the hardtop legs. The side curtains will have to be stretched slightly to pull out the wrinkles and reach the snaps.

Cold weather can make the clear vinyl material on the curtains stiff and difficult to stretch to the snaps. This can be particularly difficult with new canvas that has been stored off the boat. Lay the curtains in the sun for 30 minutes during the heat of the day to make installation easier in cold weather.

There is a rigging hole drilled in the starboard hardtop leg base to provide wire routing for accessories. A smaller hole is drilled in the tubing at the base of the other legs to allow water to drain. Keep the hardtop leg drains clean, especially before winter lay-up.



7.2 Cockpit

Swim Platform

Your Pursuit boat is equipped with port and starboard aft integrated boarding platforms. A foldaway boarding ladder is located in the aft corner of the port side boarding platform.

DO NOT use the boarding platforms or ladder while an engine is running. The engines must be "OFF" before allowing anyone to enter or exit the boat or when they are in the water.

Stow ladder before starting an engine.

riangle danger

CARBON MONOXIDE POISONING AND/OR ROTATING PARTS HAZARD

Poisonous CO gases are present at the rear of the boat when an engine is running. A rotating propeller can cut or entangle swimmers. Both of these hazards will cause death or serious injury. DO NOT use the swim/boarding platform when the engine is running.

Cockpit Shower

A fresh water shower is located under the port side gunnel in the cockpit. It is supplied with hot and cold water by the fresh water system and works much like the shower in the head.

Side Boarding Door

Do not use or leave the hull side boarding door open when the boat is underway. DO NOT leave the hull side boarding door unlatched. To open the door, rotate the hand latch and swing the door open until it engages with the door stop catch. When closing the door, ensure that the latch is fully engaged with the latch plate.

Transom Door

Do not use the transom door when the boat is in motion. DO NOT leave the transom door unlatched. Latch it in the full "OPEN" or full "CLOSED" position.

UNSAFE BOAT HAZARD

Failure to close and secure the side boarding door while underway can expose passengers to rotating propellers, throw them overboard or swamp the boat which can cause death or serious injury. Close and secure the side boarding door before getting underway.

NOTICE

Inspect transom door fittings periodically for wear, damage or loose fit. Repair or replace before using your boat.

Below Deck Fishbox

The fishboxes located in the cockpit are drained by a diaphragm pump located in the bilge. Pump out and clean the fishboxes after each use. Refer to Drainage Systems for more information on the fishbox drainage.

Aft Foldout Bench Seats

Keep clear of the seat mechanism when opening and closing. Injury could occur.

The aft and port side bench seats are hinged and open to provide additional seating space. To open, grasp both handles and pull outward from the stowed position. The seat will lock into its horizontal position. To stow,



lift the forward edge with the handles and return to the stowed position.

Cockpit Grill



Cockpit Grill

A 240/220V electric grill is installed in the cockpit. To use, turn on the cockpit grill breaker located on the cabin AC breaker panel. Temperature controls are located on the grill control panel behind the door below the grill. Open the door to access the grill control panel.

Turn the breaker off whenever the grill is not being used. The grill should not be used under or inside any kind of enclosure.

The grill must be allowed to cool before the cover is shut to avoid damage to the gel coated surfaces of the cover. Never clean the grill with any form of pressurized water or other types of cleaners. Use only a cloth and a stainless steel or glass surface cleaner. This grill like all appliances has the potential to create safety hazards through careless or improper use. Please observe all of the safety precautions listed in the grill manufacturer's owner's manual. Refer to the grill owner's manual.

Severe burns can occur from the improper use of the cockpit grill. Do not leave the grill unattended when is hot. Close supervision is required when the grill is being used or is hot. DO NOT use the grill while underway.

Cooler

A cooler plate is located under the seat. This unit can be controlled by the thermostat located under the seat.

Downriggers (Dealer Installed)

Downriggers must be installed on the deck area aft of the gunwale boards. DO NOT install or insert downriggers in the rod holders mounted in the gunwale boards; damage can occur.



Operator Notes

Interior Equipment

8.1 Companionway Door

The port cabin is accessed through the port cabin fiberglass door. A lockable latch secures the door in the closed position. There is also a latch mechanism on the inside of the door. This is used to open the door from the inside. A magnetic base located in the starboard side of the deck walkway is used to hold the door in the fully opened position. Rotate the door open until the two magnets engage. DO NOT leave the door opened and unlatched with the boat under way. Before operating the boat, latch the cabin door in the full "CLOSED" position.

Keep the port cabin door latched in the open or closed position. The door is heavy and can rotate closed easily. If the door is unlatched, it could rotate unexpectedly as the boat rocks, causing injury or damage.

8.2 Mid-Berth

The mid-berth is located aft of the port side cabin steps. There is a removable hatch below the berth cushion to provide access to the fresh water tank, fresh water pump, raw water washdown pump and forward bilge pump. Remove the starboard side outboard access panel to access the vacuum generator for the head system. The stereo amplifier, TV antenna control box and Fireboy® module are located in the aft port side cabinet.

8.3 Head Compartment

The head compartment is equipped with a tempered glass sink and a hot and cold faucet. An independent hot and cold shower mixer and wand are located within the shower enclosure. For care and cleaning information on the sink, refer to Routine Maintenance Section. An opening port light

above the sink provides daylight and ventilation. An AC G.F.I. duplex outlet is also provided inside the vanity.

Marine Head System

Your boat is equipped with a VacuFlush® marine head system as standard equipment. This system uses a small amount of water and vacuum, which is generated by the 12-volt vacuum pump to flush. The toilet is connected to the pressurized fresh water system. Fresh water is used to reduce odor in the head compartment.

To use the toilet, make sure the "VacuFlush" breaker on the MDP is on; lift the foot flush lever slightly to wet the bowl with the desired water level. Depress the flush lever all the way for approximately three seconds or until the bowl is clear. A sharp popping noise is normal when the vacuum seal is broken and flushing action begins. It is also normal for a small amount of water to remain in the bowl after flushing.

The waste is directed to the holding tank until it is pumped out by a waste dumping station or the overboard macerator discharge system. The waste moves through a one-inch opening in the toilet base. Incoming air fragments mix with the waste as it passes through the base opening. This process eliminates the need for macerators or mechanical motors in the toilet base. When the tank is full, the tank monitor will show full and the vacuum pump will not run.

NOTICE

DO NOT operate the macerator dry; damage to the pump can occur.

The vacuum generator is mounted on the holding tank and contains stored vacuum. System vacuum is monitored by a vacuum switch, which is located on the vacuum generator tank. When the switch senses a drop in vacuum in the system, it automatically signals the pump to energize and bring the vacuum back to operating level. This process is



normally completed in less than two minutes.

It is normal for the stored vacuum to leak down slightly between flushes, causing the vacuum pump to run for a short period. The pump should not run more than once every three hours after the last flush for recharging the system. A holding tank fluid level monitor and macerator pump-out switch are located in a panel near the toilet. Refer to the head manufacturer owner's manual for more information on the operation of the marine head system.

Holding Tank

Monitor tank level and have it pumped out before it is completely full. If the tank is allowed to overfill, the waste will overflow out the tank vent and overboard.

Emptying the Holding Tank

When the tank is full, pump it out using an approved waste dumping station through the waste deck fitting or use the macerator discharge pump, when it is legal to do so.

NOTICE

In some waters it is illegal to discharge waste overboard. Remove the seacock handle or use another method to prevent accidental discharge.

To operate the macerator pump, open the ball valve at the thru-hull fitting. The thru-hull fitting and valve are accessed through the cockpit machinery space hatch. The valve is labeled MACERATOR DISCHARGE. Activate the macerator switch until the tank is empty. Release the switch and close the discharge ball valve when pumping is complete.

Maintenance

Clean and inspect the head for leaks regularly. Periodically add chemical to the head

to help control odor and to chemically break down the waste. Refer to the head owner's manual for additional operating and maintenance information.

NOTICE

The head and macerator systems must be winterized before winter lay-up; refer to Winterizing.

8.4 Galley

Microwave Oven

A microwave oven is standard equipment. The microwave operates on AC power and is protected by a breaker on the AC panel. Refer to the microwave owner's manual for additional operating and maintenance information.

8.5 Carbon Monoxide Detector


The Safety Section in this manual contains important information on carbon monoxide and the carbon monoxide detector. Read section titled Carbon Monoxide.

8.6 Air Conditioner

Your boat is equipped with a cabin air conditioning unit. It is mounted inside the cabinet assembly inboard of the port cabin companionway stairs. It can be accessed through the forward facing centerline door in the midberth. If the optional cockpit air unit is installed it will be located under the helm seat.

These reverse cycle air conditioners can be operated to cool or heat. They are controlled by a thermostat and protected by a breaker in the AC breaker panel. To operate, turn the cabin or cockpit air conditioner switches to the "ON" position.





Cabin & Cockpit Air Controls

Set desired temperature and fan speeds using the control panels located in the cabin AC distribution panel. Refer to the owner's manual for more information and setting options.

The cold air return is located on the forward facing centerline access door to the cabin air conditioning unit in the mid-berth. There is also an adjustable cold air return in the forward berth. The port cabin has a non-adjustable return just aft of the microwave. The head has a non-adjustable cold air return adjacent to the cabin steps. Do not obstruct the return to obtain maximum efficiency from the air conditioner. Be careful when storing items in this compartment. Items stored next to the return can obstruct air flow and possibly damage the unit.

The air conditioner is self-contained and sea water cooled. The cooling pump supplies sea water to the unit and cools the condensing unit and is discharged overboard. The pump is located in the mechanical space. Sea water is supplied to the pump from a thru-hull fitting located in the hull near the pump. A sea strainer between the pump and thru-hull fitting protects the system from contaminants that can damage the pump or the air conditioning system. Periodically clean the sea strainer basket to make sure the sea water pump receives adequate water.

Air locks can occur in the cooling pump water supply at the time of launching. If your boat has been recently launched and water is not flowing from the overboard thru-hull when the air conditioner is activated, air may have to be purged from the system. This can be achieved by making sure the valve at the cooling pump intake thru-hull is open. Then run the boat at cruise speed for several minutes. This will pressurize the system and force the air through the pump. Refer to the air conditioner owner's manual for additional operating and maintenance information.

NOTICE

Air conditioners use surface water to cool. DO NOT operate the air conditioner out of the water or without the raw water supply or damage to the system will occur. Make sure there is a water supply before operating the air condition. No water supply can also trip the circuit breaker.

8.7 Audio and Video Systems

Stereo

The main stereo control unit is located at the console helm. The stereo can use an iPod® connection, an MP3 USB input, or a streaming Bluetooth® signal. A secondary remote is also located in the bow seating area for convenience. The remote can control several functions of the stereo, but not all. An optional satellite radio system, made up of a receiver and an antenna can be installed by a qualified electronics installer. Refer to the stereo owner's manual for additional operating information.

Stereo Amplifier

The stereo amplifier is located inside the port side aft cabin cabinet. To access, open the blank turn latch and open. The amplifier has controls to adjust the sound system response. Refer to the amplifier owner's manual for additional operating information.

TV

A flat screen TV is installed in the cabin. Refer to the TV owner's manual for additional operating information.



TV Antenna

A TV antenna is installed on the hardtop. The antenna has an amplifier box located in the aft port locker in the cabin. A red light on the antenna box indicates the antenna is activated.



Safety Equipment

9.1 General

Your boat and outboard engines have been equipped with safety equipment designed to enhance the safe operation of the boat and to meet U.S. Coast Guard safety standards. The Coast Guard or state, county, and municipal law enforcement agencies require certain additional accessory safety equipment on each boat. This equipment varies according to length and type of boat and type of propulsion. Most of the accessory equipment required by the Coast Guard is described in this Section. Some local laws require additional equipment. It is important to obtain "Federal Requirements And Safety Tips for Recreational Boats" published by the Coast Guard, and copies of state and local laws, to make sure you have the required equipment for your boating area. You should also read the book entitled "Sportfish, Cruisers, Yachts - Owner's Manual" included with this manual.

Your Pursuit boat could be equipped with engine alarms and cabin monitoring equipment. These systems are designed to increase your boating safety by alerting you to potentially serious problems in the primary power systems, the engine compartment and the cabin. Alarm systems are not intended to lessen or replace good maintenance and "Pre-Cruise System Check."

This Section also describes safety related equipment that could be installed on your boat. This equipment will vary depending on the type of engines and other options installed by you or your dealer.

9.2 Engine Alarms

Most outboards are equipped with an audible alarm system mounted in the helm area that monitors selected critical engine systems. The alarm will sound if one of these systems begins to fail. Refer to the engine owner's manual for information on the alarms installed with your engines and additional operating and maintenance information.

If the alarms sounds:

- throttle the engines back to idle immediately.
- shift to neutral.
- monitor the engine gauges to determine the cause of the problem.
- if necessary, shut off the engines and investigate until the cause of the problem is found.
- if the boat is equipped with water sensors in the fuel filters, make sure to check them for excessive water.

9.3 Neutral Safety Switch

Every throttle/shift control system has a neutral safety switch. The switch allows the engines to be started in NEUTRAL only. If engines will not start, make sure controls are in NEUTRAL. Control adjustments may be required to correct this condition should it persist. See your Pursuit Dealer for necessary control adjustments. Refer to the Plumbing Systems for more information on the neutral safety switch.

9.4 Engine Stop Switch

Your Pursuit boat is equipped with an engine stop switch, clip and lanyard. When the lanyard is pulled, it will shut off the engines.

LOSS OF CONTROL AND UNSAFE BOAT HAZARD

An engine stop switch system that is not used or does not function correctly can cause death or serious injury. DO NOT operate the boat if the stop switch system does not function properly.

The stop switch will stop an engine whenever the lanyard is pulled far enough to disconnect the clip from the switch. Attach the lanyard to the boat operator whenever an engine is running, but be aware of loss of engine power if the switch is activated. If the operator is thrown from the seat, or moves



too far from the helm, the lanyard will disconnect the clip from the switch, shutting off the engine.

To attach a lanyard, connect the clip to the emergency stop switch and the hook to a strong piece of clothing on the operator, such as a belt loop.

If the engines will not start, the clip may not be inserted into the engine stop switch properly or the control is not in neutral. Make sure the clip is properly attached to the engine stop switch before attempting to start the engine.

Always carry a spare stop switch clip and lanyard and instruct at least one other person onboard the operation of the stop switch and location of the spare.

9.5 Automatic Fire Extinguishing System

FIRE/EXPLOSION HAZARD The gas of the fire extinguisher system displaces oxygen to "smother" the fire. DO NOT open the hatch. Oxygen can feed a fire and flashback can occur which can cause death or serious injury. If the onboard fire system discharges, wait at least 15 minutes before opening engine hatch.

The generator is equipped with an automatic fire extinguishing system. The extinguisher has been chosen and located to provide sufficient coverage of the generator compartment. While the system helps ensure bilge fire protection, it does not eliminate the U.S. Coast Guard requirement for hand held fire extinguishers.

The system is equipped with an engine shutdown circuit to automatically shut down the generator. The red light on the fire extinguisher control panel will light and an alarm will sound if this should occur. When sufficient time has elapsed for the fire to be extinguished and a flashback is no longer possible, find and fix the problem, then the override switch on the control panel can be moved to the "OVERRIDE" position and the engines can be restarted. Refer to the Automatic Fire Extinguisher System in the Plumbing Systems.

If the extinguisher system is activated, shut down all engines immediately. Turn off all electrical systems, powered ventilation and extinguish all smoking materials. DO NOT open the engine compartment hatch, this will feed oxygen to the fire and a flashback can occur. Allow the extinguishing agent to soak the generator compartment for at least 15 minutes and wait for hot metals or fuels to cool before inspecting for cause or damage. Have an approved portable fire extinguisher at hand and ready for use and DO NOT breathe fumes or vapors caused by the fire.

It is extremely important that you read, understand and know how this system works, refer to the manufacturer's literature.

9.6 Carbon Monoxide Hazards

🗥 DANGER

CARBON MONOXIDE HAZARD Exposure to CO will cause death or serious injury. CO is colorless, odorless and extremely dangerous. Avoid CO exposure and make sure the CO detector is working properly.

Carbon monoxide (CO) poisoning is lethal and should not be confused with seasickness, intoxication or heat exhaustion. If someone complains of irritated eyes, headache, nausea, weakness or dizziness, or you suspect carbon monoxide poisoning, immediately move the person to fresh air, investigate the cause, and take corrective action. Seek medical attention if necessary.

All engines and fuel burning appliances produce CO as exhaust. Direct and prolonged exposure to CO will cause BRAIN DAMAGE or DEATH.



Other symptoms that may signal exposure to CO: dizziness, flushed face, ears ringing, headaches, tightness of chest or hyperventilation, drowsiness, fatigue or weakness, inattention or confusion. lack of normal coordination, nausea and unconsciousness. The victim's skin also may turn red. A slight buildup of CO in the human body over several hours causes headache, nausea and other symptoms similar to food poisoning, motion sickness or the flu. Anyone with these symptoms should immediately be moved to an area of fresh air. Have the victim breath deeply and seek immediate medical attention. To learn more about CO poisoning, contact your local health authorities.

Carbon Monoxide Detector

If the carbon monoxide detector is activated, this indicates the presence of CO, which can be fatal. Evacuate the cabin immediately. Make sure all passengers are accounted for. DO NOT enter the cabin until you know it is safe and the problem found and corrected.

CO detectors warn occupants of dangerous accumulation of CO gas. It is automatically activated whenever the house battery switch panel feed breaker is "ON." When powered, the green indicator will flash for ten to fifteen minutes, indicating the unit is in its warm-up stage. The green power indicator will stop flashing when the sensor has reached optimum operating temperature. The indicator will then switch from flashing green to solid green, indicating the detector is activate.

Make sure the battery switch is on and the power light is lit whenever the cabin is occupied.

This device uses a micro controller to continuously measure and accumulate CO levels. Should a very high level of CO exist, the alarm will sound within a few minutes. If small quantities are present or high levels are short-lived, the detector will accumulate the information and determine when an alarm level has been reached.

While a CO detector enhances your protection from CO poisoning, it does not guarantee it will not occur. Do not use CO detectors as a replacement for ordinary precautions or periodic inspections of equipment. Never rely on alarm systems to save lives; common sense is still the best form of protection. Remember, the boat operator carries the ultimate responsibility to make sure the boat is properly ventilated and passengers are not exposed to dangerous levels of CO. Be alert to the symptoms and early warning signs of carbon monoxide.

CO detectors are very reliable and rarely sound false alarms. If the alarm sounds, DO NOT think it is false. If anyone has been exposed to CO, move them into fresh air immediately. Never disable the CO detector because you think the alarm may be false.

Carbon Monoxide Poisoning

Carbon monoxide (CO) is a by-product of combustion, is invisible, tasteless, odorless and is produced by all engines and most heating and cooking appliances. It exists wherever fuels are burned to generate power or heat. The most common sources of CO on boats are combustion engines, auxiliary generators and propane or butane stoves.

These produce large amounts of CO and should never be operated while sleeping. High concentrations of CO can be fatal within minutes. Many cases of CO poisoning indicate that while victims are aware they are not well, they become so disoriented they are unable to save themselves by either exiting the area or calling for help. Also, voung children, elderly persons and pets may be the first affected. Drug or alcohol use increases the effect of CO exposure. Individuals with cardiac or respiratory conditions are very susceptible to the dangers of CO. CO poisoning is especially dangerous during sleep while victims are unaware of any side effects.

Low levels of CO over an extended period of time can be just as lethal as high doses over a short period. Therefore, low levels of CO can cause the alarm to sound before persons notice any symptoms.



Contact the detector manufacturer, the Pursuit Customer Relations Department or your local fire department for assistance in finding and correcting the situation.

In certain situations, boats can have a problem due to the "station wagon effect" where engine exhaust fumes are captured in the vessel by the vacuum or low pressure area, usually the cockpit, bridge deck and cabin, that can be created by the forward speed of the boat. Boats that are underway should close all aft facing portholes, hatches and doors. The forward facing deck hatches should be open whenever possible to help pressurize living spaces of the boat. Sleeping, particularly in aft cabins, should not be permitted while underway. Proper ventilation must be maintained on the bridge deck by opening a forward window or windshield to drive fumes away from the occupants. The canvas drop or aft curtain must be removed and side curtains should be opened or removed to increase airflow and maintain proper ventilation whenever the engines are running.

DO NOT operate the engines with side curtains closed and the aft or drop curtain installed.

Use extreme caution while anchored or in a slip and an auxiliary power generator is operating. Calm wind nights can easily allow fumes to enter the boat. Inspect the exhaust systems of propulsion and the auxiliary generators, if equipped, frequently for possible leaks. High concentrations of CO in your boat can originate from an adjacent boat through open hatches or windows.

Failure to properly ventilate the boat while the engines are running can cause CO to accumulate within the cabin. Make sure to ventilate the boat and to avoid CO from accumulating in the boat whenever an engine is running.

Read the book entitled, "Sportfish, Cruisers, Yachts - Owner's Manual" and the owner's manual supplied by the CO detector manufacturer for additional information regarding the hazards and symptoms of CO gas, CO poisoning and operation instructions. If you did not receive these manuals, contact the Pursuit Customer Relations Department.

Read the book entitled, "Sportfish, Cruisers, Yachts - Owner's Manual" and the owner's manual supplied by the CO detector manufacturer for additional information regarding the hazards and symptoms of CO gas, CO poisoning and operation instructions. If you did not receive these manuals, contact the Pursuit Customer Relations Department.

Carbon monoxide detectors have a limited life span. The End of Life (EOL) date, 5 years after the manufactured date, can be found on a sticker adhered to the body of the unit. Plan on replacing this unit prior to the EOL date comes. See the carbon monoxide detector manual for more information.

9.7 First Aid

It is the boat operator's responsibility to be familiar with proper first-aid procedures and be able to care for minor injuries or illnesses of your passengers. In an emergency, you could be far from professional medical assistance, so be prepared. We recommend you be prepared by receiving training in basic first aid and CPR, through classes given by the Red Cross or your local hospital.



Equip your boat with at least a simple marine first-aid kit and a first-aid manual. The marine first-aid kit should be designed for the marine environment and be well supplied. Keep it accessible so each person onboard knows where it is located. As sup-



plies are used, replace them. Some common drugs and antiseptics can lose their strength or become unstable as they age. Ask a medical professional about the supplies you should carry and the safe shelf life of prescription drugs or other medical supplies you carry. Replace old supplies whether they have been used or not.

In many emergency situations, the Coast Guard can provide assistance in obtaining medical advice for treatment of serious injuries or illness. If you are within VHF range of a Coast Guard Station, make the initial contact on channel 16 and follow their instructions.

9.8 Required Safety Equipment

In addition to items installed by Pursuit, certain other equipment is required by the U.S. Coast Guard to help ensure passenger safety. Items like a sea anchor, working anchor, extra dock lines, flare pistol, life vests, a line permanently secured to your ring buoy, etc., could at some time save your passengers' lives, or save your boat from damage. Refer to the "Federal Requirements and Safety Tips for Recreational Boats" pamphlet for a more detailed description of the required equipment. You can also contact the U.S. Coast Guard Boating Safety Hotline, 800-368-5647, for information on boat safety courses and brochures listing the Federal equipment requirements. Also, check your local and state regulations.

The Coast Guard Auxiliary offers a "Courtesy Examination." This inspection will help ensure your boat is equipped with all of the necessary safety equipment.

The following is a list of the accessory equipment required on your boat by the U.S. Coast Guard:

Personal Flotation Devices (PFD's)

PFD's must be Coast Guard approved, in good and serviceable condition, and of appropriate size for the intended user. Wearable PFD's must be readily accessible, meaning you must be able to put them on in a reasonable amount of time in an emergency. Though not required, the Coast Guard emphasizes that PFD's should be worn at all times when the vessel is underway. Throwable devices must be immediately available for use. All Pursuit boats must be equipped with at least one Type I, II or III PFD for each person onboard, plus one throwable device (Type IV).

Visual Distress Signals

All Pursuit boats used on coastal waters, the Great Lakes, territorial seas, and those waters connected directly to them, must be equipped with Coast Guard approved visual distress signals. These signals are either Pyrotechnic or Non-Pyrotechnic devices.

Pyrotechnic Visual Distress Signals

Pyrotechnic visual distress signals must be Coast Guard approved, in serviceable condition and readily accessible. They are marked with a date showing the service life, which must not have expired. A minimum of three are required. Some pyrotechnic signals meet both day and night use requirements. They should be stored in a cool, dry location. They include:

- pyrotechnic red flares, hand held or aerial.
- pyrotechnic orange smoke, hand-held or floating.
- launchers for aerial red meteors or parachute flares.

Pyrotechnics are universally recognized as excellent distress signals. However, there is potential for injury and property damage if not handled properly. These devices produce a very hot flame and the residue can cause burns and ignite flammable material. Pistol launched and hand-held parachute flares and meteors have many characteristics of a firearm and must be handled with caution. In some states they are considered a firearm and prohibited from use. Make sure you are careful and follow the manufacturer's instructions when using pyrotechnic distress signals.



FIRE/EXPLOSION HAZARD

Pyrotechnic signaling devices can cause fire and/or explosion, death, serious injury and property damage if misused. Follow the manufacturer's directions in the use of these signaling devices.

Non-Pyrotechnic Devices

Non-Pyrotechnic visual distress signals must be in serviceable condition, readily accessible, and certified by the manufacturer as complying with U.S. Coast Guard requirements. They include:

Orange Distress Flag, day use only.

The distress flag is a day signal only. It must be at least 3×3 feet with a black square and ball on an orange background. It is most distinctive when attached and waved from a paddle or boat hook.

Electric Distress Light, night use only.

The electric distress light is accepted for night use only and must automatically flash the international SOS distress signal. Under Inland Navigation Rules, a high intensity white light flashing at regular intervals from 50-70 times per minute is considered a distress signal.

Sound Signaling Devices

The navigation rules require sound signals to be made under certain circumstances. Recreational vessels are also required to sound fog signals during periods of reduced visibility. Therefore, you must have some means of making an efficient sound signal.

Navigation Lights

Recreational boats are required to display navigation lights between sunset and sunrise and other periods of reduced visibility (fog, rain, haze, etc.) Navigation lights are intended to keep other vessels informed of your presence and course. Your Pursuit boat is equipped with the navigation lights required by the U.S. Coast Guard at the time of manufacture. It is up to you to make sure they are visible, operational and turned on when required.

The navigation lights on your Pursuit comply with the Coast Guard 72 COLREGS standard that is in place.

Periodically test and verify that the bow fixture containing the red (port) and green (starboard) and masthead white all-around light and mast white stern light illuminate when the navigation lights are turned ON. Replace any burned out bulbs or light fixtures that are not working.

Modifying the navigation light system with the addition of additional lights, or removing lights, could cause the system to be incompliant with the Coast Guard 72 COLREGS standard. Additional lights could diminish the visibility of the installed navigation lights or be confused with navigation lights.

Modifying or replacing the navigation light fixtures with something that is not an exact replacement could cause the system to be incompliant with the Coast Guard 72 COLREGS standard. The fixtures used on your Pursuit meet the 72 COLREGS standard for the length of your boat and visibility required. Consult your Pursuit dealer when considering an addition to, removal of, or change to a navigation light fixture.

The operator is responsible for making sure the navigation lights are in good working order and are not obstructed. Navigation lights should not be modified, and additional lights should not be added if they could diminish the visibility of navigation lights or be confused with navigation lights.

The installed navigation lights may have a date indicating when the lighting quality may diminish. Replace the navigation lights before the indicated expiration date to maintain compliance and safety.



Fire Extinguishers

Pursuit Boats provides locations for two fire extinguishers on boats under 26 feet. Boats over 26 feet have provisions for up to three fire extinguishers. Boats equipped with cabins have one fire extinguisher located in the cabin, cockpit and helm areas. Center console boats have fire extinguishers mounted in the vicinity of the helm and passenger cockpit. Coast Guard approved fire extinguishers are hand-portable, either B-I or B-II classification and have a specific marine type mounting bracket. It is recommended the extinguishers be mounted in a readily accessible position.

Fire extinguishers require regular inspections to ensure:

- seals and tamper indicators are not broken or missing.
- pressure gauges or indicators read in the operable range.
- no obvious physical damage, corrosion, leakage or clogged nozzles.

For information on the type and size fire extinguisher required for your boat, refer to the "Federal Requirements and Safety Tips for Recreational Boats" pamphlet or contact the U.S. Coast Guard Boating Safety Hotline, 1-800-368-5647.

For instructions on the proper maintenance and use of your fire extinguisher, refer to the information provided by the fire extinguisher manufacturer.

Information for halon or agent FE-241 extinguishers is provided by the manufacturer. It is extremely important that you read, understand and know how this system works; refer to the manufacturer's literature.

Bilge and Fuel Fires

Fuel compartment and bilge fires or explosions are dangerous because of the presence of fuel. You must make the decision to fight the fire or abandon the boat. If the fire cannot be extinguished quickly or it is too intense to fight, abandoning the boat may be your only option. You must consider your safety, the safety of your passengers, the intensity of the fire and the possibility of an explosion in your decision.

If you find yourself in this situation, make sure all passengers have a life preserver on and go over the side and swim well upwind of the boat, to keep clear of any burning fuel that could be released and spread on the water as the boat burns or in the event of an explosion. When clear of the danger, check and account for all passengers who were onboard. Give whatever assistance you can to anyone in need or in the water without a buoyant device. Keep everyone together for morale and to aid rescue operations.

BURN HAZARD

Fuel floating on water which is ignited can cause death or serious injury. Fuel will float on top of water and can burn. If the boat is abandoned, swim upwind, far enough to avoid fuel that can spread over the surface of the water.

9.9 Additional Safety Equipment

Besides meeting the legal requirements, prudent boaters carry additional safety equipment. This is particularly important if you operate your boat offshore. You should consider the following items, depending on how you use your boat.



Satellite EPIRB 'S

EPIRB's (Emergency Position Indicating Radio Beacon) operate as part of a world wide distress system. When activated, EPIRB's will send distress code homing beacons that allow Coast Guard aircraft to identify and find them quickly. The satellites that receive and relay EPIRB signals are operated by the National Oceanic and Atmospheric Administration (NOAA) in the United States. The EPIRB should be mounted and registered according to the instructions provided with the beacon, so the beacon's unique distress code can be used to quickly identify the boat and owner.

Additional Equipment to Consider:

- VHF Radio
- Life Raft
- □ Spare Anchor
- □ Spare Keys
- Heaving Line
- □ Fenders
- □ First Aid Kit
- Portable Radio
- □ Flashlight and Batteries
- □ Mirror
- □ Searchlight
- □ Sunburn Lotion
- Tool Kit
- □ Ring Buoy
- □ Whistle or Horn
- □ Anchor
- □ Chart and Compass
- Boat Hook
- □ Spare Propellers
- Mooring Lines
- Food and Water
- Binoculars
- Sunglasses
- Marine Hardware
- □ Extra Clothing
- Spare Parts



Operation

10.1 General

Before you start, become familiar with the various component systems and their operation, and perform a "Pre-Cruise System Check." A thorough understanding of the component systems and their operation is essential to operate the boat safely. This manual and the associated manufacturers' information have been provided to enhance your knowledge of your boat. Read them carefully, and also, read the book titled "Sportfish, Cruisers, Yachts - Owner's Manual."

Your boat must have the necessary safety equipment onboard and be in compliance with the U.S. Coast Guard, local and state safety regulations. There should be one Personal Floatation Device (PFD) for each person. Non-swimmers and small children should wear PFD's at all times. You should know and understand the "Rules of the Road" and have had an experienced operator brief you on the general operation of your new boat. At least one other person should be instructed on the proper operation of the boat in case the operator is suddenly incapacitated.

The operator is responsible for his safety and the safety of his passengers. When boarding or loading the boat, always step onto the boat, never jump.

DROWNING OR LOSS OF CONTROL HAZARD

Ejection or sudden loss of control can cause death or serious injury from improper use of seating. DO NOT stand while driving above engine idle speeds and make sure cockpit seat is locked/secured and all passengers are seated when boat is underway. DO NOT allow passengers to sit on the seat backs, gunwales, bows, transoms or on fishing seats whenever the boat is underway. Passengers should be seated to properly balance the load and must not obstruct the operator's view, particularly to the front.

Overloading and improper distribution of weight can cause the boat to become unstable and are significant causes of accidents. Know the weight capacity and horsepower rating of your boat. Do not overload or overpower your boat.

OVERLOAD HAZARD Overloading the boat beyond maximum load or altering the stability, buoyancy or center-of-gravity can result in death or serious injury. DO NOT exceed the maximum load or alter the center-of-gravity of the boat.

Remember, it is the operator's responsibility to use good common sense and sound judgment in loading and operating the boat.

SLIPPERY SURFACE HAZARD Wet surfaces can generate slippery conditions which can result in death or serious injury. Use caution on wet surfaces.

10.2 Homeland Security Restrictions

- Recreational boaters have a role in keeping our waterways safe and secure. Violators of the restrictions below can expect a quick and severe response.
- Do not approach within 100 yards, and slow to minimum speed within 500 yards of any U.S. Naval vessel. If you need to pass within 100 yards of a U.S. Naval vessel, for safe passage you must contact the U.S. Naval vessel or the Coast



Guard escort vessel on VHF-FM channel 16.

- Observe and avoid all security zones. Avoid commercial port areas, especially those that involve military, cruise-line or petroleum facilities. Observe and avoid other restricted areas near dams, power plants, etc.
- Do not stop or anchor beneath bridges or in channels.


America's Waterway Watch

America's Waterway Watch, a combined effort of the Coast Guard and its Reserve and Auxiliary, wants your help in keeping America's waterways safe and secure. America's Waterway Watch urges you to adopt a heightened sense of sensitivity toward unusual events or individuals you may encounter in or around ports, docks, marinas, riversides, beaches or waterfront communities. To report suspicious activities, call the National Response Center at 1-877-24WATCH or 1-800-424-8802. If there is immediate danger to life or property call 911 or call the Coast Guard on Marine channel 16.

10.3 Rules of the Road

As in driving an automobile, there are a few rules you must know for safe boating operation. The following information describes the basic navigation rules and action to be taken by vessels in a crossing, meeting or overtaking situation while operating in inland waters. These are basic examples and not intended to teach all the rules of navigation. For further information consult the "Navigation Rules" or contact the Coast Guard, Coast Guard Auxiliary, Department of Natural Resources, or your local boat club. These organizations sponsor courses in boat handling, including rules of the road. We strongly recommend such courses. Books on this subject are also available from your local library.

When two motor boats are crossing, the boat on the right has the right of way and should maintain its course and speed. The other vessel should slow down and permit it to pass. Both boats should sound appropriate signals.




Avoid collisions by following navigation rules. If a collision appears unavoidable, both vessels must act. Prudence takes precedence over right-of-way rules if a crash is imminent. Less maneuverable boats generally have the right of way. Steer clear of the right-of-way boat and pass to its stern.


When two motor boats are crossing, the boat on the right has the right of way and should maintain its course and speed. The other vessel should slow down and permit it to pass. Both boats should sound appropriate signals.



Operation

Crossing situations





The General Prudential Rule

Meeting Head-On Or Nearly-So Situations

When two motorboats are approaching each other head-on or nearly head-on, neither boat has the right of way. Both boats should reduce their speed and turn to the right, passing port side to port side and provide enough clearance for safe passage. Both boats should sound appropriate signals.


Overtaking Situations

When one motorboat is overtaking another motorboat, the boat being passed has the right of way. The overtaking boat must make adjustments necessary to provide clearance for a safe passage of the other vessel and should sound appropriate signals. In obeying the Rules of the Road, due regard must be given to all dangers of navigation and collision and to any special circumstances, including the limitations of the vessels, which may justify a departure from the rules that is necessary to avoid immediate danger or a collision.

Navigation Aids

Aids to navigation are placed along coasts and navigable waters as guides to mark safe water and to assist mariners in determining their position in relation to land and hidden dangers. Each aid to navigation is used to provide specific information. Become familiar with these and any other markers used in your boating area.





▲ CAUTION

Storms and waves can move buoys, do not rely on buoys alone to determine your position.

10.4 Pre-Cruise Check

Before Starting The Engines:

- Check the weather forecast. Decide if your planned cruise can be made safely.
- Make sure all required documents are onboard.
- Make sure all necessary safety equipment is onboard and operative; items like running lights, spotlight, life saving devices, etc. Refer to Safety Equipment for additional information.

Each person onboard must have at least one personal flotation device onboard and one throwable device. Check the U.S. Coast Guard standards for the correct type required for your boat.

• Make sure signal kits are onboard and are in good operating condition and are not expired.

- Make sure you have sufficient water and other provisions for the planned cruise.
- Leave a written message listing details of your planned cruise (Float Plan) with a close friend ashore. Include a description of your boat, where you intend to cruise, schedule of your arrival in the cruising area and when you expect to return.
- Keep the person informed of any changes in your plan to prevent false alarms. This information can tell authorities where to look and your boat type in the event you fail to arrive.
- Check the amount of fuel onboard. Observe the "rule of thirds": one third of the fuel for the trip out, one third to return and one third in reserve. An additional 15% may be consumed in rough seas.
- Check the water separating fuel filters for water.
- Turn on the battery switches.
- Check for bilge water and for other signs of potential problems. Monitor for the scent of fuel fumes.
- Test the automatic and manual bilge pump switches to make sure the system is working properly.
- Have a tool kit and spare parts onboard.

The kit should include basic tools:

- Spark Plug Wrench
- □ Hammer
- Spark Plug Gap Gauge
- Electrician's Tape
- Screwdrivers
- Lubricating Oil
- Pliers
- Jackknife
- Adjustable Wrench
- Vise Grip Pliers
- Needle Nose Pliers
- Wire Crimping Tool
- End Wrench Set
- Wire Connector Set



The spare parts kit should include:

- Extra Light Bulbs
- Spark Plugs
- □ Fuses and Circuit Breakers
- □ Flashlight and Batteries
- Drain Plugs
- Engine Oil
- Propellers
- Fuel Filters
- Propeller Nuts
- □ Fuel Hose and Clamps
- Make sure all fire extinguishers are in position and in good operating condition.
- Make sure the shift control is in NEU-TRAL.
- Make sure the emergency engine stop lanyard is attached to the operator and the stop switch.

10.5 Operating your Boat

The operator must be seated, and ready with the controls (steering/throttle) when the engine is started or running.

After Starting the Engines:

- Check engine gauges. Make sure all are reading normally.
- Visibly check engines to be sure there are no apparent water, fuel or oil leaks.
- Check operation of engine cooling systems.
- Check controls and steering for smooth and proper operation.
- Allow engines to warm up for 10 to 15 minutes before operating them above idle speeds.
- Make sure all lines, cables, anchors, etc. for securing the boat are onboard and in good condition. All lines should be coiled, secured and off the decks when underway.
- Have a safe cruise and enjoy yourself.

REMEMBER:

When operating a boat, you accept the responsibility for the boat, safety of passengers and others out enjoying the water.

- Alcohol and any mind altering chemicals can severely reduce your reaction time and affect your better judgment.
- Alcohol reduces the ability to react.
- Alcohol makes it difficult to judge speed and distance or track moving objects.
- Alcohol reduces night vision and ability to distinguish red from green.

STAY ALERT. The use of alcohol or any other mind altering chemicals that impair judgment, pose a serious threat to you and others. The boat operator is responsible for their consequences and behavior of passengers.

IMPAIRED OPERATION HAZARD Operating any boat while intoxicated or under the influence of other drugs can cause death or serious injury. DO NOT operate any boat under the influence of any mind-altering chemical.

Avoid sea conditions that are beyond the skill and experience of you and your crew.

Make sure at least one other person onboard is instructed in the operation of the boat and it is operated in compliance with all state and local laws.

DO NOT operate the boat unless it is completely assembled. Make sure all fasteners are tight and adjustments are to specifications.

Before operating the boat for the first time, read the engine break-in procedures. Refer to the engine owner's manual. Since different types of engines are used, have your dealer describe the operating procedures for your boat. For more instructions on "How to Operate the Boat," read the instructions given to you for your engines.



Section 10

For more instructions on safety, equipment and boat handling, enroll in one of the several free boating courses offered. For information on the courses offered in your area, call the "Boating Safety Hotline," 800-368-5647.

If the drive unit hits an underwater object, stop the engine. Inspect drive unit for damage. If damaged contact your dealer for a complete inspection and repair of the unit.

Stopping the Boat

- Allow engines to drop to the idle speed.
- Shift controls to NEUTRAL.

If the engines have been run at high speed for a long period of time, allow engines to cool by running at idle for 3 to 5 minutes.

- Turn the ignition keys "OFF."
- Raise the trim tabs to full "UP" position.

NOTICE

Turn off engines at idle speed. Racing the engine before switching it off can draw water into the engine through the exhaust, resulting in internal damage.

After operation:

- If operated in saltwater, wash the boat and all equipment with soap and water.
 Flush the engines using fresh water.
 Refer to the engine owner's manual for instructions on flushing.
- Check the bilge area for debris and excess water.
- Fill the fuel tanks to near full to reduce condensation. Allow room in the tanks for the fuel to expand without being forced out the vent.
- Turn off all electrical equipment except the automatic bilge pumps.
- If you are going to leave the boat unattended for a long period of time, put the battery main switches to "OFF" and close all seacocks.
- Make sure the boat is securely moored.

NOTICE

To prevent damage, close all seacocks before leaving the boat.

10.6 Fishing

Fishing can be very exciting and distracting for the operator of the boat when the action gets intense. Be conscious that your primary responsibility is operating the boat safely to protect yourself, your passengers and other boats around you.

Make sure the helm is properly manned and is never left unattended while trolling.

If you are fishing in an area that is crowded with other fishing boats, it may be difficult to follow the rules of the road. This situation can become especially difficult when most boats are trolling. Be courteous and exercise good common sense. Avoid trying to assert your right of way and stay clear to preventing tangled or cut lines and other unpleasant encounters. Also, keep in mind that fishing line wrapped around a propeller shaft can cause damage to the lower unit seal.

10.7 Docking, Anchoring and Mooring

Docking and Docklines

Maneuvering a boat near a dock and securing it requires skill and techniques that are unique to water and wind conditions, and the dock layout. If possible, position a crew member at the bow and stern to assist with the lines and docking. While maneuvering close to the dock, compensate for wind and current, and anticipate how you can use them to help docking. Practice in open water using an imaginary dock to develop a sense for how the boat handles in different scenarios. You must be able to understand docking techniques before problems occur.

Approaching a dock or backing into a slip in high winds or strong currents requires skill. If you are new to handling a boat, take lessons



Operation

from an experienced pilot and learn to maneuver in tight quarters in less than ideal conditions. Also, practice away from the dock during windy conditions.

Dock lines are generally twisted or braided nylon. Nylon is strong and stretches to absorb shock. Nylon also has a long life and is soft and easy on the hands. The size of the line, will vary with the size of the boat. Typically a 30 to 40 feet boat will use 5/8inch line and a 20 to 30 feet boat will use 1/2-inch line. The number of lines and their configuration will vary depending on the dock, the range of the tide, and other factors. Usually a combination of bow, stern and spring lines is used to secure the boat.

Maneuvering to the Dock

Approach the dock slowly at a 30 to 40 degree angle. When possible, approach against the wind or current. Turn the engines straight and shift to neutral when you feel you have enough momentum to reach the dock. Use reverse to slow the boat and pull the stern toward the dock as the boat approaches. If you approached properly, the boat will lightly touch the pilings at the same time forward momentum is stopped. Have the dock lines ready and secure the boat as soon at it stops. Use fenders to protect the boat while it is docked. Keep the engines running until the lines are secured.

Backing into a Slip

Approach the slip with the stern against the wind or current and the engines straight ahead. Use the engines and turn the steering wheel to maneuver the boat into alignment with the slip. Reverse the engines and slowly back into the slip. Shift from reverse to neutral frequently at idle to prevent the boat from gaining too much speed. Move the stern right and left by shifting the engines in and out of gear or turning the wheel. When nearly in the slip all the way, straighten the engines and shift to forward to stop. Keep the engines running until the lines are secured.

Securing Docklines

Securing a boat along side the dock typically requires a bow and stern line and two spring lines. The bow and stern lines are usually secured to the dock at a 40 degree angle aft of the stern cleat and forward of the bow cleat. The after bow spring line is secured to the dock at a 40 degree angle aft of the after bow spring cleat. The forward quarter spring is secured to the dock at a 40 degree angle forward of the stern cleat. The spring lines keep the boat square to the dock and reduce fore and aft movement while allowing the boat to move up and down with the tide.

Securing a boat in a slip is somewhat different. It typically requires two bow lines secured to pilings on each side of the bow, two stern lines secured to the dock and two spring lines that prevent the boat from hitting the dock. The bow lines are typically secured with enough slack to allow the boat to ride the tide. The stern lines are crossed. One line runs from the port aft boat cleat to the starboard dock cleat and the other line runs from the starboard aft boat cleat to the port cleat on the dock. The stern lines center the boat, control the forward motion and allow the boat to ride the tide. Two forward quarter spring lines typically are secured to the stern cleats and to mid ship pilings or cleats. The spring lines keep the boat from backing into the dock while allowing it to ride the tide.

Leaving the Dock

Start the engines and let them warm up for 10 to 15 minutes before releasing the lines. Boats steer from the stern and it is important you achieve enough clearance at the stern to maneuver the boat as quickly as possible. Push the stern off and maneuver to gain stern clearance quickly. Proceed slowly until the boat has cleared the dock and other boats.



Mooring

Approach the mooring buoy heading into the wind or current. Shift to neutral when you have just enough headway to reach the buoy. Position a crew member on the bow to retrieve the buoy with a boat hook and secure the line. Keep the engines running, until the line is secure.

Leaving a Mooring

Start the engines and let them warm up before releasing the mooring line. The boat will already be headed into the wind, so move it forward enough to loosen the line and untie it. Back the boat away until you can see the buoy and slowly move away.

Anchoring

Make sure the bitter end of the anchor rode is attached to the boat before dropping the anchor. Bring the bow into the wind or current and put the engine in neutral. When the boat comes to a stop, lower the anchor. Allow enough rode so that it is at least 5 to 7 times the depth of the water and secure the line to a cleat. Use caution to avoid getting your feet or hands tangled in the line. Additional scope of 10 times the depth may be required for storm conditions. Check landmarks on shore to make sure the anchor is not dragging. If it is dragging, start over. It is prudent to use two anchors if you are anchoring overnight or in rough weather.

SINKING OR DROWNING HAZARD Anchoring at the stern can pull a boat under water. DO NOT anchor at the stern.

Releasing the Anchor

Release the anchor by traversing to the point where the anchor line becomes vertical. It should release when you pass that point. If the anchor does not release, stop the boat directly above the anchor and tie the line to a cleat as tight as possible. The up and down movement of the boat will usually loosen the anchor. Make sure the anchor is secured and stowed before getting underway.

10.8 Controls, Steering or Propulsion System Failure

MOVING PARTS HAZARD Contact with moving parts can entangle, cut and cause death or serious injury. DO NOT come close enough to make contact with any running machinery moving parts, i.e., engine or propeller. Contact can result in loss of body parts, strangulation, burns and/or severe loss of blood resulting in serious injury or death.

The engine covers are machinery guards and must be in place whenever the engines are running. DO NOT operate the boat without the covers in place unless you are performing a check or maintenance.

If the propulsion, control or steering system fails while you are operating the boat, bring both throttles to idle and shift to neutral. Determine if the boat should be anchored to prevent the boat from drifting or to hold the bow into the seas. Investigate and correct the problem if possible. Make sure the engines are off before investigating the problem. If you are unable to correct the problem, call for help.

If only one engine has failed, you can operate on one engine. Do not to apply too much power to the running engine. When running one engine to power a twin engine boat, the engine is "over propped" and can be overloaded if too much throttle is applied. Contact your dealer or the engine manufacturer for the maximum power settings when running on one engine.



Collision

If your boat is involved in a collision with another boat, dock, piling or a sandbar, your first priority is to check passengers for injuries and administer first aid if necessary. Once all passengers' situations are stabilized, thoroughly inspect the boat for damage. Check below decks for leaks and all control systems for proper operation. Plug all leaks or make the necessary repairs to the control systems before proceeding. Operate slowly and carefully, but take all necessary precautions to be safe. Request assistance if necessary. Haul the boat and make a thorough inspection of the hull, lower unit and control system for damage.

10.9 Grounding, Towing and Rendering Assistance

The law requires the owner or operator of a vessel to render assistance to any individual or vessel in distress, as long as his vessel is not endangered in the process.

If the boat should become disabled, or if another craft that is disabled requires assistance, be careful. The stress applied to a boat during towing can become excessive. Excessive stress can damage the structure and create a safety hazard for all onboard.

Freeing a grounded vessel, or towing a disabled boat requires specialized equipment and knowledge. Line failure and structural damage caused by improper towing have resulted in fatal injuries. To safely accomplish the towing task, we recommend this to be reserved for those with the right equipment and knowledge, e.g., the U.S. Coast Guard or a commercial towing company.

The mooring cleats or bow/stern eyes on Pursuit boats are not designed or intended to be used for towing or lifting. These cleats are designed as mooring cleats for securing the boat to a dock, pier, etc. only. DO NOT use these fittings for towing, lifting or attempting to free a grounded vessel.

When towing operations are underway, have everyone on both vessels stay clear of the

tow line and surrounding area. DO NOT allow anyone to be in line with the tow rope; a dangerous, recoil can occur if the rope should break or pull free.

Running aground can cause serious injury to passengers and damage the boat and its underwater gear.

If your boat runs aground, evaluate the damage, then proceed at low speed to the nearest service facility and have an immediate inspection made before further use. A damaged boat can also take on water; keep all life saving devices close while heading to a dock area. If the boat cannot be immediately removed from the water, thoroughly inspect the bilge area for leaks.

Flooding or Capsizing

Boats can become unstable if they become flooded or completely swamped. Always be aware of the position of the boat to the seas and the amount of water in the bilge. Water entering the boat over the transom can usually be corrected by turning the boat into the waves. If the bilge is flooding because of a hole in the hull, the engine bracket or a defective hose, you may be able to plug it with rags, close the thru-hull valve or assist the pumps by bailing with buckets. Put a mayday call into the Coast Guard or nearby boats and distribute life jackets as soon as you discover your boat is in trouble.

If the boat becomes swamped and capsizes, you and your passengers should stay with the boat as long as you can. It is much easier for the Coast Guard, aircraft, or other boats to spot, than people in the water.

Transporting your Boat

Your Pursuit boat is a large boat and should only be trailered by professionals with the right equipment and knowledge to transport large boats without causing damage. Contact your dealer or the Pursuit Customer Relations Department if you are planning to transport your boat and have any questions in regard to the proper equipment and support for the hull.



Section 10

Damaged from trailers can occur if the boat hull is not supported properly. Make sure the trailer bunks and pads are adjusted so they provide enough support for the hull and are not putting excessive pressure on the lifting strakes. Hull damage resulting from improper trailer support is not covered by the Pursuit warranty.

Trailering your Boat

The boat trailer is an important part of your boating package. The trailer must be matched to the weight of the boat. A trailer with a capacity too low will be unsafe on the road and cause abnormal wear. A trailer with a capacity too high, can damage the boat. Contact your dealer to evaluate your towing vehicle and hitch, and to make sure you have the correct trailer for your boat.

NOTICE

Your Pursuit is heavy and the selection of your trailer is very important. We recommend using a bunk style trailer that incorporates a combination of heavy duty rollers to support the keel and long bunks running under and parallel to the stringers to support the hull. Trailers without bunks can cause damage and have a tendency to put extreme pressure points on the hull, especially on the lifting strakes. The situation worsens when launching or retrieving. Damage resulting from improper trailer support or the use a full roller trailer will not be covered by the Pursuit Warranty.

If you trailer your boat, make sure your tow vehicle is capable of towing the weight of the trailer, boat and equipment and the weight of the passengers and equipment inside the vehicle. This may require the tow vehicle to be specially equipped with a larger engine, transmission, brakes and trailer tow package.

The following safety tips and a book titled "Sportfish, Cruisers, Yachts - Owner's Man-

ual," provide additional information you should know before trailering your boat.

DO NOT use bow or stern eyes, cleats or any other hardware for the purpose of towing, being towed or lifting, they are not designed for that purpose.

Contact your dealer to evaluate your towing vehicle and hitch, and to make sure you have the correct trailer for your boat.

- Make sure the trailer is a match for the weight and hull design of the boat. More damage can occur by the stresses of road travel than by normal water operation. A boat hull is designed to be supported evenly by water. So, when it is transported on a trailer it should be supported as evenly across the hull as possible allowing for even distribution of the weight of the hull, engine and equipment.
- Make sure the trailer bunks and rollers properly support the hull and do not put pressure on the lifting strakes. The rollers and bunks must be kept in good condition to prevent scratching and gouging of the hull.
- The capacity rating of the trailer should be greater, but not to an extreme, than the combined weight of the boat, motor, and equipment. The gross vehicle weight rating must be shown on the trailer. Make sure the weight of the boat, engine, gear and trailer is not more than the gross vehicle weight rating.
- DO NOT use your boat and trailer as a means for hauling excess gear.
- Make sure the boat is securely fastened on the trailer to prevent movement between the boat and trailer. The bow rope, chain or turnbuckle in addition to the winch cable. Additional straps may be required across the beam of the boat. If these types of straps are used, protect your boat from chaffing or from the straps "slapping" the gelcoat. Cover area where straps are secured and twisting the straps before they are secured will help reduce the "slapping" affect. Your dealer can provide instructions on how to load, fasten and launch your boat.

Before Going out on the Highway:

- **Canvas Enclosures** must be removed when trailering. Canvas enclosures will be damaged, they are not designed to withstand the extreme wind pressure encountered while trailering. Remove and properly store enclosures before trailering.
- **Tow Ball And Trailer Coupler** make sure they are the same size and bolts and nuts are tightly secured.
- The coupler **MUST BE** completely over the ball and the latching mechanism **LOCKED DOWN**.
- Load Trailer Evenly make sure load is evenly distributed from front to rear, as well as side to side and has the correct distribution of weight on the hitch. Too much weight on the hitch will cause the rear of the tow vehicle to drag and may make steering more difficult. Too little weight on the hitch will cause the rig to fishtail and will make controlling the tow vehicle difficult. Contact your Pursuit dealer or the trailer manufacturer for the correct weight on the hitch for your trailer.
- Safety Chains attach crisscrossing under the coupler to the frame of the tow vehicle. If the ball breaks, the trailer would follow in a straight line and prevent the coupler from dragging on the road. Make sure the trailer emergency brake cable or chain is also installed to the tow vehicle frame.
- **Lights** make sure they are functioning properly.
- **Brakes** check on a level parking area; roll forward and apply the brakes several times at increasing speeds to determine if the brakes on the tow vehicle and trailer are working properly.
- Side View Mirrors make sure the tow vehicle mirrors are large enough to provide an unobstructed rear view on both sides of the vehicle.
- **Tires and Wheel Bearings** check before getting on the road.

Make sure your tow vehicle and trailer are in compliance with all state and local laws for the area you will be trailering. Contact your state motor vehicle bureau for laws governing the towing of trailers.

Water Skiing

Your Pursuit can be equipped for water skiing. If you have never pulled skiers, you should observe, learn and practice from an experienced driver. If you are an experienced driver, become familiar with the boat and the way it handles before pulling a skier. The driver should also know the ability of the skiers and drive accordingly. The following safety precautions should be observed while towing water skiers.

- Water ski only in safe areas, away from other boats and swimmers, out of channels and in water free of underwater obstructions and water ski only during daylight hours.
- Make sure that anyone who skis can swim. DO NOT allow people who cannot swim to water ski.
- Make sure all skiers wear a proper life jacket. A water skier is considered onboard the boat and a Coast Guard approved life jacket is required. A skier should wear a flotation device designed to withstand the impact of hitting the water at high speed. A second person must be onboard to observe the skier so your attention can be directed to the safe operation of the boat.
- Approach a skier in the water from the downwind side and STOP THE ENGINE and forward motion of the boat before coming in close proximity to the skier.
- Give immediate attention to a fallen skier. A fallen skier is very hard to see by other boats and is extremely vulnerable. When a skier falls, be prepared to turn the boat immediately and return to the skier. Never leave a fallen skier alone in the water for any reason.

For additional information on water skiing, including hand signals and water skiing manuals, contact the American Water Skiing Association - 863-324-4341 or visit their Web Site at <u>www.usawaterski.org</u>.



CARBON MONOXIDE POISONING AND/OR ROTATING PARTS HAZARD Poisonous CO gases are present at the rear of the boat when an engine is running. A rotating propeller can cut or entangle swimmers, both of these hazards will cause death or serious injury. DO NOT use the swim/boarding platform when the engine is running.

Remove and store the ladder properly before starting the engines.

Man Overboard

If someone falls overboard, be prepared to react quickly, especially when you are offshore. The following procedures will help you in recovering a person that has fallen overboard.

- Immediately stop the boat and sound a man overboard alarm and have all passengers point to the person in the water.
- Circle around quickly and throw a throwable PFD, cushion or life jacket to the person and if possible, another to use as a marker.
- Keep the person on the driver side of the boat to keep them in sight.
- Approach the person from the downwind side and maneuver the boat so the propellers are well clear of the person in the water.
- Turn off the engines when person is alongside and use a ring buoy or a boat cushion with a line attached, a paddle or boathook to assist person to the boat; make sure you do not hit them with the ring buoy or the boat.
- Pull person to the boat and assist onboard.
- Check person for injuries and administer first aid if necessary, if the injuries are serious, call for help immediately.

Refer to Safety Equipment for more information on first aid and requesting emergency medical assistance.

Trash Disposal

The discharge of plastic trash or trash mixed with plastic is illegal anywhere in the marine environment. It is also illegal to discharge garbage in the navigable waters of the United States including the great lakes.

Regional, State, and local restrictions on garbage discharges also may apply. Vessels of 26 feet or longer must display in a prominent location, a durable placard at least 4 by 9 inches notifying the crew and passengers of the discharge restrictions.

Responsible boaters store refuse in bags and disposed of it properly on shore. Make sure your passengers are aware of the local waste laws and the trash management procedure on your boat.



Routine Maintenance

11.1 General

FIRE/EXPLOSION/ASPHYXIATION HAZARD

Cleaning agents and paint ingredients can be flammable and/or explosive, or dangerous to inhale. Make sure ventilation is adequate, wear proper personal protection and dispose of rags properly ashore.

Vapors from flammable solvents can cause fire, explosion or asphyxiation resulting in death or serious injury. Keep open flame or spark away from work area. DO NOT paint unless in a well-ventilated area.

Before using a cleaning product, refer to the product directions and specifications.

If urethane foam is used in the construction of your boat, be careful with high temperatures or flames in these areas. Urethane foam can ignite. DO NOT smoke, weld or burn. Avoid the use of space heaters and lights in areas where urethane foam is present. If ignited, urethane foam burns rapidly, produces extreme heat, releases hazardous gases and consumes much oxygen.

11.2 Exterior Hull and Deck

Hull Cleaning - Below the Waterline

When the boat is removed from the water, clean the outer bottom surface immediately. Algae, grass, dirt and other marine growth can be removed easier while the hull is still wet. Use a pressure cleaner or a hard bristle brush to clean the surface.

Bottom Painting

If the boat is to be left in the water for more than sixty (60) days in any ninety (90) day period an epoxy barrier coat should be applied to prevent blistering or osmosis prior to applying antifouling paint. Because of variations in water temperature, marine growth and pollution in different regions, your dealer and/or a qualified boat yard in your area should be consulted when deciding what bottom paint system to apply to your hull, because pollution and marine growth can damage fiberglass hulls.

Sanding or sandblasting the hull bottom will damage the fiberglass. Only use standard antifouling paints and fiberglass wax removers and primers recommended by the antifouling paint manufacturer when preparing the hull for bottom paint. Sanding or sandblasting and the use of a coating other than standard antifouling paint or epoxy barrier coatings are not recommended and will void the hull blister warranty.

DO NOT allow antifouling paint to contact the outboard engine. Most antifouling paints contain copper which will cause severe galvanic damage to the motor. Leave a 1/2 inch (12,7 mm) barrier between the hull bottom paint and outboard engine.

Most bottom paints require maintenance, especially when the boat is in saltwater or not used for extended periods, or after dry storage. If the hull bottom has been painted with antifouling paint, contact your dealer for the recommended maintenance procedures.



Sacrificial Anodes

Sacrificial zinc anodes are installed on the trim tabs, transom and outboard engines. The transom anode is connected to the bonding system and protects the underwater hardware that is bonded.

The anodes are less noble than copper based alloys and aluminum and will deteriorate first, protecting the more noble underwater hardware against galvanic corrosion. Anodes should be checked monthly and changed when they are 75% of their original size. When replacing the anodes, make sure the contact surfaces are clean, shiny metal and free of paint and corrosion. Never paint over the anode or protect it.

Boats stored in saltwater will require anodes to be replaced at least every 6 months to one year. Anodes requiring replacement more frequently may indicate a stray current problem within the boat or at the slip or marina. Anodes that do not need to be replaced after one year may not be providing the proper protection. Loose or low quality anodes could be the problem. Contact your dealer for the proper size and type of anodes to be used and the specific installation procedure.

Fiberglass Gelcoat Surfaces

Normal maintenance requires only washing with mild soap and water. A stiff brush can be used on the nonskid areas. Kerosene or commercially prepared products will remove oil and tar which could be a problem on trailered boats. DO NOT use harsh abrasive and chemical cleaners because they can damage or dull the gelcoat, reducing its life and making it more susceptible to stains. When the boat is used in saltwater, wash it thoroughly with soap and water after each use.

Sudden changes in temperature can affect gelcoat. When planning on moving your boat from outdoors to a heated location, allow the change of temperature to be gradual. Warm the location slowly after the boat is brought inside to allow the boat to change temperature slowly as the location is warmed. Or, if you are moving your boat from a warmer area to a colder one, wait for the temperature to be closer to the temperature of the warmer area or allow the warmer area and the boat to cool down.

At least once a season, wash and wax all exposed fiberglass surfaces. Use a high quality marine wax ONLY. Follow the procedure recommended by the wax manufacturer. Washing and waxing of your boat will have the same beneficial effects as they have on an automobile finish. The wax will fill minute scratches and pores which help prevent soiling and will extend the life of the gelcoat.

NOTICE

Use only a good quality marine wax (carnauba or equivalent). Never use a polymer or silicone based product on gelcoat surfaces as these products can cause irreparable damage and staining.

After the boat is exposed to the direct sunlight for a period of time, the color in the gelcoat tends to fade, dull or chalk from oxidation of the gel. This condition will be more apparent with dark colors, which require more frequent maintenance. A heavier buffing is required to bring the gelcoat back to its original luster. For power cleaning use a light cleaner. To clean the boat by hand, use a heavier automotive cleaner. Before cleaning the surfaces, read the instructions given with the cleaner. After cleaning the surfaces, apply wax and polish all fiberglass surfaces except the nonskid areas.

If the fiberglass should become damaged and need repair, contact your dealer for an authorized repair person to make the repairs.



SLIPPERY SURFACE HAZARD

Cleaning surfaces can generate slippery conditions which can result in death or serious injury. Use caution when cleaning with detergents. Rinse thoroughly.

Be careful when walking on wet gelcoat surfaces.

DO NOT wax nonskid surfaces, these could make them slippery and increase the possibility of injury.

Stainless Steel Hardware

When using the boat in saltwater, wash hardware with soap and water after each use. When your boat is used in a higher corrosive environment, such as saltwater, water with a higher sulfur content or polluted water, stainless steel will periodically develop surface rust stains; this is normal under these conditions.

Clean and protect by using a high quality boat or automotive wax or a commercial metal cleaner and protectant.

DO NOT use citrus-based, abrasive materials such as sandpaper, bronze wool, or steel wool on stainless steel as damage will result.

Anodized Aluminum Surfaces

Wash periodically with soap and water to keep it clean. If the boat is used in saltwater or polluted water, wash with soap and water after each use. Saltwater allowed to remain on anodized aluminum will penetrate the anodized coating and attack the aluminum.

Hardtops with aluminum parts, bimini tops and towers with canvas and/or fiberglass tops require special attention to the anodized aluminum just below the top. This area is subject to salt build-up from salty condensation and sea spray. It is often overlooked when the boat is washed and will not be rinsed by the rain. The aluminum just below the top is more likely to become pitted than the exposed aluminum on the structure. Make sure these areas are washed frequently with soap and water and rinsed thoroughly. Pay particular attention to places where the top material and lacing contact the frame. Coat any anodized aluminum with a metal protector made for anodized aluminum once a month to protect against pitting and corrosion caused by the harsh effects of saltwater. The anodized aluminum used on your Pursuit was coated with a metal protector called Aluma Guard at the factory. Aluma Guard is a nonabrasive marine metal protector that protects anodized aluminum, stainless steel, brass and chrome. It also protects color anodizing from fading and discoloring due to harmful ultraviolet rays. Aluma Guard is available from your dealer or Rupp Marine Inc., 4761 Anchor Avenue, P.O. Drawer F, Port Salerno, FL 34992.

Aluma Guard and other metal protectors can make the metal slippery and should not be used on tower ladders, steering wheels and other areas for gripping or stepping.

Stains can be removed with a metal polish or fine polishing compound. To minimize corrosion, use a caulking compound to bed hardware and fasteners mounted to aluminum fabrications. If the anodized coating is badly scratched it can be touched up with paint. With proper care, anodized aluminum will provide many years of service.

Contact Pursuit Customer Relations before making any modifications to aluminum fabrications. Unauthorized modifications can void the warranty.

Powder Coated (Painted) Aluminum Surfaces

Regular care is necessary to maintain the appearance of the powder coat finish. Buildup of salt and grime can hold moisture and damage powder coatings. This buildup can cause a corrosive condition that can damage the coating, especially in a salt air or coastal environment.



- Wash the finish regularly with warm water containing a pH neutral detergent (i,e., mild dish soap).
- Use a non-abrasive fiber cloth.
- Rinse thoroughly after cleaning.

Chrome Hardware

Rinse with fresh water and wipe dry with towel or chamois after each use. Use a good chrome cleaner and polish on all chrome hardware. Clean and wax chrome prior to extended storage. In saltwater or other harsh environments, clean and wax more often.

Acrylic Plastic

Acrylic plastic scratches easily. DO NOT use a dry cloth or glass cleaning solutions on acrylic. Use a soft cloth and mild soap and water for routine cleaning. Solvents and products containing ammonia can permanently damage acrylic plastic.

Fine scratches can be removed with a fine automotive clear coat polishing compound. A coat of automotive or boat wax is beneficial to protect the surface.

DO NOT use the following on acrylic plastic:

- Abrasive cleaners
- Acetone
- Solvents
- Alcohol
- Glass cleaners
- Cleaners containing ammonia.

Engines

Proper engine maintenance is essential to performance and reliability of your outboard engines. Maintenance schedules and procedures are outlined in your engine owner's manual, follow them exactly.

Flush the system when the boat is out of the water. If the boat is used in saltwater, flush daily.

The age of gasoline can affect engine performance. Chemical changes occur as the gasoline ages, causing deposits and varnish in the fuel system and reduces the octane rating of the fuel. Degraded fuel can damage the engine and boat fuel tank and lines. If your boat does not require at least one full tank of fresh fuel a month, add a fuel stabilizer to the gasoline to protect the fuel from degradation. Use only a fuel stabilizer recommended by your dealer or the engine manufacturer. Operate the boat at least 15 minutes after adding the stabilizer to allow the treated fuel to reach the engine. Your dealer or engine manufacturer can provide additional information on fuel degradation. For more recommendations for your specific area, check with your local Pursuit dealer.

Avoid using fuels with alcohol additives. Gasoline, extended with an alcohol blend, will absorb moisture from the air which can reach such concentrations that "phase separation" can occur where the water and alcohol mixture becomes heavy enough to settle out of the gasoline to the bottom of the tank. Since the fuel pick-up tube is near the bottom of the tank, phase separation can cause the engine to run poorly or not at all. This condition is more severe with methyl alcohol and will worsen as the alcohol content increases. Water or a jelly like substance in the fuel filters is an indication of possible phase separation from the use of alcohol blended fuels.

Contact your Pursuit dealer or engine manufacturer for additional information regarding fuels and additives.

Corian® Surfaces

Corian® is resistant to heat, but you should always use a hot pad or a trivet with rubber feet to protect Corian®. Avoid exposing Corian® to strong chemicals, such as paint removers, oven cleaners, etc. If contact occurs, flush the surface with water immediately. Soapy water or ammonia-based cleaners will remove most dirt and stains from all types of finishes.

DO NOT use the Corian® countertop as a cutting board.

Minor damage, scratches, general or chemical stains, scorches or burns and minor



impact marks can be repaired on-site with a light abrasive cleanser and a product such as a Scotch-Brite® pad. For heavier damage, light sanding may be necessary. Heavy damage should be repaired by a Corian® licensed professional.

Tempered Glass Sink

For best results:

- DO NOT use strong/abrasive cleaner. Test your cleaning solution on an unnoticeable area first, before applying to the entire surface.
- Wipe surfaces clean, immediately after applying cleaner.
- DO NOT allow cleaner to sit or soak on the surface.
- DO NOT use an abrasive brush or scouring pad to clean surfaces as damage will occur. Use only a soft, dampened sponge and cloth.
- Rinse and wipe the fixtures to prevent soap build-up.

11.3 Seats, Upholstery, Canvas and Enclosures

Seat Slides and Swivel Bases

Perform the following periodically:

- Inspect and tighten mounting screws between seat slides and seat bottom.
- Inspect and tighten the mounting screws attaching seat bases to boat.
- Keep a light film of grease on manual seat slides.
- Keep a light film of grease on manual seat adjusting mechanism.
- Clean electric seat slides. DO NOT use harsh chemicals or abrasives. Lubrication is not required.

Vinyl Upholstery

The vinyl upholstery used on the exterior seats and bolsters should be cleaned with soap and water periodically. Stains, spills or soiling should be cleaned up immediately to prevent the possibility of permanent staining. When cleaning, rub gently. DO NOT use products containing ammonia, powdered abrasive cleaners, steel wool, strong solvents, acetone and lacquer solvents or other harsh chemicals as they can permanently damage or shorten the life of vinyl. Never use steam heat, heat guns or hair dryers.

Stronger cleaners, detergents and solvents may be effective in stain removal, but can cause either immediate damage or slow deterioration. Lotions, sun tan oil, waxes and polishes, etc., contain oils and dyes that can cause stiffening and staining of vinyls.

- **Dry soil, dust and dir**t remove with a soft cloth.
- **Dried on dirt** wash with a soft cloth dampened with water.
- Variations in surface gloss wipe with a water-dampened soft cloth and allow to air dry.
- Stubborn dirt wash with a soft cloth, dampened with Ivory Flakes® and water. Rinse with clean water.
- Stubborn spots and stains spray with either Fantastik Cleaner® or Tannery Car Care Cleaner® and rub with a soft cloth. Rinse with clean water.
- Liquid spills wipe with a clean absorbent cloth immediately. Rinse with clean water.
- Food grease and oily stains spray with either Fantastik Cleaner® or Tannery Car Care Cleaner®, wiping with a soft cloth immediately. Be careful not to extend the area of contamination beyond its original boundary. Rinse with clean water.

Canvas and Side Curtains

Acrylic canvas should be cleaned periodically by using a mild soap and water. Scrub lightly and rinse thoroughly to remove the soap. Do not use detergents. The top or accessories should never be folded or stored wet.

After several years, the acrylic canvas may lose some of its ability to shed water. If this occurs, wash the fabric and treat it with a commercially available water proofing designed for this purpose. Some leakage at



the seams is normal and unavoidable with acrylic enclosures.

Side curtains and clear connectors can be cleaned with mild soap and water. Do not allow them to become badly soiled. Dirt, oil, mildew, and cleaning agents containing ammonia will shorten the life of the vinyl that is used for clear curtains. After cleaning the curtains and allowing them to dry, apply a non-lemon furniture polish or an acrylic plastic and clear plastic protector to extend the life of the curtains.

Vinyl curtains should be stored either rolled or flat, without folds or creases. Folding the curtains will make permanent creases that could cause the vinyl to crack.

DO NOT use any polish containing lemon or lemon scents; lemon juice attacks vinyl and shorten its life.

Lubricate snaps periodically with petroleum jelly or silicone grease. Lubricate zippers with silicone spray or paraffin.

Remove the bimini top, side curtains, clear connector, back drop and aft curtain when trailering. Canvas enclosures are not designed to withstand the extreme wind pressure encountered while trailering and will be damaged. Always remove and store properly before trailering.

11.4 Cabin Interior

Clean cabin interior just like you would clean a home interior.

- Interior woodwork use damp cloth to wipe clean. A gentle furniture cleaner can be used for stubborn areas.
- Bedding materials Most covers can be removed and cleaned outside the boat.
- **Ceramic stovetop** Use damp cloth for minor spills. Use a cleaner designed for ceramic cooktops. Take care not to leave it on wood or Corian surfaces.
- **Corian** Damp cloth. Do not use abrasive cleaners.

Air and sunlight are very good cleansers. Periodically, place cushions, sleeping bags, etc. on deck, under the sun and fresh air to dry and air out. If cushions or equipment get wet with saltwater, remove and use clean, fresh water to rinse off the salt crystals. Salt retains moisture and will cause damage. Dry thoroughly and reinstall.

If you leave the boat for a long period of time, put all cushions on their sides, open all interior cabin and locker doors, and hang a commercially available mildew protector in the cabin.

Read the label carefully on mildew protectors and remove the protector and allow the cabin to ventilate completely before using the cabin.

11.5 Bilge

To keep the bilge clean and fresh, use a commercial bilge cleaner regularly. Follow the directions carefully. All exposed pumps and metal components should be sprayed with a protector periodically to reduce the corrosive effects of the high humidity present in these areas.

FIRE/EXPLOSION OR ASPHYXIATION HAZARD

Fumes from flammable solvents can cause fire, explosion or asphyxiation resulting in death or serious injury. DO NOT use flammable solvents to clean the bilge.



11.6 Generator (Optional)

The engine maintenance required on the generator is similar to an inboard engine. The engine incorporates a pressure-type lubrication system and a fresh water cooled engine block which is thermostatically controlled. The most important factors to the longevity of the generator is proper ventilation and maintenance of the fuel system, ignition system, cooling system, lubrication system and the AC alternator.

Maintenance schedules and procedures are outlined in the generator owner's manual; follow them exactly.



Operator Notes

Seasonal Maintenance

12.1 Storage and Lay-up

Before Hauling:

- Pump out the head. Flush the holding tank using clean soap, water, deodorizer and pump out cleaning solution.
- Leave the fuel tank nearly full to reduce condensation that can accumulate in the tank. Allow enough room for fuel to expand without leaking from the vents.
- Algae can grow in the accumulated water in diesel fuel tanks, especially in warm climates. Adding a high quality diesel fuel additive containing an algaecide may be required to control algae during storage in your area.
- Drain fresh water system.
- Refer to the engine owner's manual for detailed information on preparing the engines for storage.

Lifting

It is essential that care be used when lifting your boat. Make sure the spreader bar at each sling is at least as long as the distance across the widest point of the boat that the sling will surround. Put the slings in position. Refer to the drawing in the Schematics for the correct position of the lifting slings. The positions are marked with small labels on each side of the boat under the rubrails. Tie fore and aft slings together to prevent slings from sliding on the hull.

Elevating lifts are commonly used to store boats for extended periods. To provide proper support, the bunks that support the hull should be aligned with and run parallel to the hull stringers. The bow and stern eyes, if equipped should not be used as sole support for storage.

Your boat can be damaged from improper lifting and rough handling when being transported by lift trucks. Care and proper handling procedures must be used when using a lift truck to move your boat. DO NOT attempt to lift boat with a substantial amount of water in the bilge. Severe gelcoat cracking or more serious hull damage can occur during hauling and launching if pressure is created on the gunwales (sheer) by the slings. Use flat, wide slings and spreaders long enough to keep pressure from the gunwales. DO NOT allow your boat to be hauled when the spreaders on the lift are not wide enough to take the pressure off the gunwales.

Supporting The Boat for Storage

A trailer, elevating lift or a well-made cradle is the best support for your boat during storage.

When storing the boat on a trailer for a long period:

- Make sure the rollers and pads support the hull of the boat and the trailer is on a level surface with the bow high enough so water will drain from the bilge and cockpit. The trailer must properly support the hull. The bunks and rollers should match the bottom of the hull and should not be putting pressure on the lifting strakes.
- Make sure the hitch is properly supported.
- Check the tires once each season. Add enough air for the correct amount of inflation for the tires.
- Make sure the engines are in the down position.

When storing the boat on a lift or cradle:

- The cradle must be specific for boat storage. Make sure lift or cradle is well supported with the bow high enough to provide proper drainage of the bilge. The cradle or lift must be in the proper fore and aft position to properly support the hull. When the cradle or lift is in the correct location, the bunks should match the bottom of hull and should not be putting pressure on the lifting strakes.
- Make sure the engines are in the down position.
- Make sure bunks and rollers are adjusted so they are not putting pressure on lifting strakes and are providing enough support for the hull. Hull damage



resulting from improper cradle or trailer support is not covered by the Pursuit warranty.

Preparing The Boat For Storage:

- Remove the bilge drain plug(s), if installed.
- Thoroughly wash fiberglass exterior, especially the antifouling portion of the bottom. Remove as much marine growth as possible. Lightly wax the exterior fiberglass components.
- Remove all oxidation from the exterior hardware and apply a light film of moisture displacing lubricant.
- Remove propellers and grease the propeller shafts using light waterproof grease.
- Remove batteries and clean using clear, clean water. Make sure batteries have sufficient water and terminals are clean. Keep the batteries charged and stored in a cool, dry place and safe from freezing throughout the storage period.
- Refer to the Electrical System for information on the maintenance of the AC and OS electrical systems.
- Coat all faucets and exposed electrical components in the cabin and cockpit with a protecting oil.
- Clean, drain and completely dry the fishboxes, sinks and livewells.
- Thoroughly clean the interior of the boat; clean all upholstery.
- Remove cushions, open the refrigerator/ cooler door and as many locker doors as possible. Leaving as many of these areas open as possible will improve fresh air ventilation during the storage period.
- Place a mildew preventive system in the cabin area before it is closed for storage.
- Clean the exterior upholstery with a good vinyl cleaner and dry thoroughly. Spray the weather covers and boat upholstery with a spray disinfectant. Enclosed areas such as the refrigerator, shower basin, storage locker areas, etc. should also be sprayed with a disinfectant.

12.2 Winterizing

Fresh Water System

The entire fresh water system must be completely drained. Disconnect all hoses, check valves, etc. and blow all the water from the system. Make sure the water heater and fresh water tank are completely drained. Use very low air pressure only when blowing water from the system to prevent damage to components. The check valve mechanism built in the fresh water pump will not remove the water from the pump. Remove the outlet hose on the pump, turn it on and allow it to pump out any remaining water, approximately a cupful.

An alternate method is to use commercially available nontoxic, fresh water system antifreeze. After draining the potable water tank, lines and water heater, pour the antifreeze mixture into the fresh water tank, prime and operate the pump until the mixture flows from all fresh water faucets. Be sure to open ALL faucets, including the fresh water spray head in the cockpit and the water supply valve for the head. Make sure antifreeze has flowed through all of the fresh water drains. Allow the antifreeze to fill the sink traps to trap odors from the waste tank.

The shower/cabin drain sump system must be winterized also. Clean debris from the drain and sump and flush for several minutes with fresh clean water. After the system is clean, pump the drain sump as dry as possible. Then pour a potable water antifreeze mixture into the shower drain until antifreeze has been pumped through the entire system and out of the thru-hull.

For additional information, refer to Plumbing Systems.



Raw Water System

Drain the raw water systems completely. Disconnect all hoses and blow the water from the system. Use very low air pressure only when blowing water from the system to prevent damage to components. The check valve mechanism built in the raw water washdown pump, will not remove the water from the pump. Remove the outlet hose on the pump, turn it on and allow it to pump out any remaining water, approximately a cupful.

An alternate method is to use commercially available nontoxic, potable water system antifreeze. If antifreeze is used, pour the mixture into a pail and put the raw water intake lines into the solution. Run the pumps one at a time until the antifreeze solution is visible at all raw water faucets, discharge fittings and drains. Make sure antifreeze has flowed through all of the raw water drains.

Run the fishbox macerator pump until all the water is removed from the fishboxes and the pump. To avoid damage to the pump, DO NOT run pump dry for more than ten seconds.

Generator Raw Water Systems

Drain sea strainer, heat exchangers and raw water supply and discharge lines for the optional generator raw water supply pumps. Make sure all sea water has drained from the exhaust system. Some generator engine mufflers have a drain plug that must be removed to properly drain the muffler. Once this is accomplished, pour a nontoxic marine engine antifreeze mixture into a large pail and put the generator raw water intake lines into the solution. Run the generator until the antifreeze solution is visible at the exhaust port, then shut the engine off.

Winterize the generator engine and fuel system by following the generator manufacturer's winterizing procedures. Refer to generator's owner's manuals or contact a Pursuit dealer.

Marine Toilet

Winterize the marine toilet following the manufacturer's winterizing procedures; follow the procedures exactly. Refer to the toilet owner's manual. Drain the intake and discharge hoses completely using low air pressure if necessary. The head holding tank and macerator discharge pump must be pumped dry and one gallon of potable water antifreeze poured into the tank through the deck waste pumpout fitting. After the antifreeze has been added to the holding tank, open the overboard discharge valve and activate the macerator pump until the antifreeze solution is visible at the discharge thru-hull.

Air Conditioner (Optional)

Disconnect and drain the air conditioner intake and discharge hoses. Remove all water from the sea strainer and thru-hull fitting. Allow all water to drain from the system. An alternate method is the use of commercially available nontoxic, potable water system antifreeze. If antifreeze is used, drain the sea strainer and pour the mixture into a pail and put the raw water intake line into the solution. Run the air conditioner until the antifreeze solution is visible at the discharge fitting on the hull side.

Air conditioner components must be winterized also; follow winterizing procedure in the air conditioner owner's manual.

The air conditioning, engine control system, head, and steering systems have specific lay-up requirements. Refer to the owner's manuals for recommended winterizing procedures.



Bilge

Coat all metal components, wire busses, connector plugs (in the bilge), all strainers, seacocks and steering components with a protecting oil. The bilge pumps and bilge pump lines must be completely free of water and dried out when the boat is laid up for the winter in climates where freezing occurs. Compartments in the bilge that will not drain completely should be pumped out and then sponged until completely free of water. Dry the hull bilge and self-bailing cockpit troughs. Water freezing in these areas could cause damage.

Hardtop

Makes sure all drain holes in the legs are open and legs are completely free of water. Remove the canvas and thoroughly clean and store in a safe, dry place. Remove all electronics. Coat all wire connectors and bus bars in the helm compartment with a protecting oil.

Clean the powder coated frame with soap and water and dry thoroughly.

NOTICE

Make sure the leg drain holes are clear when the boat is laid up for the winter. Water trapped inside the hardtop, tower or radar arch legs can freeze and cause the legs to split.

Covering for Winter Storage

Proper storage is very important to prevent serious damage to the boat. If the boat is stored outside, support and secure a storage cover properly over the boat. It is best to have a frame built over the boat to support the cover. It should be a few inches wider than the boat so the cover will clear the rails and allow passage of air. If this cover is fastened too tightly there will be inadequate ventilation and can lead to mildew, moisture accumulation, etc. Fasten the cover down securely so wind cannot remove it or cause chafing of the hull superstructure. DO NOT store the boat in a damp storage enclosure. Excessive dampness can cause electrical problems, corrosion, and excessive mildew.

DO NOT use the factory canvas top in place of the winter storage cover. The life of these tops can be shortened if exposed to harsh weather elements for long periods.

DO NOT use an electric or fuel burning heating unit in the bilge area.

If the boat is to be stored indoors, make sure the building has enough ventilation and there is enough ventilation both inside the boat and around the boat. If the boat is to be stored indoors or outdoors, open all drawers, clothes lockers, cabinets, and doors a little. If possible, remove the upholstery, mattresses, clothing, and rugs.

12.3 Recommissioning

DO NOT operate the boat unless it is completely assembled. Keep all fasteners tight. Keep adjustments according to specifications.

Before launching the boat, make sure to install hull drain plug(s).

Reactivating the Boat After Storage:

- Charge and install the batteries.
- Install hull drain plug(s).
- Check the engines and generator for damage and follow the manufacturer's instructions for recommissioning.
- Check the mounting bolts of engines to make sure they are tight.
- Perform all routine maintenance.
- Check all hose clamps for tightness.
- Pump antifreeze from any systems winterized with antifreeze and flush several times with fresh water. Make sure all antifreeze is flushed from the water heater and it is filled with fresh water before it is activated.
- Check and lubricate the steering system.
- Clean and wash the boat.
- Install all upholstery, cushions and canvas.



After Launching:

- Check all water systems and the engine mounting bolts for leaks. Operate each system one at a time and check for leaks and proper operation.
- Check the bilge pump, manual and automatic switches.
- When the engines start, check the cooling system port below the engine cowling for a strong stream of water to ensure cooling pump is operating.
- Carefully monitor the gauges and check for leakage and abnormal noises.
- Operate boat at slow speeds until engine temperature stabilizes and all systems are operating normally.



Operator Notes

Glossary of Terms

Aft: In, near, or toward the stern of a boat.

Aground: A boat stuck on the bottom.

Amidships: In or toward the part of a boat midway between the bow and stern.

Anchor: A specially shaped heavy metal device designed to dig efficiently into the bottom under a body of water and hold a boat in place.

Anchorage: An area specifically designated by governmental authorities in which boats may anchor.

Ashore: On shore. Astern: Behind the boat, to move backwards.

Athwartship: At right angles to the center line of the boat.

Barnacles: Small, hard-shelled marine animals which are found in salt water attached to pilings, docks and bottoms of boats.

Beam: The breadth of a boat usually measured at its widest part.

Bearing: The direction of an object from the boat, either relative to the boat's direction or to compass degrees.

Berth: A bunk or a bed on a boat. Bilge: The bottom of the boat below the flooring.

Bilge Pump: A pump that removes water that collects in the bilge.

Boarding: Entering or climbing into a boat.

Boarding Ladder: Set of steps temporarily fitted over the side of a boat to assist persons coming aboard. **Boat Hook:** Short shaft of wood or metal with a hook fitting at one end shaped to aid in extending one's reach from the side of the boat.

Bow: The front end of a boat's hull.

Bow Line: A line that leads forward from the bow of the boat.

Bow Rail: Knee high rails of solid tubing to aid in preventing people from falling overboard.

Bridge: The area from which a boat is steered and controlled.

Bridge Deck: A deck forward and usually above the cockpit deck.

Broach: When the boat is sideways to the seas and in danger of capsizing; a very dangerous situation that should be avoided.

Bulkhead: Vertical partition or wall separating compartments of a boat.

Cabin: Enclosed superstructure above the main deck level.

Capsize: When a boat lays on its side or turns over.

Chock: A deck fitting, usually of metal, with inward curving arms through which mooring or anchor lines are passed so as to lead them in the proper direction both onboard and off the boat.

Cleat: A deck fitting, usually of metal with projecting arms used for securing anchor and mooring lines.

Closed Cooling System: A separate supply of fresh water that is used to cool the engine and circulates only within the engine.



Section A

Coaming: A vertical piece around the edges of cockpit, hatches, etc. to stop water on deck from running below.

Cockpit: An open space, usually in the aft deck, outside of the cabin.

Companionway: Opening in the deck of a boat to provide access below.

Compartment: The interior of a boat divided off by bulkheads.

Cradle: A framework designed to support a boat as she is hauled out or stored.

Cutlass Bearing: A rubber bearing in the strut that supports the propeller shaft.

Deck: The floor-like platform of a boat that covers the hull.

Displacement: The volume of water displaced by the hull. The displacement weight is the weight of this volume of water.

Draft: The depth of water a boat needs to float.

Dry Rot: A fungus attack on wood areas.

Dry-dock: A dock that can be pumped dry during boat construction or repair.

Electrical Ground: A connection between an electrical connector and the earth.

Engine Beds: Sturdy structural members running fore and aft on which the inboard engines are mounted.

EPIRB: Emergency Position Indicating Radio Beacon. Operates as a part of a worldwide satellite distress system.

Even Keel: When a boat floats properly as designed.

Fathom: A measure of depth. One Fathom = 6 feet.

Fender: A soft object of rubber or plastic used to protect the topsides from scarring and rubbing against a dock or another vessel.

Fend off: To push or hold the boat off from the dock or another boat.

Flying Bridge: A control station above the level of the deck or cabin.

Flukes: The broad portions of an anchor which dig into the ground.

Following Sea: A sea that comes up from the stern and runs in the same direction that the boat is going.

Fore: Applies to the forward portions of a boat near the bow.

Foundering: When a boat fills with water and sinks.

Freeboard: The height from the waterline to the lowest part of the deck.

Galley: The kitchen of a boat.

Grab Rail: Hand-hold fittings mounted on cabin tops or sides for personal safety when moving around the boat, both on deck and below.

Ground Tackle: A general term including anchors, lines, and other gear used in anchoring.

Grounds: A boat touches the bottom.

Gunwale: The upper edge of a boat's side.



Glossary of Terms

Hand Rail: Rail mounted on the boat, for grabbing with your hand, to steady you while walking about the boat.

Harbor: An anchorage which provides reasonably good protection for a boat, with shelter from wind and sea.

Hatch: An opening in the deck with a door or lid to allow for access down into a compartment of a boat.

Head: A toilet on a boat.

Heat Exchanger: Used to transfer the heat that is picked up by the closed cooling system to the raw cooling water.

Helm: The steering and control area of a boat.

Hull: The part of the boat from the deck down.

nboard: A boat with the engine mounted within the hull of the boat. Also refers to the center of the boat away from the sides.

Inboard/outboard: Also stern drive or I/O. A boat with an inboard engine attached to an outboard drive unit.

Keel: A plate or timber plate running lengthwise along the center of the bottom of a boat.

Knot: Unit of speed indicating nautical miles per hour. 1 knot = 1 nautical mile per hour (1.15 miles per hour). A nautical mile is equal to one minute of latitude: 6076 feet. Knots times 1.15 equals miles per hour. Miles per hour times .87 equals knots.

Lay-up: To decommission a boat for the winter (usually in northern climates).

Leeward: The direction toward which the wind is blowing.

Length On The Waterline (I.w.I.): A length measurement of a boat at the waterline from the stern to where the hull breaks the water near the bow.

Limber Hole: A passage cut into the lower edges of floors and frames next to the keel to allow bilge water to flow to the lowest point of the hull where it can be pumped overboard.

Line: The term used to describe a rope when it is on a boat.

Lists: A boat that inclines to port or starboard while afloat.

L.O.A.: Boat length overall.

Locker: A closet, chest or box aboard a boat.

Loran: An electronic navigational instrument which monitors the boat's position using signals emitted from pairs of transmitting stations.

Lunch hook: A small light weight anchor typically used instead of the working anchor. Normally used in calm waters with the boat attended.

Midships: The center of the boat.

Marina: A protected facility primarily for recreational small craft.

Marine Ways or Railways: Inclined planes at the water's edge onto which boats are hauled.

Moored: A boat secured with cables, lines or anchors.

Mooring: An anchor permanently embedded in the bottom of a harbor that is used to secure a boat.



Section A

Nautical Mile: A unit of measure equal to one minute of latitude. (6076 feet)

Nun Buoy: A red or red-striped buoy of conical shape.

Outboard: A boat designed for an engine to be mounted on the transom. Also a term that refers to objects away from the center line or beyond the hull sides of a boat.

Pad Eye: A deck fitting consisting of a metal eye permanently secured to the boat.

Pier: A structure which projects out from the shoreline.

Pile or Piling: A long column driven into the bottom to which a boat can be tied.

Pitching: The fore and aft rocking motion of a boat as the bow rises and falls.

Pitch: The measure of the angle of a propeller blade. Refers to the theoretical distance the boat travels with each revolution of the propeller.

P.F.D: Personal Flotation Device.

Port: The left side of the boat when facing the bow.

Porthole (port): The opening in the side of a boat to allow the admittance of light and air.

Propeller: A device having two or more blades that is attached to the engine and used for propelling a boat.

Propeller Shaft: Shaft which runs from the back of the engine gear box, aft, through the stuffing box, shaft log, struts, and onto which the propeller is attached.

Pyrotechnic Distress Signals: Distress signals that resemble the brilliant display of flares or fireworks.

Raw Water Cooled: Refers to an engine cooling system that draws sea water in through a hull fitting or engine drive unit, circulates the water in the engine, and then discharges it overboard.

Reduction Gear: Often combined with the reverse gear so that the propeller turns at a slower rate than the engine.

Reverse Gear: Changes the direction of rotation of the propeller to provide thrust in the opposite direction for stopping the boat or giving it sternway.

Roll: A boat's sideways rotational motion in rough water.

Rope Locker: A locker, usually located in the bow of a boat, used for stowing the anchor line or chain.

Rubrail: Railing (often rubber or hard plastic) that runs along the boat's sheer to protect the hull when coming alongside docks, piers, or other boats.

Rudder: A movable flat surface that is attached vertically at or near the stern for steering.

Sea anchor: An anchor that does not touch the bottom. Provides drag to hold the bow in the most favorable position in heavy seas.

Scupper: An opening in the hull side or transom of the boat through which water on deck or in the cockpit is drained overboard.

Seacock: Safety valves installed just inside the thru-hull fittings and ahead of the piping or hose running from the fittings.



Glossary of Terms

Shaft Log: Pipe through which the propeller shaft passes.

Sheer: The uppermost edge of the hull.

Sling: A strap which will hold the boat securely while being lifted, lowered, or carried.

Slip: A boat's berth between two pilings or piers.

Sole: The deck of a cockpit or interior cabin.

Spring Line: A line that leads from the bow aft or from the stern forward to prevent the boat from moving ahead or astern.

Starboard: The right side of a boat when facing the bow.

Steerageway: Sufficient speed to keep the boat responding to the rudder or drive unit.

Stem: The vertical portion of the hull at the bow.

Stern: The rear end of a boat.

Stow: To pack away neatly.

Stringer: Longitudinal members fastened inside the hull for additional structural strength.

Strut: Mounted to the hull which supports the propeller shaft in place.

Strut Bearing: See "cutlass bearing."

Stuffing Box: Prevents water from entering at the point where the propeller shaft passes through the shaft log.

Superstructure: Something built above the main deck level.

Swamps: When a boat fills with water from over the side.

Swimming Ladder: Much the same as the boarding ladder except that it extends down into the water.

Taffrail: Rail around the rear of the cockpit.

Thru-hull: A fitting used to pass fluids (usually water) through the hull surface, either above or below the waterline.

Topsides: The side skin of a boat between the waterline or chine and deck.

Transom: A flat stern at right angles to the keel.

Travel Lift: A machine used at boat yards to hoist boats out of and back into the water.

Trim: Refers to the boat's angle or the way it is balanced.

Trough: The area of water between the crests of waves and parallel to them.

Twin-Screw Craft: A boat with two propellers on two separate shafts.

Underway: When a boat moves through the water.

Wake: Disrupted water that a boat leaves astern as a result of its motion.

Wash: The flow of water that results from the action of the propeller or propellers.

Waterline: The plane of a boat where the surface of the water touches the hull when it is afloat on even keel.

Watertight Bulkhead: Bulkheads secured so tightly so as not to let water pass.



Wharf: A structure generally parallel to the shore.

Working Anchor: An anchor carried on a boat for most normal uses. Refers to the anchor used in typical anchoring situations.

Windlass: A winch used to raise and lower the anchor.

Windward: Toward the direction from which the wind is coming.

Yacht Basin: A protected facility primarily for recreational small craft.

Yaw: When a boat runs off her course to either side.



Maintenence Schedule

Maintenance	Each Use	Weekly	Monthly	Semi- Annually	Yearly	As Nedeed
Clean hull below the waterline				X		
Bottom paint					X	x
Check sacrificial anodes			x			
Replace sacrificial anodes					X	
Wash boat canvas& hardware	X		x			
Wax exterior gelcoat				X		x
Clean & protect hardware						X
Polish & protect plastic glass					X	x
Clean exterior upholstery	X					X
Clean cabin & interior upholstery						x
Flush engine with fresh water	X					
Spray metal components in bilge with a protector			x			
Clean bilge				x		x
Check bilge for leaks	х		x			
Inspect & operate thru-hull valves			x			
Inspect steering & control systems	х					
Service steering & control systems				x		
Inspect fuel system for leaks	х					
Inspect & service fuel system				x		
Inspect fuel tank vents & screens					X	
Replace fuel filters					х	
Lubricate fuel fill O-rings			x			
Inspect fire extinguisher			x			
Test bilge pump auto switches	X					
Inspect & protect electrical compo- nents, wire & battery connections				x		
Check battery electrolyte & service			x			
Test and inspect AC electrical system & shore power cord				x		
Inspect water systems for leaks				x		
Check neutral safety switch	X					
Check trim tab operation			X			



Maintenance Log

Date	Hours	Dealer	Service/Repairs



Date	Hours	Dealer	Service/Repairs



Section B

Date	Hours	Dealer	Service/Repairs



Boating Accident Report

		S. Coast			OMB Control Number: 1625-0003 Expires: 12/31/2015								
owner or operator involved in the a separate report. For each que U.S.C. 6102 and 33 CFR 173 & purposes, chiefly to inform the p	INSTRUCTIONS: Use "Report required because" section below to determine if a report is required for your accident. If required, please have each vessel owner or operator involved in the accident submit a report to their state reporting authority. Each boat operator/owner involved in an accident should submit a separate report. For each question below, please provide answers if applicable and if known; otherwise leave blank. Privacy Act Notice: Authority- 46 U.S.C. 6102 and 33 CFR 173 & 174 authorize the collection of information on boating accidents. Purpose-The Coast Guard uses this information for statistical purposes, chiefly to inform the public, to measure the Program's efforts, and to regulate issues relating to boating safety. Routine Uses-The Coast Guard shares this information within the agency, and if state and federal law permit it, to the public.												
	RE	PORT S	SUBMISSION										
Report required because	e (select all that apply):			To be submitte	ed within:								
At least one person in	this accident died: If s	so, how ma	iny?		ry, disappearance or death)								
At least one injured per treatment beyond first	erson in this accident <i>requ</i> t <i>aid</i> : If s		s in need of iny?	To be submitted	/property damage only) I to: (Local State Reporting								
At least one person in recovered:	h this accident <i>disappeared</i> اf s	d and has r so, how ma		Authority)									
by this accident <i>totale</i> Approximate value		or more: \$ property: \$		Phone: You may submit any comments concerning the accuracy of the burden estimate or any suggestions for reducing the burden to: Commandant (CG-5422), U.S. Coast Guard, Washington, DC 20593-0001 or Office of Management and Budget, Paperwork Reduction Project (1625-0003), Washington, DC 20503. Question relating to the collection of this data should be sent to the Coast Guard.									
Boat Operator (require	ed if possible)			For S	tate Agency Use Only								
	or unable, or same as ope	,		First Name	Last Name								
				Phone:									
First Name	Last Name	Phone		Primary Cause	of Accident								
	AC	CIDENT	SUMMARY	/									
WHEN					Briefly describe this accident								
Date: (mm/dd/yyyy)	Time: am <i>(sele</i>	pm	(attach extra p	bages if necessary)									
WHERE Body of Water Name			-										
body of Water Name													
Location (on water) descri	iption		DAMAGE TO	O YOUR BOAT: E	Briefly summarize any damage to								
Nearest city/town													
County:	State:												
YOUR BOAT – PEOPLE					PROPERTY: (NOT BOAT)								
# people on board (includi	ing operator):		Briefly summa	arize any damage to	your other property (not boat)								
# people being towed (e.g	., on tubes, skis):												
# people wearing lifejacke	ets (on board or towed):												
OTHER BOATS INVOLV	ED IN ACCIDENT												
# of other boats involved:													

CG-3865 (6/13)

Page 1 of 6

Reset



For ea	For each question below, please provide answers IF APPLICABLE AND IF KNOWN, otherwise leave blank.																				
									YO	UR	BC	DA	Т								
BOAT IDENTIF	ICA	TIC	DN																		
Your Boat Name:											N	Manufacturer:									
Model Name:										Model Year:											
Registration #:											D	οοι	imentati	on #:							
Hull Identification	#											Rent	odi	Yes		Г	No				
(HIN)												ven.	eu.	Lites							
															-						
Length: ft. Depth from transom (stern) to keel (bottommost point):									ť	ft.			in.	Be	am	width at v	vides	st point:		ft.	
HULL MATERI	AL																				
Type of Hull Material (select one)																					
Fiberglass					Woo	bd						1	Rubber/	vinyl/canva	as		0	Other	(describe	<i>;):</i>	
Aluminum					Stee	əl						1	Plastic								
BOAT TYPE																					
Boat Type (select one) Available Propulsion (select all that apply) Cabin motorboat Inflatable Cappe Personal watercraft (PWC) Propeller Air thrust												at apply)									
Cabin motort	ooat		Infla	atable			Canoe)								Pro	peller		Air thru	st	
Open motorb	oat		Ηοι	lseboa	t		Rowbo	oat					ve Runn a-Doo™)	er™, Jet		Sail			Other (desc	:ribe):
Auxiliary sail			Sai	(only)			Air bo	at		0	ther	(de	scribe)		Manual						
Pontoon boa	t		Kay	/ak										Water jet							
ENGINE																					
# Engines			Engi	ne type	and	hor	sepov	ver (se	lect c	one)					Fue	l typ	e (select	all ti	hat apply)		
Manufacturer			0	utboard	k k	:	Sternd	rive (l/	0)		Inbo	bard		None		Gas	oline		Diesel		Electric
			Total	horse	powe	r:		hp													
SAFETY MEAS	URE	ES																			
Organizations th equipment, e.g.,										on t	ooard	d yo	ur boat	within the	past y	/ear	(includin	g ca	rriage of s	afety	V
US Coast Gu	uard A	Aux	iliary:	VSC	Deca	al?		Yes	ΠNο			Federal Agency (· · ·							
US Power So	quadr	ron	s:	VSC	Deca	al?		Yes		No	╞	State Agency (Name		,	_						
di life incluste en l				# =:										Agency (Na	,						
# Life jackets on	board	1:				-		on boar ers use						extinguish							
							•								0		useu.				
				A	CCI	JEI		ETAI	L3	- 6	:	Er	KNAL	CONDI		12					
WEATHER		. (0	oloot	2001			14 34	aa (aa)	oot o	nol	V	icib	ilitywa	s (select o	001	\ M /i	nd was	(00/0	of anal		
Overall weathe Clear	rwas	s (S		ining			11.W	as (sel Day	ecio	me)			Good	s (select o	ne)		nd was (0 mph (i		,		
Cloudy		+	_	lowing				Night					air						/ o 12 mph	(liaht	t)
Foggy				izy								_	Poor						to 25 mph		
Other (descr	ibe):						An	proxim	ate a	ir te	mne	ratu	ire:	٩F				<u> </u>	to 55 mph	· ·	ong)
							proxim			mpo	nute		•			Over 55	mph	ו (stormy)			
WATER																					
Overall water co				ect one):				Oth	her v	wate	er co	ondition					1			
Up to 6 in. w			,	, .									Арр	oroximate v		· ·			•	- T	
Over 6 in., u									Strong current? Yes					No							
Over 2 ft., up					n)				Haz	zard	ous	wat	ers? (e.	g., rapid tic		,	,		Yes		No
Over 6 ft. wa	ves (ver	y roug	n)										Co	onges	ted v	vaters?		Yes		No

CG-3865 (6/13)

Page 2 of 6

Reset



Boating Accident Report

ACCIDENT		please provid				PERATIONS (N	
			(C	TIVITIES ANL	<u> </u>	FERATIONS (FOUR BOAT
OPERATOR/PASSENGER AC			_	facidanti				
Operator/passenger activities or	1 90	ur boat at time	e c	accident:				
Activities were (select one)		Operator/Pas	se	enger activities (se	elec	t all that apply)		
Recreational		Fishing				Tubing		Starting engine
Commercial		Hunting				Water Skiing		Making repairs
	Ш	White water a	ct	vity (e.g., rafting)		Relaxing		Other (list):
BOAT OPERATIONS								
Your boat operations at time of a		1	tł	nat apply)				
Cruising (underway under power)		Drifting				Racing		Towing another vessel
Changing direction		At anchor				Rowing/paddling		Launching
Changing speed	\square	Being towed				Docking/undocking		Tied to dock/mooring
Sailing		Other (list)						
ACCIDE		DETAILS -	- (CONTRIBUTIN	١G	FACTORS ON	γ	OUR BOAT
CONTRIBUTING FACTORS								
ndicate factors on your boat wh	ich	may have con	ıtr	ibuted to this acci	dei	nt (select all that app	ly)	
Alcohol use		Improper look	οι	ıt		Dam/lock		Starting in gear
Drug use		Operator inatte	er	ition		Force of wake/wav	e	Sharp turn
Excessive speed	\square	Operator inex	pe	rience		Hazardous waters		Restricted vision (e.g., fog)
Improper anchoring	Π	Language bar			Heavy weather	T	Mission/inadequate aids to navigation (e.g., buoy, daymarker,	
Improper loading	Ħ	Navigation rule	violation		lgnition of fuel or vapor		Inadequate on-board navigation	
Overloading	\vdash	Failure to vent	t			Hull failure	╈	People on gunwale, bow or transo
Other (describe):							_	
Gulei (describe).		A.C.C.I.F.	~		_			
		ACCIL	7	ENT DETAILS	- 1	YOUR BOAT		
MACHINERY/EQUIPMENT FA	ILU	RE						
Failure of the following machine	ry/eq	quipment on y	/0	ur boat contribute	d t	o this accident (sele	ect a	all that apply)
Engine		Onboard lights	s			Shift		Sound equipment (e.g., horn, whist
Electrical system		Seats				Radio		Auxiliary equipment
Fuel system		Steering				Fire extinguisher		Other (list):
Sail/mast		Throttle				Ventilation		
Onboard navigation aids (e.g.,	GPS	s)						
	AC	CIDENT D)E	TAILS - EVE	NT	S ON YOUR B	OA	ΛT
ACCIDENT EVENTS								
Types of events occurring to/on	you	r boat during	a	cident (select all t	hat	apply)		
Collision with recreational boat	-	Ĭ		Flooding/swampin	a		Pe	erson fell overboard
		tur homol	-		-			
Collision with commercial boat			_	Fire/explosion – fu				erson fell on/within boat
Collision with fixed object (e.g.,	doc	k, bridge)		Fire/explosion – n	on-	fuel	Sι	udden medical condition
Collision with submerged objec cable)	:t (e.g	g., stump,		Carbon monoxide	ex	posure	Pe	erson struck by boat
Collision with floating object (e.g., log, buoy)				Mishap of skier, tu boarder, etc.	ibe	r, wake	Pe un	erson struck by propeller or propulsio it
Capsizing			Person left boat v	olui	ntarily	Pe	erson electrocuted	
		Person ejected from boat (caused by collision or maneuver)						
Grounding Sinking				Other (describe)				

Reset



For each question below, please provide answers IF APPLICABLE AND IF KNOWN, otherwise leave blank.

ACCIDENT DETAILS -YOUR BOAT-

INJURED PEOPLE RECEIV	VING	OR	!N	NEE	ΞD	OF TREATME	ENT BEYO	ND F	1	RST AID		
Report only injured people on, struck by, or being injured people on, struck by, or being towed by a to report, attach additional copies of this page. If	nother	boat	or no	boat	(e.g	g., swimmers, peop						
INJURED PERSON												
First Name		MI		L	.ast	Name						
Street		1										
City		Stat	е				Zip					
Phone			e of E ∕dd/y				Age					
INJURY DETAILS												
Injury caused when person (select all that apply	y)				Na	ature of most serio	ous injury (sel	lect on	e)			
Struck the (e.g., boat, water):						Scrape/bruise		Di	slo	ocation		
Was struck by a (e.g., boat, propeller):						Cut		Int	er	nal organ ir	njury	/
Was exposed to carbon monoxide poisoning						Sprain/strain		An	np	utation		
Received an electric shock						Concussion/brain	n injury	Bu	Burn			
Other (describe):						Spinal cord injury		Ot	Other (describe):			
Person was wearing lifejacket?	Y	es		No		Broken/fractured	bone					
Person received treatment beyond first aid?	Y	es		No	Bo	ody part of <i>most sei</i>	rious injury (e.g	g., hea	d,	trunk, leg):		
Person was admitted to a hospital?	Y	es		No								
ACCIDENT DETAIL	.s –	γου	IR E	BOA	Т-	- DEATHS/DIS	SAPPEARA	ANCE	Ξ\$	5		
Only report deaths/disappearances of people on, If more than one death/disappearance to report, a If none. SKIP DEATHS/DISAPPEARANCES sect	attach			•								
PERSON WHO DIED/DISAPPEARED												
First Name		MI		L	.ast	Name						
Street												
City		Stat	е				Zip					
Phone			e of E /dd/yy				Age					
DETAILS OF DEATH/DISAPPEARANCE												
Injury caused when person (select all that apply	y)				Nat	ture of death/disa	ppearance (se	lect or	ıe,)		
Struck the (e.g., boat, water):						Death – by drown	ing					
Was struck by a (e.g., boat, propeller):						Death – other like	ly cause (desc	ribe)				
Was exposed to carbon monoxide poisoning												
Received an electric shock						Disappeared and	not yet recover	red		· · · · · · · · · · · · · · · · · · ·		
Other (describe):						Person was wear	ring lifejacket	?		Yes		No

Page 4 of 6

Reset



CG-3865 (6/13)

For each ques	stion below, please provi	ide answers	IF APP	LICABLE AND IF	KNOWN, otherwise	e leave	e blan	k.		
	ACCIDENT	DETAILS	– YOL	IR BOAT OPE	RATOR					
OPERATOR INSTRUC	TION		OPEF	ATOR SAFETY	MEASURES					
Boating safety instruction	on completed (select all th	at apply)	On bo	ard, prior to accid	ent, was operator w	earing	:			
None					Yes	;	No			
State course			A	n engine cut-off swi	Yes	;	No			
USCG Auxiliary course	9		On bo	ard, prior to accider	nt, was operator using	I:				
US Power Squadrons	course				Alcoho	ol?	Yes	;	No	
Internet (name of spor	nsoring organization)				Drug	s?	Yes	;	No	
Other (describe)			Operate	or arrested for Boat	ing Under the Influence	ce?	Yes	;	No	
			v V	/eather reports con	sulted prior to accider	nt?	Yes	;	No	
OPERATOR EXPERIE	NCE									
Experience operating th	is type of boat (select one	ə)								
0 to 10 hours	Over 10, up to 100 ho	urs		Over 100, up to 50	0 hours	Ov	er 500	hours		
		S – O	THER KEY PE	OPLE						
	ple <i>not already documented</i> y people to report, attach ad	•			pr/owner of <i>your</i> boat.					
NAME/ADDRESS										
This other key person w	vas a(n) (select all that appl	ly)								
Other boat operator	Other boat owner	Owner of	other da	maged property	Passenger on yo	our boa	t 🗌	Witn	ess	
First Name		МІ		Last Name						
Street										
City		State		Zip	Phone					
<i>Other</i> boat name <i>(if any)</i>				Other boat registr	ation # (if any)					
NAME/ADDRESS										
This other key person w	vas a(n) (select all that appl	ly)								
Other boat operator	Other boat owner	Owner of	<i>other</i> da	maged property	Passenger on yo	our boa	t 🗌	Witn	ess	
First Name		МІ		Last Name						
Street										
City		State		Zip	Phone					
Other boat name (if any)				Other boat registr	ation # (if any)					
CC 2865 (6/42)								Pac	5 of C	
CG-3865 (6/13)							Г	-	e 5 of 6	
							L	Res	;et	

For each que	stion below, please p	rovide answers I	F APPLICABLE	AND IF KNOWN,	otherwise leave blank.
		YOUR BO	AT OPERATO	R	
NAME/ADDRESS					
First Name		МІ	Last Name		
Street		I			
City		State	Zip		
AGE/GENDER/PHON	E				
Date of Birth (mm/dd/yyyy)	Age	Gender	Male	Female	Phone
	,	YOUR B	OAT OWNER		
If same as your boat o	operator SKIP rest of	YOUR BOAT OW	/NER section.		
NAME/ADDRESS/PH	ONE				
First Name		М	Last Name		
Street		I			
City		State	Zip		Phone
	PEF	RSON SUBMI	TTING THIS I	REPORT	
If same as <i>your</i> boat o	operator OR owner, SI	KIP rest of PERS	ON SUBMITTIN	G THIS REPORT	section.
NAME/ADDRESS/PH	ONE/ROLE				
First Name		М	Last Name		
Street		I			
City		State	Zip		Phone
I was a(n) (select one)					
Other person on boa	ard <i>this</i> boat				
Accident witness no	<i>t</i> on board <i>this</i> boat				
Other (describe):					
Your signature	SIGNATURE	OF PERSON		G THIS REPO	T Date (mm/dd/yyyy)
rour signature					Date (mm/dd/yyyy)
displays a currently The Coast Guard es concerning the accu 5422), U.S. Coast G	valid OMB Control Nu timates that the avera racy of this burden es	mber. Ige burden for thi timate or any sug 2 20593-0001 or	is report form is ggestions for red	30 minutes. You n ucing the burden t	ation collection, unless it nay submit any comments o: Commandant (CG- ; Paperwork Reduction
CG-3865 (6/13)					Page 6 of 6
					Reset





FLOAT PLAN

INSTRUCTIONS: Complete this plan before you go boating and leave it with a reliable person who can be depended upon to notify the Coast Guard, or other rescue agency, should you not return or check-in as planned. If you have a change of plans, or will be delayed, notify the person holding your Float Plan. Finally, close your plan by notifying the holder you have arrived home safely and if the holder has reported you overdue, notify all applicable rescue authorities of your safe return.



the holder has reported you overdue, notify all app	
www.cgaux.org Do NOT file this plan v	
VESS	
IDENTIFICATION:	COMMUNICATION:
Name & Hailing Port	Radio Call Sign / Number
Document / Registration No HIN	DSC MMSI No.
Year, Make & Model	Radio-1: Type Ch. / Freq. Monitored
Length Type Draft Hull Mat	Radio-2: Type Ch. / Freq. Monitored
Hull & Trim Colors	Cell / Satellite
Prominent Features	Email
PROPULSION:	NAVIGATION: (Check all onboard)
Primary Type Eng. Fuel Capacity	Compass Radar GPS / DGPS Depth Sounder
AuxiliaryType Eng. Fuel Capacity	Charts Maps
SAFETY & S	SURVIVAL
VISUAL DISTRESS SIGNALS: AUDIBLE DISTRESS SIGNALS:	ADDITIONAL GEAR:
Electric Distress Light (night only)	Anchor - Line length Food for days / person
Flag (day only)	Dewatering device Water for days / person
Flare, Aerial (day & night)	Exposure suits
Flare, Handheld (day & night) EPIRB:	Fire Extinguisher
Signal Mirror (day only) UIN*	Flashlight / Searchlight
Smoke (day only)	Raft / Dinghy
PERSONS (DNBOARD
OPERATOR:	
Name	Has experience with: \Box this vessel; \Box the boating area(s).
Address	Home Phone
City State Zip Code	Vehicle (Year, Make & Model)
Age Gender PFD PLB UIN*	Vehicle License No Trailer
Note	Vehicle parked at
Float Plan Note	
PASSENGERS / CREW: (Identify all on board)	Passenger PLB UIN*
Name Home Phone Age Gender PFD	
1	
2	
3	
4	

If you have a genuine concern for the safety or welfare of the persons onboard this vessel that have not returned or checked-in, in a reasonable

5._____

6._____



7.

8.

9.

10.

11.

12.



FLOAT PLAN continued

INSTRUCTIONS: Complete this plan before you go boating and leave it with a reliable person who can be depended upon to notify the Coast Guard, or other rescue agency, should you not return or check-in as planned. If you have a change of plans, or will be delayed, notify the person holding your Float Plan. Finally, close your plan by notifying the holder you have arrived home safely and if the holder has reported you overdue, notify all applicable rescue authorities of your safe return.



www.cgaux.org

١	www.cgau>	k.org		Do NOT file this plan with the U.S. Coa	st Guard	www.L	scgboating.org
				CONTACTS			
Cor	tact 1				Phone Numb	er	
						er	
Res	cue Autho	rity			Phone Numb	er	
				ITINERARY			
	Denert	DATE	TIME	LOCATION / WAYPOINT	MODE OF TRAVEL	REASON FOR STOP	CHECK-IN TIME
1	Depart Arrive						
2	Depart						
	Arrive						
3	Depart						
	Arrive						
4	Depart						
	Arrive						
5	Depart						-
	Arrive						
6	Depart						
-	Arrive						
7	Depart						
	Arrive						
8	Depart						
_	Arrive						
9	Depart						
10	Arrive						
10	Depart						
11	Arrive						
1.1	Depart						· · · · · · · · · · · · · · · · · · ·
12	Arrive						
12	Depart						
13	Arrive						
	Depart						
14	Arrive						
	Depart						
15	Arrive						
	Depart						
16	Arrive						
	Depart						
17	Arrive						
	Depart						
18	Arrive						
	Depart						
19	Arrive						
	Depart					1	
20	Arrive						
21	Depart Arrive						
21	Arrive						

If you have a genuine concern for the safety or welfare of the persons onboard this vessel that have not returned or checked-in, in a reasonable amount of time, then follow the step-by-step instructions on the Boating Emergency Guide™ located on the last page of this Float Plan.

USCG Float Plan Version 10.2

Copyright 2015 Coast Guard Auxiliary Association, Inc. All rights reserved.



USCG Float Plan - BOATING EMERGENCY GUIDE™

BEFORE YOU BEGIN – This guide is designed to work either with or without a Float Plan. You will need the following items: 1) the <u>Float Plan</u>, if one was given to you; 2) a <u>pen</u> or <u>pencil</u>; 3) a clean sheet of <u>paper</u> or <u>writing tablet</u>; and 4) your local <u>telephone directory</u>.

Step 1: Do you have a genuine concern for the safety or welfare of any persons who have not returned or checked-in, in a reasonable amount of time?

If <u>yes</u>, then continue with **Step 2**. Otherwise **STOP** -- no further action is required at this time.

Step 2: Were you given a prepared Float Plan by anyone on board the vessel?

If yes, then continue with Step 3. Otherwise, go to Step 5.

Step 3: Locate the Contacts at the top of page 2 on the Float Plan. Call Contact number 1...

IF CONTACT #1	THEN		
Answers phone	 Take notes during your conversation. Let the person know you are responding to a late return or check-in by the individuals designated on the Float Plan. Determine if the person you are talking to, or anyone else at that location, has recently had contact with anyone on the vessel, and when and where that contact occurred. Are you still concerned about the safety or welfare of any persons on board the vessel? 		
		IF	THEN
		Yes	Continue with Step 4.
		No	STOP . No further action is required.
Does not answer phone	Continue with Step 4 .		

Step 4: Call Contact number 2...

IF CONTACT #2	THEN		
	Take notes during your conversation.		
	1.	to a late re	rson know you are responding eturn or check-in by the s designated on the Float Plan.
Answers phone	2.	 Determine if the person you are talking to, or anyone else at that location, has recently had contact with anyone on the vessel, and when and where that contact occurred. 	
	3.	Are you still concerned about the safety or welfare of any persons on board the vessel?	
		IF	THEN
		Yes	Continue with Step 6.
		No	STOP . No further action is required.
Does not answer phone	Continue with Step 6.		

Step 5: Using the checklist below, jot down only what you know about each item:

DO NOT SPECULATE. Incorrect information may mislead Search and Rescue personnel; add to the overall search and rescue time; and adversely affect the outcome.

- Period of time the vessel has been overdue.
- Purpose of the trip or voyage.
- Description of vessel. (Type, size, color, features, etc.)
- Vessel's departure point and destination.
- Places the vessel planned to stop during transit.
- Navigation equipment aboard. (Examples: GPS, radar, compass, sounder, etc.)
- Number of persons aboard. Relevant characteristics such as dependability, reliability, etc.
- Was the vessel initially docked or moored or did a vehicle tow it to a launch point?
- License plate number and description of the tow vehicle p and/or the passenger's transport vehicle.
- Communications equipment aboard, including type of radio and frequencies monitored, cellular or satellite telephone numbers of individuals, etc.
- Additional points of contact along the vessel's planned route.
- Operator and/or a passenger/crew member absolutely had to be back at the scheduled return time.
- Call your local Rescue Authority that responds to marine emergencies (Police. Sheriff, Constable, First responder, etc.).

Go to Step 6-2.

Step 6:

- 1. Call the Rescue Authority contact at the top of page 2 on the Float Plan.
- 2. Tell the dispatcher you are responding to a late return or check-in by the persons on board the vessel.
- 3. The dispatcher will instruct you from there.

Note: The dispatcher will provide you with the necessary contact or agency connection to get a search and rescue mission started. This puts you in direct contact with the agency conducting the actual search and rescue, eliminating unnecessary middlemen.

The dispatcher will tell you if he/she desires a follow-up call on the outcome of the rescue.

4. Continue with Step 7.

Step 7: Be patient... you've done everything you can possibly do for now. It is important to keep the telephone available so emergency personnel can contact you with additional information and/or questions concerning the search and rescue effort.

STOP -- End of Guide



The USCG Float Plan is the official Float Plan of the U.S. Coast Guard and U.S. Coast Guard Auxiliary. For more information visit:

www.floatplancentral.org

USCG Float Plan Version 10.2

3 of 3

Copyright 2015 Coast Guard Auxiliary Association, Inc. All rights reserved.



Operator Notes

Troubleshooting Guide

Problem	Cause and Solution	
Control Systems		
Hydraulic Steering is slow to respond and erratic.	 Steering system is low on fluid. Fill and bleed system. Steering system has air in it. Fill and bleed system. A component in the steering system is binding. Check and adjust or repair binding component. Engine steering cylinder is binding. Grease spindle. 	
The boat wanders and will not hold a course at cruise speeds.	 There could be air in the steering system. Fill & bleed the system. The engine steering tab is corroded or out of adjustment. Replace or adjust steering tab. Engine steering cylinder is binding. Grease spindle. 	
The engine will not start with the shift control lever in neutral.	 The control cable is out of adjustment & not activating the neutral safety cut out switch. The shift control lever is not in the neutral detent. Try moving the shift lever slightly. There is a loose wire on the neutral safety switch on the transmission. Inspect wires and repair loose connections. The starter or ignition switch is bad. 	
Performanc	e Problems	
Boat is sluggish and has lost speed and RPM.	 The boat may be need to have marine growth cleaned from hull and running gear. Propeller may be damaged & need repair. Weeds or line around the propeller. Clean propeller. Boat is overloaded. Reduce load. Check for excessive water in the bilge. Pump out bilge & find & correct the problem. The throttle adjustments has changed and the engine is not getting full throttle. Adjust the throttle cable. 	




Problem	Cause and Solution
The boat vibrates at cruising speeds.	 Propeller may be damaged and need repair. The propeller or propeller shaft is bent. Repair or replace damaged components. The running gear is fouled by marine growth or rope. Clean running gear. The engine is not trimmed properly. Trim the engine.
Engine F	Problems
The engine is running too hot.	 The engine raw water pick-up strainer up is clogged with marine growth. Clean pick-up. The engine raw water pump impeller is worn or damaged. Repair the pump. The engine thermostat is faulty and needs to be replaced.
The engine alternator is not charging properly.	 The battery cable is loose or corroded. Clean and tighten battery cables. The alternator is not charging and must be replaced. The engine battery isolator in the charg- ing system is not working properly. Replace the isolator. The battery is defective. Replace the bat- tery.
The engine suddenly will not operate over 2000 RPM.	 The engine emergency system has been activated. The onboard computer has sensed a problem and has limited the RPM to protect the engine. Find & correct the problem. The tachometer is bad and needs to be replaced.

Problem	Cause and Solution	
The engine is loosing RPM. The boat is not overloaded and the hull bottom and running gear are clean and in good con- dition.	 The engine may be having a problem with a sticky anti-siphon valve, located in the fuel line near the fuel tank, that is restricting the fuel flow. Remove & clean or replace the anti-siphon valve. The remote gasoline fuel filter could be dirty. Inspect and replace the fuel filter. The primary fuel filter on the engine may be dirty. Inspect and replace the fuel filter. The electronic engine control system on the engine is malfunctioning. Repair the engine is malfunctioning. Repair the fuel injection system. 	
Accessory Problems		
The livewell pump runs, but does not pump water.	 The strainer on the intake scoop is clogged preventing the water from getting to the pump. Put the boat in reverse to clean the strainer. There is an air lock in the system. Run the boat above 15 m.p.h. and the pick-up scoop will force the air lock past the pump and prime the system. The thru-hull valve is not open. Open valve. The valve in the livewell is not open. Open the valve in the livewell. 	
The automatic float switch on the bilge pump raises but does not activate the pump.	 The in-line fuse near the battery switch has blown. Replace the fuse. The pump impeller is jammed by debris. Clean pump impeller housing. The pump is defective. Replace pump. 	


Operator Notes




Schematics









PURSUIT. DC 365 dual console




PURSUIT DC 365 dual console




PURSUIT. DC 365 dual console







PURSUIT. DC 365 DUAL CONSOLE









PURSUIT. DC 365 DUAL CONSOLE




PURSUIT DC 365 dual console












PURSUIT. DC 365 DUAL CONSOLE












PURSUIT DC 365 dual console











Section F




















PURSUIT. DC 365 DUAL CONSOLE


































PURSUIT DC 365 DUAL CONSOLE











PURSUIT DC 365 DUAL CONSOLE


F-36




F-37










PURSUIT DC 365 DUAL CONSOLE













Section F



PURSUIT. DC 365 DUAL CONSOLE

Schematics



PURSUIT. DC 365 DUAL CONSOLE

Operator Notes

Fresh Water System

The fresh water system must be disinfected before first use and yearly at the beginning of each season. A clean sanitized fresh water system will greatly reduce the risk of developing coliform bacteria or other disease-causing organisms (pathogens) and will help protect the health of everyone onboard.

DISINFECT THE ENTIRE FRESH (POTABLE) WATER SYSTEM PRIOR TO USE AND YEARLY AT THE BEGINNING OF EACH SEASON. FAILURE TO DO SO CAN RESULT IN DEVELOPING COLIFORM BACTERIA OR OTHER DIS-EASE-CAUSING ORGANISMS (PATHOGENS) IN THE WATER SYSTEM. CON-SUMPTION OF CONTAMINATED WATER COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH.

Follow this procedure to disinfect the fresh water system, kill bacteria that may be present, and prepare the system for operation:

Note: The fresh water system may be filled with nontoxic potable water antifreeze. If antifreeze was not used, skip to step 7.

- 1. Turn both water heater valves to the normal operation position.
- 2. Open all faucets (hot & cold), setting single faucets to the warm position.
- 3. Switch ON the FRESH WATER PUMP breaker(s), located on the DC Distribution Panel. The pumps are self-priming.
- 4. When anti-freeze stops flowing out of the faucets, switch the pump breaker(s) OFF. Do not close faucets.
- 5. Fill the fresh water tank with clean, fresh water. The fill fitting for the water tank is on the deck amidships, labeled WATER. The tank should be filled until water runs out of the vent located on the hull side just below the fill.
- 6. Keeping all faucets open, switch the FRESH WATER PUMP breaker(s) ON and empty the water tank. When the water tank is empty turn the pump breaker(s) OFF.
- 7. Repeat steps 5 and 6 until all nontoxic potable water antifreeze is removed from the system.

Section G

- 8. Ensure the water system, including the water heater and pump(s), is drained completely.
- 9. Close all faucets.

Notify all persons aboard that the fresh water system is being sanitized. Do not allow anyone to drink from the fresh water system during the sanitizing process.

10. Prepare a chlorine sanitizing solution: in a container with 1 gallon of fresh water, mix 1/4 cup of Clorox® or Purex® regular unscented household bleach (5% sodium hypochlorite solution) for each 15 gallons of water tank capacity (**Table A-1**).

Water Tank Capacity	Cups of Bleach
15 Gal.	1/4 Cup
30 Gal.	1/2 Cup
45 Gal.	3/4 Cup
60 Gal.	1 Cup
75 Gal.	1-1/4 Cups
90 Gal.	1-1/2 Cups
105 Gal.	1-3/4 Cups
120 Gal.	2 Cups
135 Gal.	2-1/4 Cups
150 Gal.	2-1/2 Cups

Table A-1: Tank capacity vs. cups of bleach

- 11. Fill the fresh water tank halfway with clean, fresh water.
- 12. Pour the sanitizing solution into the water tank through the deck WATER fill fitting.
- 13. Fill the remainder of the tank with clean, fresh water. The tank should be filled until water runs out of the vent. (See step 5.)



Fresh Water System

- 14. Switch ON the FRESH WATER PUMP breaker(s).
- 15. At each faucet, run about 1/2 gallon of water out of each tap (hot and cold), then close the tap. You should be able to smell chlorine out of each tap.
- 16. Switch OFF the FRESH WATER PUMP breaker(s).
- 17. Allow the chlorine sanitizing solution to sit in the system for three (3) hours. A shorter time period will require a greater concentration of chlorine sanitizing solution to disinfect the water system.
- 18. Switch ON the FRESH WATER PUMP breaker(s).
- 19. Drain the chlorine sanitizing solution by opening all faucets (hot & cold), setting single faucets to the warm position, and empty the water tank. When the water tank is empty turn the pump breaker(s) OFF.
- 20. Ensure the water system, including the water heater and pump(s), is drained completely.
- 21. Fill the fresh water tank with clean, fresh water. The tank should be filled until water runs out of the vent. (See step 5.)
- 22. Keeping all faucets open, switch the FRESH WATER PUMP breaker(s) ON and empty the water tank. When the water tank is empty turn the pump breaker(s) OFF.
- 23. Repeat steps 21 and 22.
- 24. Final fill: Fill the fresh water tank with clean, fresh water. The tank should be filled until water runs out of the vent. (See step 5.)
- 25. Turn the FRESH WATER PUMP breaker(s) ON.
- 26. Open each faucet. When a smooth flow of water is observed from each hot and cold tap, close the faucet. When all faucets are closed, the pumps will shut off as the system pressure increases. Any air should now be purged from the system. Leave the FRESH WATER PUMP breaker(s) ON.

The fresh water system is now commissioned and ready for use.

To remove excessive chlorine taste or odor that might remain in the system, do the following:

- 1. Ensure the water tank has enough available capacity to accept 10 additional gallons. If there is ample room in the tank, proceed to step 3, below.
- 2. Drain at least 10 gallons of water out of the system so the following vinegar solution will have room to be added. To do this switch ON the FRESH WATER PUMP breaker(s) and open a faucet. When at least 10 gallons has been drained, close the faucet and turn the pump breaker(s) OFF.
- 3. Prepare a solution of one (1) quart vinegar to five (5) gallons fresh water.
- 4. Pour the vinegar solution into the water tank through the deck WATER fill fitting.
- 5. Repeat steps 3 and 4.
- 6. Allow the vinegar solution to agitate in the tank for 24 hours.
- 7. Switch ON the FRESH WATER PUMP breaker(s).
- 8. Drain the vinegar solution by opening all faucets (hot & cold), setting single faucets to the warm position, and empty the water tank. When the water tank is empty turn the pump breaker(s) OFF.
- 9. Close all faucets.
- 10. Fill the fresh water tank with clean, fresh water. The fill fitting for the water tank is on the deck amidships, labeled WATER. The tank should be filled until water runs out of the vent located on the hull side just below the fill.
- 11. Turn the FRESH WATER PUMP breaker(s) ON.
- 12. Open each faucet. When a smooth flow of water is observed from the hot and cold tap, close the faucet. When all faucets are closed, the pumps will shut off as the system pressure increases. Any air should now be purged from the system. Leave the FRESH WATER PUMP breaker(s) ON.
- 13. Repeat if necessary.



Acuatic Invasive Species

Aquatic invasive species (AIS) are plants and animals that occur in waters in which they are not native and whose introduction causes or is likely to cause economic or environmental damage or harm to human health. AIS have a negative impact on the waterway, its native species, and recreational and commercial uses of the waterway. As responsible boaters and citizens, each boat owner should do their part to prevent the spread of these aquatic hitchhikers. In many cases, it is also required by law. Check local regulations for any waterway where you will boat. After each boating trip, follow these three simple steps before you leave the water access to stop the spread of AIS: Clean, Drain, and Dry. This is the boater's way to help protect the environment from the damage that AIS can cause.



PATHWAYS OF AQUATIC INVASIVE SPECIES

We are living in a very different era where goods, people and services are being shipped around the world. Because of this globalized economy, different species are hitchhiking through many different pathways. Species can be moved to new locations in many ways, and most are a result of human activity, including recreational activities. Some common ways that species may be moved during recreational boating and other activities include:

- Attaching to watercraft, trailers, motor and fishing gear.
- Transport by water ballast water, bilge, and other water containing devices.
- Dumping of unwanted live bait.
- Tangled in fishing lines and downrigger cables
- Sticking to the soles of waders
- Trapped in mud on a dog's paws


Just one organism, or in some case a piece of a plant, is enough to start a new invasion.



GENERAL CLEAN DRAIN DRY PROCEDURE

Clean, Drain, Dry... In every waterbody, every time.

Preventing the spread of aquatic invasive species starts with you. A cooperative effort is necessary by all persons and agencies involved with recreational activities to achieve the best results and protect our aquatic resources and recreational opportunities. The general Clean Drain Dry procedure is described below:



CLEAN

Clean off visible aquatic plants, animals, and mud from all equipment before leaving water access. Inspect and clean motor or engine, including the lower unit and motor mounts; trailer, including axles, bunks, and rollers; anchors; dock lines; and equipment before leaving the water body.

- Rinse equipment and boat hulls (with high pressure, hot water when possible)
- Rinse interior compartments of boats with low pressure, hot water (120°F) for a minimum of 130 seconds contact time.
- Flush motor with hot water (120°F) for 2 minutes (or according to owner's manual)

DRAIN

Drain the motor, motor cooling system, bilge, live well, fish box, and other water containing devices before leaving water access.

DRY

Allow the boat to completely dry OR wipe with a towel before reuse, before visiting any other bodies of water. For ANGLERS, the additional step of DISPOSE is recommended.



DISPOSE

Dispose of unwanted bait, worms, and fish parts in the trash. When keeping live bait, drain bait container and replace with spring or dechlorinated tap water. Never dump live fish or other organisms from one water body into another. Together the three steps of Clean Drain Dry greatly minimizes the risk of spreading Aquatic Hitchhikers into new locations.

- Cleaning will remove visible large-bodied organisms attached to or in watercraft or recreational equipment. Rinsing with water removes organisms, while hot water often kills them. Water at least 120°F is recommended; be sure to avoid contact with skin and check manufacturers' recommendations to ensure equipment can withstand high temperatures. If hot water is not available or may cause damage, rinsing with tap water and completely drying will help prevent spread of aquatic invasive species.
- Draining removes small and nearly invisible organisms such as zebra mussel larvae (veligers) potentially entrained in water containing devices.
- Drying is necessary as many organisms can survive in standing water.

A note about chemicals. The use of chemical prophylactics or disinfectants (e.g., bleach) are not recommended for treating watercraft and recreational equipment. Chemicals may:

- Damage equipment or components
- Cause environmental damage
- Harm human health
- May not be effective against many aquatic invasive species

Report new sightings. If you think you have found an invasive species, note its exact location and, if possible, take a photo. Report new sightings to the appropriate authorities or use the USGS Sighting Report Form.

Know the rules! Specimens are needed to confirm sightings, but some jurisdictions prohibit possession and transport of invasive aquatic plants and animals. Before collecting specimens, contact your local natural resource management agency for instructions. Unauthorized introduction of plants, fish, or invertebrates into the wild is illegal in most states. Protect your property and our waters.

Remember that AIS Threaten the Environment, Recreation, Economy, and Human Health. Refer to the Stop Aquatic Hitchhikers! Website for more details (<u>www.StopAquaticHitchhikers.org</u>).



Operator Notes

